

Design and installation materials INABA DENKO https://www.inaba-denko.com

Beautiful Line SLIMDUCT<sup>™</sup> Region 1000 Reg

Remarks...For more details, general catalogues are available upon requests. Quality, technical information & packing details in the leaflet are subject to change without notice.

# INABA DENKI SANGYO CO.,LTD. Inaba Denko Products Overseas Sales Department

4-11-14, ITACHIBORI, NISHI-KU, OSAKA, JAPAN 550-0012 Tel: +81 (0) 6-4391-1920 Fax: +81 (0) 6-4391-1935 E-MAIL: inabadenko-overseas@gr-inaba.com

https://www.inaba-denko.com/en/



# For designing and installation companies

Before using "SLIMDUCT RD" ("the Product" hereinafter), read "SLIMDUCT RD Design and Installation Materials" carefully and perform designing and installation work properly for correct and safe use of the Product.

We cannot be held responsible for any damage (including but not limited to breakage, overturning and other accidents) caused by operating or installation methods which differ from that is described in this document.

#### Read the following first (for correct and safe use)

The Product is a decorative cover for air conditioning piping. Do not use for any other purpose.

■The following categories are used to indicate the degree of harm or damage that may occur when operating incorrectly ignoring what is indicated.

<b>⚠</b> Warning	ncorrect handling of the Product may result in death or serious injury of the user.			
<u> </u>	Incorrect handling of the Product may result in injury of the user.			
Notice Incorrect handling of the Product may result in property damages.				

■Observe the following instructions for preventing harm to the user and others and damage to properties.

<u></u> Marning	<ul> <li>Do not apply a load that exceeds the allowable load. Doing so may result in damage or fall.</li> <li>Use the bolts and nuts that come with the Product when assembling the parts and tighten them carefully without crushing bolt threads and nut corners, or it may cause loosening, fall, breakage and rusting.</li> </ul>
<b></b> Caution	<ul> <li>[General precautions for SLIMDUCT RD]</li> <li>Surface treatment is not provided, and the cut ends are exposed. Always wear work clothes, gloves, helmet, etc. when performing installation work.</li> <li>For preventing accidents, do not use the Product as a substitute for a scaffold or ladder. Doing so may result in a fall.</li> <li>[About the RD duct (walkway type)]</li> <li>It is designed for the purpose of being used as a walkway for maintenance work of outdoor units. Avoid using it as a normal walkway (comply with industrial safety and health regulations and other laws and regulations and perform installation work safely).</li> <li>Always wear gloves, helmet, etc. for safety when walking on it.</li> <li>Do not walk on the area near the joint parts and duct ends.</li> <li>The mounting brackets shall be mounted on the straight duct or at the designated positions of the part and firmly secured to the floor. Do not mount the bracket at locations where the joint parts are used.</li> </ul>
Notice	• This Product is not of the waterproof structure. If waterproof property is required, be sure to apply caulking or putty to the joints and coupling parts. If waterproof property is required for pipe shafts and other pipe exit points, use a water stop plate (RSP), water stop sleeve (RSB), bottom plate (RDB) or similar components, and apply caulking or putty.

#### Observe the following points

#### ■About handling

- (1) Do not damage the surface.
- (2) Do not place the Product directly on the ground for temporary placement (use non-wood liners to create a gap).
- (3) Do not handle the Product in the stuck condition in the rain.
- (4) When using acidic or alkaline chemicals (including cleaning fluids) during or after installation work, cover the duct with a sheet or the like to prevent contact with the chemicals.
- (5) When cutting piping made of copper, etc., cover the duct with a sheet, etc. to protect the duct from being exposed to metallic powders.

#### ■About storage

- (1) Store the duct in a well-ventilated room.
- (2) When storing the duct outside, place the duct with a gap from the ground in a well-drained area. Cover the duct completely with a sheet in rainy weather and remove the cover promptly in fine weather.
- Ensure that the duct is protected from seawater splashes when during marine transportation and storage on the quay.
- (3) When storing the duct in the stack, use non-wood cushioning materials to provide a sufficient gap between members, and provide a larger gap with the ground.

Appendix1

# For designing and installation companies

Read this "SLIMDUCT RD Design and Installation Materials" carefully and perform designing and installation work properly for correct and safe use of the Product.

#### **About the SLIMDUCT RD-ZA Series**

- SLIMDUCT RD-ZA series consist of uncoated steel plates, which causes the metallic luster of the Product surface to decrease and the color to change from gray to grayish black over time.
- Due to the production process of steel plates, SLIMDUCT RD-ZA series differs in the appearance of the steel plate surface (color and pattern) from one product to another. In addition, machining marks may be found due to unavoidable reasons of the product machining process. However, the steel base will not be exposed and the corrosion resistance will not reduce at all.
- As with the hot-dip zinc-coated finishing (HDZT), white rust will occur. However, that will not significantly reduce the corrosion resistance, because the white rust will work as the protective film.
- As with the hot-dip zinc-coated finishing (HDZT), blackening phenomenon will occur. However, that will not reduce the corrosion resistance.
- The black soot in the weld nut part inside the duct does not promote oxidation, and there is no problem in use.
- In the end face, red rust will occur in the early stage because the steel base is exposed. However, in several months after the installation, aluminum and magnesium will melt out from the plating layer of the plane sur face. The dense zinc-based protective film which contains the melted out aluminum and magnesium covers the end face, and produces an excellent corrosion resistance. (For the mechanism of corrosion resistance production in the end face, see [5.2])
- When you perform a cutting work on site, be sure to perform the repair work by using the zinc rich paint (Zn-Al).
- Stainless steel is used for bolts, nuts and washers, used for assembly of the Product. Due to the characteristics of thermal expansion and thermal conduction, seizure may occur depending on the tightening conditions.

#### **About appearance changes**

The surface of the highly corrosion-resistant hot-dip zinc-coated steel sheet forms a duplex dense oxide film composed of the following:

- (1) Magnesium-containing zinc-aluminum protective film
- (2) Magnesium-containing zinc-based protective film

It works as the protective film on the coated surface.

This protective film is very thin and transmits light, and the luster of the underlying zinc is seen. As time passes and the environment changes, however, the oxide film will become thick and will not transmit the light, resulting in losing luster and change to grayish black in color. This is called blackening.

#### **About white rust**

Highly corrosion-resistant hot-dip zinc-coated steel sheets contain zinc that has an ionization tendency higher than iron in its coated layer. By this, for cut end faces of the coated steel sheet and parts of surface where defects were developed due to flaws, sacrificial anticorrosion protection works and corrosion of the steel base is suppressed by zinc hydroxide (white rust).

Also, the surface of the coated steel sheet reacts with carbon dioxide and water in the air, zinc hydroxide (white rust) is formed on the surface, and corrosion is suppressed by its film. This zinc hydroxide (white rust) is formed almost evenly on the surface of the coated steel sheet. However, there are some cases where it is locally formed in a short time, e.g., in two hours or so if the formation of zinc hydroxide (white rust) is promoted by condensation etc. or the coated layer is damaged.

Therefore, it is important to minimize damage to the protective film on the surface during the installation work for maintaining the corrosion resistance for a long period of time. Care should be taken in handling and storage.

#### **About the SLIMDUCT RD-SUS**

Stainless steel has a strong resistance against rust. However, it can rust in a salt damage region, in a strongly acidic environment, or by contacting a dissimilar metal.

## About handling of the data

#### Read the conditions below carefully before using data contained in this document.

- The data contained in this document can be used only for the product design review when using our Product. Use of the data is prohibited for any purpose other than the above.
- Data contained in this document does not guarantee the specifications of our Product.We cannot be held responsible
  for any damage caused by using these data regardless of the reason.
- Values provided in the figures and tables of this document are not guaranteed to be the same as those of the actual products.
- Data is subject to change without prior notice for product improvement. Please understand.
- Alteration, reproduction or distribution of the data in this document is prohibited without permission from Inaba Denko.
- Take full responsibility for your use of this document.

Polyphyletic ducting system creating comfortable environment

# Beautiful Line SLIMDUCT RD

# Design and installation materials

<b>Design</b> P1 to P67
Installation · · · · P69 to P160
Materials · · · · · · P161 to P167

Installation Materials to

Appendix 2 Appendix 3

Table of contents

Table of contents

# Design

1 Specifications	s	1
1.1 Product	configuration	2
1.1.1	Product list · · · · · · · · · · · · · · · · · · ·	2
1.1.2	Product variations · · · · · · · · · · · · · · · · · · ·	3
1.1.3	Part name · · · · · · · · · · · · · · · · · · ·	3
1.2 Specifica	ations ·····	3
1.2.1	Material · · · · · · · · · · · · · · · · · · ·	3
1.3 Product	weight · · · · · · · · · · · · · · · · · · ·	4
1.3.1	Duct ·····	4
1.3.2	Parts · · · · · · · · · · · · · · · · · · ·	5
1.3.3	Mounting bracket · · · · · · · · · · · · · · · · · · ·	5
1.4 Load cap	pacity and strength · · · · · · · · · · · · · · · · · · ·	6
1.4.1	Allowable load of base (duct base + strut)·····	6
1.4.2	Strength of cover (allowable load) · · · · · · · · ·	6
1.4.3	Load capacity (allowable load) of mounting bracket $\cdots$	6
	nodation capacity · · · · · · · · · · · · · · · · · · ·	7
1.5.1	When using BHC the BIGTIE holder (for channel)	7
1.5.2	Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed	
	(thickness of insulation = Liquid pipe: 10 mm, Gas pipe: 10 mm) · · · · ·	8
1.5.3	Table of rough indication of accommodatable quantity of pipelines	
	in a case where the piping is not fixed (thickness of insulation = Liquid pipe: 10 mm, Gas pipe: 20 mm) · · · · ·	9
1.5.4	Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed (for the triple piping system)	10
2 Total design		11
_	sign flow·····	12
	on method (on the floor) · · · · · · · · · · · · · · · · · · ·	14
2.2.1	Installation by using mounting bracket · · · · · ·	14
2.2.2	Installation by using H-steel/channel steel $\cdots$	14
2.2.3	Installation by using channel	14
2.3 Installation	on method (on the wall surface) · · · · · · · · · · · · · · · · · · ·	15
2.3.1 2.3.2	Types of installation on the wall surface (vertical) · · · Feasibility of installation on wall face for each product type · · ·	15 15
2.3.3	Conditions for installation on the wall surface (directly on the wall surface)	16
2.3.4	Conditions for installation on the wall surface (suspended from the wall surface)	17
2.4 Installation	on method (hanging from the ceiling) · · · · · · · ·	18
2.4.1	Notes on hanging from the ceiling · · · · · · · · ·	18
3 Design of	each part ·····	19
3.1 Duct		20
3.1.1	Product configuration	20
3.1.2 3.1.3	Load capacity · · · · · · Selecting duct · · · · · · · · · · · · · · · · · · ·	20 20
3.1.4	About installation on the wall surface and by hanging from the ceiling · · ·	20
3.1.5	Position to set the mounting bracket (for installation on the floor) · · ·	21
3.1.6	Notes on designing · · · · · · · · · · · · · · · · · · ·	21
3.1.7	Cutting duct · · · · · · · · · · · · · · · · · · ·	21
•	Ift and wall penetration	22
3.2.1	Installation example of Pipe shaft and wall penetration (installation outdoors on the floor)	22
3.2.2 3.2.3	Installation of RWP wall flange · · · · · · · · · Installation of RSP wall sleeve · · · · · · · · · · · · · · · · · ·	23 24
3.2.4	Installation of RSB cut-off wall plate · · · · · · ·	24
3.2.5	Installation of RSPC water shut-off plate protection cover · · · ·	25
3.2.6	Installation of CB chamber box (removal from the front) · · · · · · · · · · · · · · · · · · ·	26
3.2.7	Installation of CB chamber box	
2.2	(removal from the bottom)	27
3.2.8 3.2.9	Installation of chamber box (self-making) · · · · Wall penetrating installation method (indoors) · · · ·	28 28
5.2.9	Trail perioraling installation (induols)	20

3.3 0			
	Connection	on method · · · · · · · · · · · · · · · · · · ·	29
	3.3.1	Table for selecting connection method · · · · ·	29
	3.3.2	Coupler-free connection · · · · · · · · · · · · · · · · · · ·	30
	3.3.3	RSJ fixing coupler · · · · · · · · · · · · · · · · · · ·	30
		RFJ free coupler · · · · · · · · · · · · · · · · · · ·	30
	3.3.4		
	3.3.5	RSS sliding coupler·····	32
	3.3.6	RR reducer · · · · · · · · · · · · · · · · · · ·	33
	3.3.7	Connection for 900/900H corner parts · · · · ·	33
	3.3.9	Connection for 900/900H joint (1) RXR·····	33
	3.3.8	Connection for 900/900H joint (2) RXJ · · · ·	34
	3.3.10	RXSS/RXSSW box joint sliding coupler · · · · · · ·	34
	3.3.11	RCSS sliding coupler for RCF-900 (H)-SUS · · · ·	35
3.4 N	1ounting	bracket · · · · · · · · · · · · · · · · · · ·	36
	3.4.1	Product configuration · · · · · · · · · · · · · · · · · · ·	36
	3.4.2	Load capacity · · · · · · · · · · · · · · · · · · ·	36
	3.4.3	Table for selecting a 150-type mounting bracket	
	00	(for installation on the floor)	36
	3.4.4	Table for selecting a mounting bracket other than 150-type	00
	0.4.4	(for installation on the floor)	27
	0.45		37
	3.4.5	Table for selecting a mounting bracket for installation on the wall surface	
		(basic installation example) · · · · · · · · · · · · · · · · · · ·	37
	3.4.6	Example of position for setting · · · · · · · · · · · · · · · · · · ·	38
	3.4.7	Position for setting · · · · · · · · · · · · · · · · · · ·	39
	3.4.8	Standard pitch between bases · · · · · · · · · · · · · · · · · ·	40
	3.4.9	Example of setting the mounting bracket · · · · ·	41
	3.4.10	RZC bracket attachment plate for vertical ell · · · · ·	42
	3.4.11	RBK-B auxiliary bracket for strut · · · · · · · · · ·	42
	3.4.12	RBK-A auxiliary bracket for duct base · · · · · ·	42
	3.4.13	RD-HB screw set for wall cover ·····	42
	3.4.14	RZY mounting bracket guide for duplex mounting · · ·	42
		RDY pipe support base · · · · · · · · · · · · · · · · · · ·	43
	3.4.16	RKT fixing bracket for fixing RD to shaped steel · · · · ·	43
	3.4.17	RKTW RD walkway fixing bracket for	40
	3.4.17	shaped steel·····	43
	2 / 10	RCT RD bracket for fixing channel·····	44
	3.4.19	Fixing (to floor) · · · · · · · · · · · · · · · · · · ·	44
3.5 F	ittings		45
	3.5.1	Types of fittings · · · · · · · · · · · · · · · · · · ·	
			45
	3.5.2	RE 90°flat ell·····	
		RE 90°flat ell · · · · · · · · · · · · · · · · · ·	45
	3.5.2	RE 90°flat ell·····	45 46
	3.5.2 3.5.3	RE 90°flat ell · · · · · · · · · · · · · · · · · ·	45 46 47
	3.5.2 3.5.3 3.5.4 3.5.5	RE 90°flat ell · · · · · · · · · · · · · · · · · ·	45 46 47 49 50
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6	RE 90°flat ell	45 46 47 49 50 51
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7	RE 90°flat ell  RF 45°flat ell  RFS flexible corner  RT tee  RXN/RX cross  RCF 45°vertical ell	45 46 47 49 50
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6	RE 90°flat ell         RF 45°flat ell         RFS flexible corner         RT tee         RXN/RX cross         RCF 45°vertical ell         RC/RCI/RCO 90° vertical ell	45 47 49 50 51
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8	RE 90°flat ell	45 46 47 49 50 51
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7	RE 90°flat ell	45 46 47 49 50 51 53
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H)	45 47 49 50 51
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8	RE 90°flat ell  RF 45°flat ell  RFS flexible corner  RT tee  RXN/RX cross  RCF 45°vertical ell  RC/RCI/RCO 90° vertical ell  (for 150 to 600H)  RCI/RCO 90° vertical ell  (for 900/900H)  Installation of a mounting base on	45 46 47 49 50 51 53 56
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H)	45 46 47 49 50 51 53
36 B	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner	45 46 47 49 50 51 53 56 59
3.6 B	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H)· Installation of a mounting base on the elevation surface corner	45 46 47 49 50 51 53 56 61 62
3.6 B	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting	45 46 47 49 50 51 53 56 61 62 62
3.6 B	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 sottom pl 3.6.1 3.6.2	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position	45 46 47 49 50 51 53 56 61 62 62 63
3.6 В	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting	45 46 47 49 50 51 53 56 61 62 62
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 cottom pl 3.6.1 3.6.2 3.6.3	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation	45 46 47 49 50 51 53 56 61 62 62 63 64
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 sottom pl 3.6.1 3.6.2 3.6.3	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation vits	45 46 47 49 50 51 53 56 61 62 62 63 64
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 3.6.1 3.6.2 3.6.3 other par 3.7.1	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation ts RXH cover reinforcing plate	45 46 47 49 50 51 53 56 61 62 62 63 64 65
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 sottom pl 3.6.1 3.6.2 3.6.3	RE 90°flat ell  RF 45°flat ell  RFS flexible corner  RT tee  RXN/RX cross  RCF 45°vertical ell  RC/RCI/RCO 90° vertical ell  (for 150 to 600H)  RCI/RCO 90° vertical ell  (for 900/900H)  Installation of a mounting base on the elevation surface corner  ate  Type of bottom plate setting  Bottom plate usable position  Fittings necessary for bottom plate installation  ts  RXH cover reinforcing plate  RSK RD duct partitioning bracket for H type	45 46 47 49 50 51 53 56 61 62 62 63 64 65 65
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 3.6.1 3.6.2 3.6.3 other par 3.7.1	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation ts RXH cover reinforcing plate RSK RD duct partitioning bracket for H type RDK RD strut set	45 46 47 49 50 51 53 56 61 62 62 63 64 65
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 3.6.1 3.6.2 3.6.3 4ther par 3.7.1 3.7.2	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation  ts RXH cover reinforcing plate RSK RD duct partitioning bracket for H type RDK RD strut set REC end cap	45 46 47 49 50 51 53 56 61 62 62 63 64 65 65
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 3.6.1 3.6.2 3.6.3 3.7.1 3.7.2 3.7.3	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation  ts RXH cover reinforcing plate RSK RD duct partitioning bracket for H type RDK RD strut set REC end cap RPH PD supporting bracket	45 46 47 49 50 51 53 56 62 62 62 63 64 65 65 66 66 66
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 sottom pl 3.6.1 3.6.2 3.6.3 other par 3.7.1 3.7.2 3.7.3 3.7.4	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation  ts RXH cover reinforcing plate RSK RD duct partitioning bracket for H type RDK RD strut set REC end cap	45 46 47 49 50 51 53 56 59 61 62 63 64 65 66 66 66 66
	3.5.2 3.5.3 3.5.4 3.5.5 3.5.6 3.5.7 3.5.8 3.5.9 3.5.10 3.6.1 3.6.2 3.6.3 other par 3.7.1 3.7.2 3.7.3 3.7.4 3.7.5	RE 90°flat ell RF 45°flat ell RFS flexible corner RT tee RXN/RX cross RCF 45°vertical ell RC/RCI/RCO 90° vertical ell (for 150 to 600H) RCI/RCO 90° vertical ell (for 900/900H) Installation of a mounting base on the elevation surface corner ate Type of bottom plate setting Bottom plate usable position Fittings necessary for bottom plate installation  ts RXH cover reinforcing plate RSK RD duct partitioning bracket for H type RDK RD strut set REC end cap RPH PD supporting bracket	45 46 47 49 50 51 53 56 61 62 62 63 64 65 66 66 66 66 67

# Installation

4	Installation	n procedure	69
	4.1 How to p	roceed installation · · · · · · · · · · · · · · · · · · ·	70
	4.1.1	How to proceed installation · · · · · · · · · · · · · · · · · · ·	70
	4.1.2	Tools for installation · · · · · · · · · · · · · · · · · · ·	70
	4.2 Pipe shaf	ft and wall penetration ·····	71
	4.2.1	List of installation methods · · · · · · · · · · · · · · · · · · ·	71
	4.2.2	RWP wall flange · · · · · · · · · · · · · · · · · · ·	72
	4.2.3	RSP/RSPR wall sleeve · · · · · · · · · · · · · · · · · ·	73
	4.2.4	RSB cut-off wall plate·····	75
	4.2.5	RSPC water shut-off plate protection cover·····	76
	4.2.6	CB chamber box · · · · · · · · · · · · · · · · · · ·	77
	4.3 Mounting	bracket ·····	82
	4.3.1	List of parts for the mounting bracket $\cdots\cdots$	82
	4.3.2	RZ (RZM+RZB) RD mounting bracket	
		(for 300 to 900) · · · · · · · · · · · · · · · · · ·	83
	4.3.3	RZ-150, RZW RD mounting bracket (for 150) $\cdots$	85
	4.3.4	RZC bracket attachment plate for vertical ell $\cdot\cdot\cdot\cdot$	87
	4.3.5	RZY mounting bracket guide for duplex mounting $\cdot\cdot\cdot\cdot\cdot$	88
	4.3.6	RDY pipe support · · · · · · · · · · · · · · · · · · ·	89
	4.3.7	RZH RD mounting base reinforcing plate $\cdots$	89
	4.3.8	FL-B-Z cross-lock B type (for outdoor use)····	90
	4.3.9	RBK-B auxiliary bracket for strut · · · · · · · · · · · · · · · · · · ·	90
	4.3.10	RBK-A auxiliary bracket for duct base · · · · · · ·	91
	4.3.11	RKT RD bracket for fixing to shaped steel · · · ·	92
	4.3.12	RKTW RD walkway fixing bracket for shaped steel · · · · · · · · · · · · · · · · · ·	92
	4.3.13	RCT RD bracket for fixing channel······	94
	4.3.14	CR recycling lock (multipurpose support base) · · ·	95
	4.3.15	PB plastic base · · · · · · · · · · · · · · · · · · ·	96
	4.4 Duct	(straight pipe) · · · · · · · · · · · · · · · · · · ·	97
	4.4.1	RD Duct·····	97
	4.4.2	RDW walkway type duct · · · · · · · · · · · · · · · · · · ·	98
	4.4.3	Example of RD/RDW assembly · · · · · · · · · · ·	99
	4.4.4	RD/RDW coupler-free connection	
		<simple assembly="" method=""> · · · · · · · · · · · · · · · · · · ·</simple>	100
	4.5 Connection	on ·····	101
	4.5.1	Connection methods and part list · · · · · · · · ·	101
	4.5.2	Coupler-free connection · · · · · · · · · · · · · · · · · · ·	102
	4.5.3	RSJ fixing coupler · · · · · · · · · · · · · · · · · · ·	103
	4.5.4	RFJ free coupler · · · · · · · · · · · · · · · · · · ·	105


4.5.5	RSS sliding coupler · · · · · · · · · · · · · · · · · · ·	108
4.5.6	RR reducer (coupler type) · · · · · · · · · · · · · · · · · · ·	110
4.5.7	RR reducer (plate type) · · · · · · · · · · · · · · · · · · ·	111
4.5.8	RXR 900(H) type reducer for fittings $\cdots\cdots$	112
4.5.9	RXJ 900(H) type	
	coupler for fittings · · · · · · · · · · · · · · · · · · ·	113
4.5.10	RXSS/RXSSW box joint sliding coupler·····	114
4.5.11	RCSS sliding coupler for RCF-900 (H)-SUS $\cdots$	117
4.6 Fittings		119
4.6.1	Fittings list · · · · · · · · · · · · · · · · · · ·	119
4.6.2	RE 90° flat ell · · · · · · · · · · · · · · · · · ·	120
4.6.3	REW 90° flat ell (walkway type) · · · · · · · · · · · · · · · · · · ·	122
4.6.4	RF 45° flat ell · · · · · · · · · · · · · · · · · ·	123
4.6.5	RFW 45° flat ell (walkway type) · · · · · · · · · · · · · · · · · · ·	125
4.6.6	RFS flexible corner·····	127
4.6.7	RFSW flexible corner (for walkway type) · · · · · · · ·	129
4.6.8	RT tee · · · · · · · · · · · · · · · · · ·	131
4.6.9	RTW tee (walkway type) · · · · · · · · · · · · · · · · · · ·	133
4.6.10	RXN/RX cross · · · · · · · · · · · · · · · · · ·	134
4.6.11	RXNW/RXW cross (walkway type) · · · · · · · · · · · · · · · · · · ·	136
4.6.12	RCI 90° inside vertical ell · · · · · · · · · · · · · · · · ·	138
4.6.13	RCO 90° outside vertical ell · · · · · · · · · · · · · · · · ·	140
4.6.14	RC 90° vertical ell (150) · · · · · · · · · · · · · · · · · · ·	143
4.6.15	RCF 45° vertical ell · · · · · · · · · · · · · · · · ·	144
4.7 Bottom p	late · · · · · · · · · · · · · · · · · · ·	146
4.7.1	Bottom plate list · · · · · · · · · · · · · · · · · · ·	146
4.7.2	RDB bottom plate set for RD duct · · · · · · · · ·	147
4.7.3	REB bottom plate set for $90^\circ$ flat eII $\cdots$	150
4.7.4	RFB bottom plate set for 45° flat ell·····	151
4.7.5	RTS bottom plate set for tee · · · · · · · · · · · · · · · · · ·	152
4.7.6	RDBJ bottom plate for coupler · · · · · · · · · · · · · · · · · · ·	153
4.7.7	RJB retrofit bottom plate for coupler · · · · · · ·	154
4.7.8	RNB bottom net · · · · · · · · · · · · · · · · · · ·	155
4.8 Others		156
4.8.1	List of other members · · · · · · · · · · · · · · · · · · ·	156
4.8.2	REC end cap ·····	157
4.8.3	RPH PD supporting bracket · · · · · · · · · · · · · · · · · · ·	158
4.8.4	RDK RD strut set · · · · · · · · · · · · · · · · · · ·	159
4.8.5	RSK RD duct partitioning bracket for H type · · · ·	159
4.8.6	RDS caution sticker·····	160

# **Materials**

5 Materials		16
5.1 Specific	ations by Ministry of Land, Infrastructure, Transport and Tourism · · · · · · · · · · · · · · · · · · ·	162
5.1.1	Standard specifications of machinery and equipment installation by Ministry of Land, Infrastructure, Transport and Tourism · · · · ·	162
5.1.2	Supervision guidelines of machinery and equipment installation by Ministry of Land, Infrastructure, Transport and Tourism	162
5.2 About th	ne corrosion resistance of RD-ZA type · · · · · · · · · · · · · · · · · · ·	163
5.3 View of	snow accumulation·····	164
5.3.1	The Building Standards Act · · · · · · · · · · · · · · · · · · ·	164
5.3.2	Calculation of snow load for RD (example) · · · · · · · · · · · · · · · · · · ·	164
5.3.3	Other notes · · · · · · · · · · · · · · · · · · ·	165
5.4 Copper	pipe·····	166
5.4.1	Table of copper pipe specifications·····	166
5.4.2	Pipe weight (reference value) · · · · · · · · · · · · · · · · · · ·	166
5.5 SI units		167
5.5.1	Table of SI units · · · · · · · · · · · · · · · · · · ·	167
5.5.2	SI unit conversion table · · · · · · · · · · · · · · · · · · ·	167

Appendix 4 Appendix 5


Installation image Installation image



SLIMDUCT RD is a piping decorative cover aiming at accommodating and protecting polyphyletic copper pipes covered with insulation material for air-conditioning.

This product is equipped with slim-shaped excellent appearance, performance with high weatherability and durability, and workability enabling installation without using special tools or connecting members.

Since we launched this series, we have developed and improved various parts, and they have been used in various sites as the standard of refrigerant pipe duct for air conditioner for building.



Appendix 6



# Slim finish, Accommodation in order

#### Beautiful finish

Straight and curved lines are combined for slim finish, and pipes are accommodated in order.




# Functions

# Accommodating multiple pipes of various types

# Accommodating multiple pipelines

Multiple pipes of various types can be accommodated in different sizes. With a streamlined collective piping, multiple pipelines can be accommodated in a smaller area than the conventional method.



#### Simple installation design


No special tool is needed for connecting members and assembling ducts, enabling start of installation from the day of delivery.

#### Various installation methods

Various installation methods are supported including installation on the floor, wall, and ceiling, allowing free design planning depending on the installation conditions.\*

\* Some sizes are excluded.







# Toughness

# Excellent load capacity, durability, weatherability, and resistance to flaws

#### Excellent load capacity

The walkway type on which you can walk on the ducts in maintenance as well as various mounting brackets which have excellent load capacity are prepared.



# Excellent durability and weatherability

As to the material, two types with excellent durability and weatherability are prepared: highly corrosion-resistant hot-dip galvanized steel sheet\*1 and stainless steel sheet\*2 (made-to-order).

Especially the highly corrosion-resistant hot-dip galvanized steel sheet has the excellent weatherability which allows being used in a heavy salt damage region where the stainless steel (SUS304) cannot be used.

\*1 JIS G 3323 K27 \*2 JIS G 4305 SUS304

#### **Excellent resistance to flaws**

The highly corrosion-resistant hot-dip galvanized steel sheet is harder in its plated layer than the Galvalume or the hot-dip galvanized steel sheet owing to the effect of magnesium contained in the plated layer, producing an excellent resistance to flaws.

Also, even if a flaw is caused, the galvanized protective film covers the flaw in several months, presenting an excellent resistance to flaws.

# Design

# 1 Specifications

Product configuration · · · · · P2
Specifications · · · · P3
Product weight P4 to P5
Load capacity and strength P6
Accommodation capacity P7 to P10

Design

Product configuration, specifications,

pacity cor

Load ca

gn Accomm

stallation method the floor)

Installation method

> Installation method anging from the ceiling)

Dnc

Pipe shaft and wall penetration

Sonnection method

Mounting bracket

Fittings

Botton

Other pa


# 1.1 Product configuration

# 1.1.1 Product list


<Table 1.1.1-1>

Product type	Product name	Model number (duct size omitted)	Relate Design	ed item Installation
Straight pine	RD duct	RD	(3.1)	(4.4)
Ottaignt pipo	RD duct (walkway type)	RDW	[3.1]	[4.4]
Flhow		RE	[3.5.2]	[4.6.2]
2.000	90° flat ell (walkway type)	REW	[3.5.2]	[4.6.3]
Straight pipe  RD duct ( A5° flat el Flexible co Flexible co Flexible co 45° vertic 90° inside 90° outsid 90° vertic Tee Tee (walk Cross Cross Cross (walk Reducer ( R		RF	[3.5.3]	[4.6.4]
	45° flat ell (walkway type)	RFW	[3.5.3]	[4.6.5]
	Flexible corner	RFS	[3.5.4]	[4.6.6]
	Flexible corner (walkway type)	RFSW	[3.5.4]	[4.6.7]
	45° vertical ell	RCF	[3.5.7]	[4.6.15]
	90° inside vertical ell	RCI	[3.5.8]	[4.6.12]
	90° outside vertical ell	RCO	[3.5.8]	[4.6.13]
	90° vertical ell (for 150)	RC	[3.5.8]	[4.6.14]
Tee	1 1	RT	[3.5.5]	[4.6.8]
100	Tee (walkway type)	RTW	[3.5.5]	[4.6.9]
Cross		RXN/RX	[3.5.6]	[4.6.10]
0.000	Cross (walkway type)	RXNW/RXW	[3.5.6]	[4.6.11]
Reducer	Reducer (coupler type)	RR	[3.3.6]	[4.5.6]
rioddoli	Reducer (plate type)	RR	[3.3.6]	[4.5.7]
Counter	Fixing coupler	RSJ	[3.3.3]	[4.5.3]
Cross  Reducer  Coupler  End cover  Pipe shaft and penetrating part  Partition in ducts  Supporting pipes		RFJ	[3.3.4]	[4.5.4]
	Sliding coupler	RSS	[3.3.5]	[4.5.5]
	Reducer for 900-type fittings	RXR	[3.3.8]	[4.5.8]
	Coupler for 900-type fittings	RXJ	[3.3.9]	[4.5.9]
	Box joint sliding coupler	RXSS/RXSSW	[3.3.10]	[4.5.10]
	Sliding coupler for RCF-900 (H)-SUS	RCSS	[3.3.11]	[4.5.11]
End cover		REC	[3.7.4]	[4.8.2]
	RD wall flange	RWP	[3.2.2]	[4.2.2]
•	Wall sleeve	RSP	[3.2.3]	[4.2.3]
	Wall sleeve (inverted)	RSPR	[3.2.3]	[4.2.3]
	Cut-off wall plate	RSB	[3.2.4]	[4.2.4]
	Water shut-off plate protection cover	RSPC	[3.2.5]	[4.2.5]
	Chamber box	СВ	[3.2.6/3.2.7/3.2.8]	[4.2.6]
Partition in ducts	RD duct partitioning bracket	RSK	[3.7.2]	[4.8.5]
Supporting pipes	Pipe support base	RDY	[3.4.15]	[4.3.6]
	RD mounting bracket	RZM,RZB,RZ,RZW	[3.4]	[4.3]
	Fixing bracket for fixing RD to shaped stee	RKT/RKTW	[3.4.16/3.4.17]	[4.3.11/4.3.12]
	RD bracket for fixing channel	RCT	【3.4.18】	[4.3.13]
	Auxiliary bracket for strut	RBK-B	[3.4.11]	[4.3.9]
	Auxiliary bracket for duct base	RBK-A	[3.4.12]	[4.3.10]
	Bracket attachment plate for vertical ell	RZC	[3.4.10]	[4.3.4]
	RZ guide for duplex mounting	RZY	[3.4.14]	[4.3.5]
Bottom plate	Bottom plate set for RD duct	RDB	[3.6]	[4.7.2]
	Bottom plate for coupler	RDBJ	[3.6]	[4.7.6]
	Retrofit bottom plate for coupler	RJB	[3.6]	[4.7.7]
	Bottom plate set for 90° flat ell	REB	[3.6]	[4.7.3]
	Bottom plate set for 45° flat ell	RFB	[3.6]	[4.7.4]
	Bottom plate set for tee	RTS	[3.6]	[4.7.5]
	Bottom net	RNB	[3.6]	[4.7.8]
	Resin bush for bottom plate	RDB-B	[3.6]	[4.7]
Supporting branch pipes	PD supporting bracket	RPH	[3.7.5]	[4.8.3]
Strut		RDK	[3.7.3]	[4.8.4]
	Cover reinforcing plate	REH/RFH	[3.5.2/3.5.3]	
20.0.	Cover reinforcing plate (for 900 type)	RXH	[3.7.1]	4.6.5/4.6.10/4.6.1

# .1.2 Product variations



# 1.1.3 Part name



# 1.2 Specifications

# 1.2.1 Material

#### ■ Metal products

	Туре	Material		Surface treatment	Salt damage resistance
Stee	el sheet type	Highly corrosion-resistant hot-dip galvanized steel sheet (Molten zinc: 6%, Aluminum: 3%, Magnesium) JIS G 3323 K27	Standard product	_	Specificationwith heavy saltdamage resistance
Stai	inless type	Stainless steel sheet JIS G 4305 SUS304	Made-to -order	Hairline finish 2B finish	_

#### Resin products

Product name	Model number	Material	Color tone	Usage environment temperature range
Bottom net	RNB	PE (polyethylene)	Black	−20~70°C
Resin bush for bottom plate	RDB-B	PA6 (6-nylon)	Gray	-20 <sup>-3</sup> /0 C

Note If the product is used in a temperature lower than the minimum value of usage environment temperature, the strength of the resin itself is lowered, but the product will not be damaged as long as external stress is not applied.

#### Notes on the waterproof property

RD does not have the waterproof property, because RD is designed to be used with a insulation such as polyethylene foam that is of extremely low water absorption.

If waterproofness (preventing rain water intrusion) is required for the pipe takeout part etc., use the bottom plate for duct (RDB), wall sleeve (RSP), and cut-off wall plate (RSB), as well as be sure to apply caulking or take other means for waterproofing.

Reference [3.2] Pipe shaft and wall penetration

2

Model number REW-450-□

REW-450H-□

REW-600-□ REW-600H-

RFW-300-□

RFW-300H-

RFW-450-□

RFW-450H-□

RFW-600-□

RFW-600H-

RFSW-300 RFSW-300H

RFSW-450

RFSW-450H

RFSW-600

RFSW-600H

RFSW-900

RFSW-900H

RTW-300-□

RTW-300H-□

RTW-450-□

RTW-450H-

RTW-600-□

RTW-600H-

RXNW-300-□

RXNW-300H-

RXNW-450H-□

RXNW-600-□

RXNW-600H-□

RXW-900-□

RXW-900H-□

RXNW-450-□

(unit:kg)

Weight

11.1

13.3 15.8

19.0

6.2

7.7

9.5

10.5

11.8

14.2 2.5

3.1

4.0

4.7

6.6

7.4

10.1

11.2

9.0

10.8

14.4

16.4

22.6

25.5

8.8

10.7

14.5

16.4

21.7

23.5

37.4

40.5

Design

# **Product weight**

#### Table of contents

1.3.1	Duct ····	4
1.3.2	Parts ····	5
1.3.3	Mounting bracket ·····	5

# **Duct**

	Standard prod	luct		(unit : Walkway type					
Model number	Base part	Cover part	Total	Model number	Base part	Cover part	Total		
RD-150-□	7.0	3.0	10.0	_	_	_	_		
RD-150-1-□	3.5	1.5	5.0	_	_	_	_		
RD-150-05-□	2.3	0.6	2.9	_	_	_	_		
RD-300-□	8.0	5.0	13.0	RDW-300-□	8.0	6.1	14.1		
RD-300-1-□	4.2	2.5	6.7	RDW-300-1-□	4.2	3.2	7.4		
RD-300-05-□	2.3	1.3	3.6	RDW-300-05-	2.3	2.0	4.3		
RD-300-03-□	1.5	0.7	2.2	RDW-300-03-	1.5	1.3	2.8		
RD-300H-□	13.3	5.0	18.3	RDW-300H-□	13.3	6.1	19.4		
RD-300H-1-□	6.8	2.5	9.3	RDW-300H-1-	6.8	3.2	10.0		
RD-300H-05-□	2.7	1.3	4.0	RDW-300H-05-	2.7	2.0	4.7		
RD-300H-03-□	2.3	0.7	3.0	RDW-300H-03-	2.3	1.2	3.5		
RD-450-□	8.5	7.6	16.1	RDW-450-□	8.5	9.1	17.6		
RD-450-1-□	4.6	3.5	8.1	RDW-450-1-□	4.6	4.8	9.4		
RD-450-05-□	2.6	1.8	4.4	RDW-450-05-	2.6	3.0	5.6		
RD-450-03-□	1.8	1.0	2.8	RDW-450-03-	1.8	1.8	3.6		
RD-450H-□	13.8	7.6	21.4	RDW-450H-□	13.8	9.1	22.9		
RD-450H-1-□	7.2	3.5	10.7	RDW-450H-1-□	7.2	4.8	12.0		
RD-450H-05-□	3.0	1.8	4.8	RDW-450H-05-	3.0	3.0	6.0		
RD-450H-03-□	2.5	1.1	3.6	RDW-450H-03-	2.5	1.9	4.4		
RD-600-□	9.0	10.5	19.5	RDW-600-□	9.0	13.5	22.5		
RD-600-1-□	4.8	5.6	10.4	RDW-600-1-	4.8	8.2	13.0		
RD-600-05-□	2.9	3.2	6.1	RDW-600-05-	2.9	5.3	8.2		
RD-600-03-□	2.0	2.2	4.2	RDW-600-03-	2.0	3.1	5.1		
RD-600H-□	14.3	10.5	24.8	RDW-600H-□	14.3	13.5	27.8		
RD-600H-1-□	7.6	5.6	13.2	RDW-600H-1-□	7.6	8.2	15.8		
RD-600H-05-□	4.3	3.2	7.5	RDW-600H-05-	4.3	5.3	9.6		
RD-600H-03-□	2.8	2.2	5.0	RDW-600H-03-	2.8	3.1	5.9		
RD-900-□	9.6	18.2	27.8	RDW-900-□	9.6	21.3	30.9		
RD-900-1-□	5.3	9.2	14.5	RDW-900-1-	5.3	13.5	18.8		
RD-900-05-□	3.6	5.7	9.3	RDW-900-05-	3.6	8.1	11.7		
RD-900-03-□	2.6	5.3	7.9	RDW-900-03-	2.6	5.3	7.9		
RD-900H-□	14.9	18.2	33.1	RDW-900H-□	14.9	21.3	36.2		
RD-900H-1-□	7.9	9.2	17.1	RDW-900H-1-	7.9	13.5	21.4		
RD-900H-05-□	4.9	5.7	10.6	RDW-900H-05-	4.9	8.1	13.0		
RD-900H-03-□	3.6	5.3	8.9	RDW-900H-03-□	3.6	5.3	8.9		

#### \* The product weight is almost the same for both the highly corrosion-resistant steel sheet type and the stainless type.

# **Parts**

### <Table 1.3.2-1> Weight of parts (fittings)

Standard product								
Model number	Weight	Model number	Weight					
RE-150-□	1.9	RCO-450-□	8.0					
RE-300-□	6.5	RCO-450H-□	12.2					
RE-300H-□	9.0	RCO-600-□	10.2					
RE-450-□	9.2	RCO-600H-□	15.8					
RE-450H-□	11.4	RCO-900-□	20.7					
RE-600-□	12.8	RCO-900H-□	25.2					
RE-600H-□	16.0	RCF-300-□	5.6					
RF-300-□	5.7	RCF-300H-□	6.7					
RF-300H-□	7.2	RCF-450-□	6.1					
RF-450-□	7.7	RCF-450H-□	7.5					
RF-450H-□	9.7	RCF-600-□	9.2					
RF-600-□	9.9	RCF-600H-□	13.5					
RF-600H-□	12.3	RCF-900-□	14.8					
RFS-300	2.5	RCF-900H-□	17.8					
RFS-300H	3.1	RT-150-□	2.3					
RFS-450	4.0	RT-300-□	8.2					
RFS-450H	4.7	RT-300H-□	10.0					
RFS-600	5.8	RT-450-□	12.0					
RFS-600H	6.6	RT-450H-□	14.0					
RFS-900	8.8	RT-600-□	18.7					
RFS-900H	9.9	RT-600H-□	21.6					
RCI-300-□	5.3	RXN-300-□	7.1					
RCI-300H-□	7.7	RXN-300H-□	9.0					
RCI-450-□	6.9	RXN-450-□	10.2					
RCI-450H-□	10.3	RXN-450H-□	12.1					
RCI-600-□	8.8	RXN-600-□	13.6					
RCI-600H-□	13.3	RXN-600H-□	15.5					
RCI-900-□	21.4	RX-900-□	28.1					
RCI-900H-□	26.2	RX-900H-□	31.2					
RCI-900H-□ RCO-300-□	26.2 5.9	RX-900H-□ REW-300-□	7.0					

<sup>※</sup> The product weight is almost the same for both the highly corrosion-resistant steel sheet type and the stainless type.
※ In the box □, a type such as A, B, C is indicated.

# Mounting bracket

<	Table 1.3.3-1> <b>Weigh</b> t	t of parts (ı	mounting bracket)			(unit : kg)
	Model number	Weight	Model number	Weight	Model number	Weight
	RZM-300-S-□	0.6	RZM-300-MS-□	0.7	RZM-300-MM-□	0.8
	RZM-450-S-□	0.8	RZM-450-MS-□	0.9	RZM-450-MM-□	1.0
	RZM-600-S-□	0.9	RZM-600-MS-□	1.0	RZM-600-MM-□	1.1
	RZM-900-S-□	1.9	RZM-900-MS-□	2.1	RZM-900-MM-□	2.2

Model number	Weight	Model number	Weight	Model number	Weight
RZM-300-M-□	1.0	RZM-300-L-□	1.3	RZB-S-□	0.4
RZM-450-M-□	1.1	RZM-450-L-□	1.4	RZB-M-□	0.7
RZM-600-M-□	1.3	RZM-600-L-□	1.6	RZB-ML-□	1.0
RZM-900-M-□	2.5	RZM-900-L-□	3.0	RZB-L-□	1.6

<sup>\*</sup> The product weight is almost the same for both the highly corrosion-resistant steel sheet type and the stainless type.

※ In the box □, a type such as A, B, C is indicated.

 $<sup>\</sup>divideontimes$  In the box  $\square$ , a type such as A, B, C is indicated.

• 1.4.1 Allowable load of base (duct base + strut)

• 1.4.2 Strength of cover (allowable load)

• 1.4.3 Load capacity (allowable load) of mounting bracket

# 1.5 Accommodation capacity

• 1.5.1 When using BHC the BIGTIE holder (for channel)

( Design )

Design

Load capacity and strength

This section explains about the load capacity of products.

In the design for special environments such as with snow accumulation, take them into consideration.

Reference [5.3] View of snow accumulation

Allowable load of base (duct base + strut)

Allowable load (allowable pipe weight) of base part for 1m- and 2m- RD ducts.

\ Item	Allowable load	l for 2-m RD duct
1.6	2-m RD duct (pipe support by 3 strut)	1-m RD duct ×2 (pipe support by 4 strut)
Duct size	Duct: RD  Mounting bracket: RZ (RZB+RZM)  1980	Duct: RD  Mounting tracket: RZ  RZB+RZM  980  980
RD-150	9,387N (958kgf)	12,548N(1,280kgf)
RD-300	3,929N (401kgf)	5,281N( 539kgf)
RD-450	2,546N(260kgf)	3,448N( 352kgf)
RD-600	1,837N(187kgf)	2,513N( 256kgf)
RD-900	1,102N(112kgf)	1,552N( 158kgf)
RD-300H	3,877N (396kgf)	5,228N( 533kgf)
RD-450H	2,494N(255kgf)	3,396N( 347kgf)
RD-600H	1,785N(182kgf)	2,461N( 251kgf)
RD-900H	2,231N(228kgf)	3,076N( 314kgf)

\* The allowable load is the same for both the steel sheet type and the stainless type.


It is substantially the allowable load of the strut (in the assembled state)

# Strength of cover (allowable load)

This is the strength of cover (allowable load for cover being restored to the original state) when the cover is attached to the base (duct base + strut).

Note that values for the W600 to 900H sizes and the walkway type are those in the state where the cover reinforcing plate is attached.

VI IBUIC 1.4	1/						
		Strength of cover					
Specifications		for 1m²	When load is applied by the load plate (200mm × 100mm)				
Standard type	Steel sheet	4.00011/-2 (5001-1/-2)	0011(401-1)				
	Stainless type	4,903N/m <sup>2</sup> (500kgf/m <sup>2</sup> ) or less	98N(10kgf) or less				
Walkway type	Steel sheet type	49,030N/m² (5,000kgf/m²) or less	980N(100kgf) or less				




( Design )

# Load capacity (allowable load) of mounting bracket

When four fixing bolts are used and the bolt tightening torque is 19.6N-m (200 kg-cm), <a href="Figure 1.4.3-1">(Figure 1.4.3-1</a> the load by which the mounting bracket will begin to shift is 6,374N (650 kgf). <Figure 1.4.3-1>

Bolt tightening torque	Load by which shift will begin (4 fixing bolts)
19.6N·m(200kg·cm)	6,374N(650kgf)



# **Accommodation capacity**

#### Table of contents

1.5.1	When using BHC the BIGTIE holder (for channel)	7
1.5.2	Table of rough indication of accommodatable quantity of	
	pipelines in a case where the piping is not fixed	
	(thickness of insulation = Liquid pipe:10mm, Gas pipe:10mm)	8
1.5.3	Table of rough indication of accommodatable quantity of	
	pipelines in a case where the piping is not fixed	
	(thickness of insulation = Liquid pipe:10mm, Gas pipe 20mm)	9
1.5.4	Table of rough indication of accommodatable quantity of	
	pipelines in a case where the piping is not fixed	
	(for the triple piping system)	10

# Notes

The quantity of accommodated pipelines described in the document is only for reference and does not guarantee the accommodation capacity.


The quantity may differ depending on the installation condition.

Especially, the accommodatable quantity of pipelines in a case where the piping is not fixed differs depending on the installation condition.

Just to be safe, values in the table of rough indication of accommodatable quantity of pipelines shown below are calculated based on around 75% of the effective sectional area of duct in consideration of meandering of the annealed pipe (soft copper pipe).

Values in the table of rough indication of accommodatable number of pipelines are also set in consideration of bending of fittings. It is recommended, however, to determine the accommodated quantity of pipelines with a margin if there is a bending in the vertical direction.

# When using BHC the BIGTIE holder (for channel)



	Maximum bindable quantity for each duct type												
Model number	RD-150	RD-300	RD-300H	RD-450	RD-450H	RD-600	RD-600H	RD-900	RD-900H				
BHC-1	1	3	3(6)	5	5(10)	7	7(14)	10	10(20)				
BHC-2	1	3	3(6)	4	4(8)	6	6(12)	8	8(16)				
внс-з	1	2	2(4)	4	4(8)	5	5(10)	8	8(16)				

• Values within ( ) are those in a case where the RSK (duct partitioning bracket) is used. Note that for the large diameter pipe, there is a restriction in the inner dimension of duct, and the bindable quantity of BHC may differ from the actual quantity of bindable

It cannot be used in a condition where load is applied on the BIGTIE, i.e., in the vertical installation, horizontal installation on the wall surface, or hanging from the ceiling (hanging upside down).

• 1.5.2 Table of rough indication of accommodatable quantity of [ Design ] pipelines in a case where the piping is not fixed (thickness of insulation = Liquid pipe:10mm, Gas pipe:10mm)

1.5 Accommodation capacity

• 1.5.3 Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed (thickness of insulation = Liquid pipe:10mm, Gas pipe:20mm)

[ Design ]

Design

Table of rough indication of accommodatable quantity of pipelines 1.5.2 in a case where the piping is not fixed

\* The accommodation capacity is the same for the cases where the wall sleeve (RSP) is used, or the cut-off wall plate (RSB)

■ Thickness of insulation = Liquid pipe:10mm, Gas pipe:10mm (15 mm for pipe diameter 50.80 or more)

Pipe diameter		Size									
liquid pipe × gas pipe)	150	300	300H	450	450H	600	600H	900	900H		
6.35 × 9.52	5	10	27	17	45	25	60	38	92		
6.35 × 12.70	4	8	22	14	36	23	48	33	72		
$6.35 \times 15.88$	4	8	22	13	32	21	43	26	64		
$9.52 \times 12.70$	4	8	22	13	33	21	44	31	67		
9.52 × 15.88	4	8	22	12	30	19	40	25	60		
9.52 × 19.05	4	8	21	11	27	17	37	24	54		
9.52 × 22.22	3	7	16	10	25	15	34	20	50		
9.52 × 25.40	2	6	13	10	21	14	29	20	42		
9.52 × 28.58	2	5	11	10	21	13	28	20	42		
12.70 × 15.88	3	7	16	11	27	16	36	24	54		
12.70 × 19.05	3	7	16	10	23	14	32	23	46		
12.70 × 22.22	3	6	13	10	22	14	31	19	44		
12.70 × 25.40	2	5	11	9	20	13	28	19	40		
12.70 × 28.58	2	5	11	9	19	13	27	18	38		
12.70 × 31.75	2	4	10	7	17	11	23	15	34		
12.70 × 34.92	2	4	9	6	16	10	21	13	32		
12.70 × 38.10	1	3	9	5	16	10	21	11	32		
15.88 × 19.05	3	6	13	9	21	13	30	22	44		
15.88 × 22.22	3	5	11	8	20	13	28	18	42		
15.88 × 25.40	2	5	11	8	19	12	25	18	38		
15.88 × 28.58	2	5	11	7	18	12	24	16	36		
15.88 × 31.75	2	4	10	7	17	10	22	14	32		
15.88 × 34.92	1	3	9	5	15	9	20	12	30		
15.88 × 38.10	1	3	9	5	15	9	20	11	30		
15.88 × 41.28	1	3	7	5	13	7	17	10	26		
19.05 × 25.40	2	5	11	7	17	11	23	17	35		
				7		11					
19.05 × 28.58	2	5	11		16		22	15	33		
19.05 × 31.75		4	10	6	15	10	20	14	30		
19.05 × 34.92	1	3	9	5	14	9	19	11	28		
19.05 × 38.10	1	3	9 7	5	14	8	19	10	28		
19.05 × 41.28	1	3		5	12	7	16	9	25		
19.05 × 44.45	1	3	7	4	12	7	16	9	24		
19.05 × 50.80	1	2	4	3	8	4	10	6	16		
19.05 × 53.98	1	2	4	3	7	4	10	6	14		
22.22 × 31.75	2	3	10	5	14	9	20	13	29		
22.22 × 34.92	1	3	9	5	13	8	18	10	27		
22.22 × 38.10	1	3	7	5	12	8	18	10	24		
22.22 × 41.28	1	3	7	5	12	6	15	8	24		
22.22 × 44.45	1	3	7	4	11	6	15	8	22		
22.22 × 50.80	1	2	4	3	8	4	10	6	16		
22.22 × 53.98	1	2	4	3	7	4	9	6	14		
25.40 × 38.10	1	3	7	5	11	7	16	9	23		
25.40 × 41.28	1	2	5	4	11	5	14	8	22		
25.40 × 44.45	1	2	5	4	11	5	14	7	21		
25.40 × 50.80	1	2	4	3	7	4	10	6	14		
25.40 × 53.98	1	2	4	3	7	4	9	6	14		
28.58 × 44.45	1	2	5	3	10	5	14	7	20		
28.58 × 50.80	1	2	4	3	7	4	10	6	14		
28.58 × 53.98	1	2	4	3	7	4	9	6	14		
31.75 × 50.80	1	2	4	3	6	3	9	6	12		
31.75 × 53.98	1	2	4	3	6	3	9	6	12		

Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed

\* The accommodation capacity is the same for the cases where the wall sleeve (RSP) is used, or the cut-off wall plate (RSB)

■ Thickness of insulation = Liquid pipe:10mm, Gas pipe:20mm

Pipe diameter					Size				
(liquid pipe $\times$ gas pipe)	150	300	300H	450	450H	600	600H	900	900H
$6.35 \times 9.52$	3	6	12	9	21	12	28	19	43
6.35 × 12.70	2	6	12	9	20	11	27	19	40
6.35 × 15.88	2	5	10	9	18	10	25	18	38
9.52 × 12.70	2	5	10	9	19	10	25	18	38
9.52 × 15.88	2	5	10	8	18	10	24	17	36
9.52 × 19.05	2	4	8	7	16	9	21	15	32
9.52 × 22.22	2	4	8	7	15	9	20	14	30
9.52 × 25.40	2	4	8	6	14	8	18	13	28
9.52 × 28.58	1	3	6	6	13	8	17	12	26
12.70 × 15.88	2	5	10	7	17	9	23	15	34
12.70 × 19.05	2	4	8	7	15	9	19	15	30
12.70 × 22.22	2	4	8	7	15	9	18	14	30
12.70 × 25.40	1	3	6	6	13	8	16	13	26
12.70 × 28.58	1	3	6	6	12	7	16	12	24
12.70 × 20.36	1	3	6	4	11	7	15	9	22
12.70 × 31.75	1	2	4	4	11	6		8	22
12.70 × 34.92 12.70 × 38.10	1	2	4	3	10	5	15	6	20
				7			13		
15.88 × 19.05	2	4	8		13	9	18	14	27
15.88 × 22.22	1	4	8	6	13	8	17	13	26
15.88 × 25.40	1	3	6	6	12	8	15	12	24
15.88 × 28.58	1	3	6	5	11	7	15	11	23
15.88 × 31.75	1	2	4	4	10	6	14	8	21
15.88 × 34.92	1	2	4	3	10	5	14	7	21
15.88 × 38.10	1	2	4	3	9	5	12	6	19
15.88 × 41.28	1	2	4	3	8	5	11	6	17
19.05 × 25.40	1	3	6	6	11	7	15	11	23
19.05 × 28.58	1	3	6	5	11	7	15	11	22
19.05 × 31.75	1	2	4	4	10	6	14	8	20
19.05 × 34.92	1	2	4	3	10	5	14	7	20
19.05 × 38.10	1	2	4	3	9	5	12	6	18
19.05 × 41.28	1	2	4	3	8	4	10	6	16
19.05 × 44.45	1	2	4	3	8	4	10	6	16
19.05 × 50.80	1	2	4	3	7	4	9	6	15
19.05 × 53.98	1	2	4	3	6	3	8	6	14
22.22 × 31.75	1	2	4	3	10	5	13	7	20
22.22 × 34.92	1	2	4	3	10	5	13	7	20
22.22 × 38.10	1	2	4	3	9	4	12	6	18
22.22 × 41.28	1	2	4	3	8	4	10	6	16
22.22 × 44.45	1	2	4	3	7	4	9	6	15
22.22 × 50.80	1	2	4	3	7	4	9	6	14
22.22 × 53.98	1	2	4	3	6	3	8	6	13
25.40 × 38.10	1	2	4	3	8	4	11	6	16
25.40 × 41.28	1	2	4	3	7	4	10	6	15
25.40 × 44.45	1	2	4	3	7	4	9	6	15
25.40 × 50.80	1	2	4	3	7	4	9	6	14
25.40 × 53.98	1	2	4	3	6	3	8	6	12
28.58 × 44.45	1	2	4	3	7	4	9	6	14
28.58 × 50.80	1	2	4	3	6	3	8	6	12
28.58 × 53.98	1	2	4	2	6	3	8	4	12
31.75 × 50.80	1	2	4	2	6	3	8	4	12
31.75 × 53.98	1	1	3	2	6	3	7	4	12

\* For a size not in the table, see the item for the one size larger pipe.

\* For a size not in the table, see the item for the one size larger pipe.

• 1.5.4 Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed (for the triple piping system)

[ Design ]

Table of rough indication of accommodatable quantity of pipelines in a case where the piping is not fixed

\*\* The accommodation capacity is the same for the cases where the wall sleeve (RSP) is used, or the water shut-off sleeve

■ Table for RD duct size selection for the triple piping system

● Thickness of insulation = 10mm × 10mm × 10mm

Dina diameter					Size				
Pipe diameter	150	300	300H	450	450H	600	600H	900	900H
9.52×15.88×19.05	2	4	10	6	17	10	23	13	34
9.52×19.05×22.22	2	4	9	6	13	9	19	13	27
12.70×19.05×22.22	1	3	8	6	12	8	17	12	25
12.70×19.05×25.40	1	3	8	5	12	7	16	11	24
12.70×22.22×25.40	1	3	7	5	11	7	16	11	23
12.70×22.22×28.58	1	2	7	4	11	6	15	10	23
12.70×25.40×28.58	1	2	6	4	11	5	15	9	22
15.88×22.22×28.58	1	2	6	4	11	5	15	9	22
15.88×25.40×28.58	1	2	6	4	10	5	14	9	21
15.88×25.40×31.75	1	2	6	3	9	5	13	8	20
15.88×28.58×31.75	1	2	6	3	9	5	13	8	20
15.88×28.58×38.10	1	1	4	3	8	4	11	6	17
19.05×22.22×28.58	1	2	6	3	10	5	14	8	21
19.05×25.40×31.75	1	2	6	3	10	5	13	8	20
19.05×28.58×31.75	1	2	5	3	9	5	13	8	19
19.05×28.58×38.10	1	1	4	3	8	4	11	6	16
19.05×31.75×38.10	1	1	4	3	7	4	10	6	15
22.22×28.58×38.10	1	1	4	2	7	3	10	5	15

\* For a size not in the table, see the item for the one size larger pipe.

#### ● Thickness of insulation = 10mm × 20mm × 20mm

Dina diameter	Size								
Pipe diameter	150	300	300H	450	450H	600	600H	900	900H
9.52×15.88×19.05	1	1	5	3	7	4	11	7	15
9.52×19.05×22.22	1	1	5	3	7	3	10	6	14
12.70×19.05×22.22	1	1	4	3	7	3	10	6	14
12.70×19.05×25.40	1	1	4	2	7	3	9	5	14
12.70×22.22×25.40	1	1	4	2	7	3	9	5	14
12.70×22.22×28.58	1	1	4	2	7	3	9	5	14
12.70×25.40×28.58	_	1	4	2	6	3	8	5	13
15.88×22.22×28.58	_	1	4	2	6	3	8	5	13
15.88×25.40×28.58	_	1	3	2	6	3	8	5	12
15.88×25.40×31.75	_	1	3	2	5	3	7	5	11
15.88×28.58×31.75	_	1	3	2	5	3	7	4	11
15.88×28.58×38.10	_	1	3	2	5	3	6	4	10
19.05×22.22×28.58	_	1	3	2	5	3	7	4	12
19.05×25.40×31.75	_	1	3	2	5	3	7	4	11
19.05×28.58×31.75	_	1	3	2	5	3	7	4	11
19.05×28.58×38.10	_	1	3	2	5	3	6	4	10
19.05×31.75×38.10	_	1	3	2	5	3	6	4	10
22.22×28.58×38.10	_	1	3	1	5	2	6	4	10

\* For a size not in the table, see the item for the one size larger pipe.

# Design

2 Total design

Basic design flow ..... P12 to P13 Installation method Installation method (on the wall surface) · · · · · · P15 to P17 Installation method (hanging from the ceiling) · · · · · P18

# Basic design flow

#### 1 Selecting duct size

Select the duct size for the Pipe shaft part and equipment layout part based on the size and quantity of pipes. <Figure 2.1-1>

Reference [1.5] Accommodation capacity

Example 15.88×25.4 (thickness of insulation: 10mm) Pipe shaft part = 12 pipelines → RD-600 size


A block = 8 pipelines → RD-450 size B block = 4 pipelines → RD-300 size


#### 2 Designing piping route and checking pipe size

Design the Pipe shaft and equipment lavout. pipe size, and walkway for maintenance, and check the piping route, pipe size, and quantity

Also at the same time, check the connection positions of piping for equipment.

<Figure 2.1-2>





<Figure 2.1-3> Example case: 0.5 pieces/m

Mounting bracketRZ (RZB+RZM)

(installation by 2 m pitch)

## 3 Checking load for 1 m and setting quantity of mounting brackets to be set

① Check the load for 1 meter for each piping route (block) based on the weight of pipe, product, and environment weight (e.g., snow accumulation).

② Set the quantity of mounting brackets to be set for 1 m.

\* The quantity of mounting brackets will differ depending on the part or position.

Reference [1.3] Product weight

[1.4] Load capacity and strength

[3.4] Mounting bracket

Example Pine weight:

14.04 kg (for one pipeline : 0.45 + 0.72 = 1.17 kg) × 12 pipelines 15.8 kg (RDW-600-C-1-ZA) Product weight

Weight of accumulated snow:

252 kg (area of duct: 0.6m2, weight of snow: 200 kg/m3, height of snow: 2 m [meter addition: 0.1]) 281.84kg

Load capacity of mounting bracket: 650 kg/piece → Quantity of mounting brackets to be set

= 0.5 pieces/m → Basic pitch for setting mounting brackets = 2m

% The weight of snow and added value (in calculation) differ depending on the region.


Reference [5.3] View of snow accumulation


#### 4 Setting Pipe shaft and height of mounting bracket

Check the method of penetrating part in the Pipe shaft part, and set the height of mounting bracket based on the height of Pipe shaft, equipment, and obstacles. <Figure 2.1-4.1/4.2>

- X Set the height within the mounting bracket settable range.
- \* As to the level difference, set it within the height adjustable with vertical ell or sliding coupler.

Reference [3.2] Pipe shaft and wall penetration, [3.4] Mounting bracket





# 5 Locating parts

Locate the ducts, fittings, couplers, and end caps etc.


2.1 Basic design flow

Connection parts include the sliding coupler for adjusting length and the reducer for connecting different size ducts.

<Figure 2.1-5>

- \* We have prepared the template file for CAD in our Website. Please use it.
- Note that the overlap width for connection will differ depending on the parts or connection

Reference [3.3] Connection method




#### 6 Locating mounting bracket

Check the types of fittings and connection methods in each part, and design the positions to set the mounting brackets.

<Figure 2.1-6>

 Required quantity of mounting brackets differs depending on the types of fittings and connection methods.


Reference [3.4] Mounting bracket (3.5) Fittings



#### 7 Connecting to equipment

Design the route end of piping (branch piping) connecting to the equipment and position of support in consideration of obstacles around the equipment.

<Figure 2.1-7>



2.2.1 Installation by using mounting bracket

• 2.2.2 Installation by using H-steel/channel steel

• 2.2.3 Installation by using channel

# Installation method (on the wall surface)

• 2.3.1 Types of installation on the wall surface (vertical)

• 2.3.2 Propriety of wall surface

# Installation method (on the floor)


# Installation by using mounting bracket <Figure 2.2.1-1>

There are the following installation patterns.

- Single-stage mounting
- Duplex mounting (in two stages separately) \*150 is excluded

Note that in the duplex mounting, three-dimensional arrangement or bending is of much difficulty. A box joint cannot be used for the size of 900 (H).


Reference For details about mounting bracket, see "[3.4] Mounting bracket".



#### Installation by using H-steel/channel steel <Figure 2.2.2-1> 2.2.2

There is a method of setting H-steel or channel steel, and setting RD duct on it. To connect and secure the duct to H-steel/channel steel, use bolts or RD fixing brackets for shaped steel. Positions where bolts are fixed are to be the same as the positions where the mounting brackets are to be fixed.

Reference For details of using the RD fixing bracket for shaped steel, see [3.4.16] RKT RD fixing bracket for shaped steel and [3.4.17] RKTW RD walkway fixing bracket for shaped steel.




#### Installation by using channel 2.2.3

<Figure 2.2.3-1>

There is a way to install RD duct in the channel. Install the channel stop fitting and tighten it with screws.

Reference This method cannot be used for the walkway type. For details about the fixing bracket for fixing RD to shaped steel, see "[3.4.18] RCT bracket for



# Installation method (on the wall surface)

#### Table of contents

Warnii	ng	15
2.3.1	Types of installation on the wall surface (vertical)	15
2.3.2	Propriety of wall surface	15
2.3.3	Conditions for installation on the wall surface (directly on the wall surface)	16
234	Conditions for installation on the wall surface (suspended from the wall surface)	17

# Warning

Although SLIMDUCT RD can be installed on the wall surface, there are some restrictions

For installation on the wall surface, a treatment to prevent loosening of bolts is required.


- For attaching the cover, use "Bolt and washer set for cover on wall surface RD-HB".
  - Set contents

M6 hex × 20L SUS

M6 spring washer SUS

M6 flat washer SUS


- \* The cover bolt supplied with the product cannot be used.
- For installation on the wall surface (suspended from the wall surface), the following treatment is required. • Be sure to attach the bottom plate. Otherwise, wind pressure is applied
- from inside the duct, causing a damage to the duct. • For fixing the duct to the mounting bracket, use a commercially
- available "Stainless W3/8 spring washer". (RZW-150 is excluded) \* Use it in addition to the bolt set supplied with the product for fixing.



# Types of installation on the wall surface (vertical)

There are two methods of installing SLIMDUCT RD on the wall surface: "Installation directly on the wall surface" and "Installation suspended from the wall surface".

<Figure 2.3.1-1,2>



# Feasibility of installation on wall face for each product size

< Table 2.3.2-1 > shows feasibility of installation on wall face for each type of SLIMDUCT RD.

Do not use the installation method marked with "X" as the product may fall off or damage with strong winds in a worst case scenario.

\*When installing the corner parts when directly mounting t the wall, please refer to the installation section and faste the stand to the wall using all the holes required for mountin the stand

Ciac Inst	<	able	2.,	3.2-	1 >
		Size		- 1	nst

	Size	on the wall face	from the wall surface
th	150	Ō	Ö
	300	Ō	Ö
th	300H	Ō	Ö
	450	0	0
	450H	0	0
to	600	Ō	0
en	600H	0	×
ng	900	Δ	×
	900H	(not applicable to corner parts)	X

# Conditions for installation on the wall surface (directly on the wall surface)

When installing SLIMDUCT RD on the wall surface (directly on the wall), observe the following conditions:

■ Use the method using couplers\* for fixing.

\* For the upper and lower ends, the free coupler or reducer cannot be used. [3.5.8] 90° vertical ell

2 The cover reinforcing plate cannot be used due to the risk of dropping off. Remove the cover reinforcing plate standardly supplied with 600, 600H, 900, and 900H sizes and some

(The cover reinforcing plate is used for preventing deflection of cover in the installation on a plane surface, and not required in the installation on the wall surface.)

## 3 Fixing method

Fix with "Stainless W3/8 or M10 anchor" by using the parts dedicated for installation on the wall surface. Note that the installable position differs depending on the product.


#### 1. General type ducts and fittings

Set the anchor on the strut by using RBK-B auxiliary bracket for strut. < Figure 2.3.3-1>

%For 2m-type and 1m-type ducts other than 150, installation by using the bracket for duct base is also possible in the same way as the Open type duct.

Set the anchors in 4 or more positions in consideration of balance. < Figure 2.3.3-2>

For the 90° flat ell and RE-300 to 600H, supporting in 5 or more positions including the outer R side of the auxiliary strut (6) is recommended.




#### 2. Open type duct

RD-450H/RD-450H-1/RD-600H/RD-600H-1/RD-900 H/RD-900H-1 is included


Set the anchor on the duct base by using RBK-A auxiliary bracket for duct base. <Figure 2.3.3-4>


Set the anchors in designated 4 positions or more. <Figure 2.3.3-5/6>

If the piping load is applied on the strut, it is recommended to add the anchor also on the strut in the same way as the general type.



Use the W3/8 or M10 anchor (female), and fix it by using RBK-A auxiliary bracket for duct base or RBK-B auxiliary bracket for strut.





# Conditions for installation on the wall surface (suspended from the wall surface)

When installing SLIMDUCT RD on the wall surface (suspended from the wall surface), observe the following conditions:

# ■ Use the method using couplers\* for fixing.

\*\* Free coupler or fixing coupler to which the bottom plate is not attachable (some types of reducer) cannot be used. Reference \* For the upper and lower ends, the free coupler or reducer cannot be used.

The cover reinforcing plate cannot be used due to the risk of dropping off.

Remove the cover reinforcing plate standardly supplied with 600 size and some fittings.

(The cover reinforcing plate is used for preventing deflection of cover in the installation on a plane surface, and not required in the installation on the wall surface.)

# 3 Fixing method

Fix the RD mounting bracket on the wall surface, and attach the SLIMDUCT RD to it.

Use "RZW-150" for 150 size, and use "RZM-S + RZB-S" for other sizes. Fix the RD mounting bracket with "Stainless W3/8 or M10 anchor".

[3.4] Mounting bracket

Note that the mounting bracket settable position differs depending on the product.

Avoid setting the mounting bracket at the connection part due to the risk of drop.

## 1. General type ducts and fittings


Fix the mounting bracket to the strut by using the bolt set supplied with the mounting bracket as well as the commercially available spring washer.

<Figure 2.3.4-1> \* RZW-150 is excluded

\*2m-type and 1m-type ducts other than 150, installation by using RBK-A auxiliary bracket for duct base is also possible in the same way as the Open type duct.

Set the anchors in 2 or more positions in consideration of balance. <Figure 2.3.4-2>

For the quantity of mounting brackets for the fittings see pages of each fittings. <Figure 2.3.4-3>



## 2. Open type duct

RD-450H/RD-450H-1 is included.


Fix the mounting bracket to the duct base by using RBK-A auxiliary bracket for duct base, and at the same time, also fix the bottom plate.


At this time, drilling is required on the bottom plate. <Figure 2.3.4-4>

Set the anchors in designated 2 positions or more.

<Figure 2.3.4-5/6>

If the piping load is applied on the strut, it is recommended to add the mounting bracket also on the strut in the same way as the general type.






# 4 Be sure to attach the bottom plate. (in advance) Reference [3.5.7] and [3.5.8] 90° vertical ell

\* When using RCO, it is recommended to attach the bottom plate also to the nearest plane part (50 cm or over).

> Spring Bottom plate

<Figure 2.3.4-7> General type Washer



Fix the Open type duct by using RBK-A auxiliary bracket for duct base, and fix the others by using a commercially available spring washer as shown in the figure. **%** RZW-150 is excluded

(commercial product)

Notes in design

Direction of cover : Ceiling


<Figure 2.4.1-2>

Direction of cover : Floor

Installation method (hanging from the ceiling)

The concrete way of installation on the ceiling face is to hang the duct with channels and fully-threaded

At this time, there are two installation methods: installation with the cover facing the ceiling and installation with the cover facing the floor.



# Notes on hanging from the ceiling

# Generally in the installation by hanging from the ceiling


- 1. Connection ··· The free coupler cannot be used.
- 2. Support ··· Support four or more positions for one duct or one fittings.

Positions to be supported are to be decided based on the positions of mounting brackets being set. (Example: If the quantity of the mounting brackets is 3, support 6 positions.) For the quantity of mounting brackets for the fittings, see pages of each part.

#### 2 Direction of cover : Ceiling <Figure 2.4.1-1>

1. Support ··· On at least two positions of struts for one duct or one fittings respectively, attach the support part such as a channel.

Although the point for determining the position to be attached to is the same as that for the mounting bracket on the floor face, an enough clearance is needed between the ceiling and the duct in consideration of attaching the pipe and cover.



- 1. Restriction on duct size ... 900 and 900H ducts are not usable for installation by hanging from the ceiling with "direction of cover: floor".
- 2. Bottom plate ... Use the bottom plate for preventing dust accumulation.

For the coupler-free connection method, the bottom plate for coupler (RDBJ)

If the coupler-free connection is used in the installation, the exclusive bottom


# 3. Pipe support ···

Support pipes by using the RD strut set (RDK) so that the pipe weight is not applied on the cover.

RD strut set is not needed for 150size, because the accommodation capacity of 150 size is small.

As long as it is of the general copper pipe covered with insulation material, it can be supported by the strength of cover.

<Figure 2.4.1-3>



4. Cover reinforcing plate ... The cover reinforcing plate cannot be used. For safety, remove the cover reinforcing plate which is standardly supplied with 600 size and some fittings.

Reference The cover reinforcing plate is used for preventing deflection of cover in the installation on a plane surface.

# Design of each part


Design

Pipe shaft and wall penetration · · · P22 to P28 Mounting bracket ..... P36 to P44 **Fittings** ..... P45 to P61 Bottom plate ..... P62 to P64 

3.1.7 Cutting duct

**Duct** 

# **Product configuration**



#### 3.1.2 Load capacity

For the load capacity, see [1.4] Load capacity and strength.

# Selecting duct

1 Select the duct size in consideration of the state of pipe takeout part (pipe shaft etc.), diameter and quantity of the pipes, piping space, space for equipment maintenance, and whether the mounted stage is single or duplex, etc.

Reference (1.4) Load capacity and strength

[1.5] Accommodation capacity


[2.1] Basic design flow

Take into consideration the position for installing the duct for walkway (such as RDW), etc. for preparation of maintenance.

2 There are two duct installation patterns as shown in the figure: standard (single stage) and duplex mounting (in two stages separately).

<Figure 3.1.3-2>

Note The duplex mounting (in two stages separately) is possible only when the mounting bracket guide for duplex mounting RZY (separately sold) is attached to RZB-M/ML/L.



# About installation on the wall surface and by hanging from the ceiling

For installation on the wall surface, see [2.3] Method of installation on the wall surface.

For installation by hanging from the ceiling, see [2.4] Method of installation by hanging from the ceiling.

# Position to set the mounting bracket (for installation on the floor) <Figure 3.1.5-1>

Set the mounting brackets in 2 or more positions in consideration of load. There are the following 3 positions to set the mounting bracket.

1 Setting on strut

This is used in the installation on the floor and installation on the wall surface.

\* For details about the installation on the wall surface, see [2.3] Method of installation on the wall surface.

2 Setting on connection part

(when the coupler-free connection installation method is used or the fixing coupler\* is used)

Only for installation on the floor (a plane surface). \*\*Only for RSJ, RSS, RFJ (A Size )

Reference [3.3] Connection method

3 Setting on duct base

Since the fixing strength in the mounting bracket setting on a duct base is weaker than that on a strut or connection part, there are some use restrictions depending on the installation method except for the installation on the floor. ※ For details, see [3.4.7] Position for setting.

<Figure 3.1.5-1> Duct base part

Generally used connection method. Connect duct bases of ducts

• For the installation on the wall surface, use the fixing coupler.

or some plane surface fittings each other without using separate

This is used when the vertical installation or coupler-free

This is used when the coupler-free connection or fixing couple

Note • It is not possible to connect with 150 type, some fittings, different size ducts, or end cut ducts.

connection cannot be applied.

cannot be used e.g. for the cut end of duct.

This is used for adjusting length or height

Note • There is no sliding coupler for 150 type.

This is used for connecting different size ducts or fittings.

[3.3] Connection method

# Notes on designing

Mounting bracket | Reference | [3.4] Mounting bracket

The width of mounting bracket is wider than that of duct.

When installing the duct, take into consideration the space for installation and maintenance works.

connection

Fixing coupler

<Table 3.1.6-1> Connection method

(Rough indication: 200 mm or more around)

2 Connection part

Reference [3.3] Connection method

Coupler-free · In the jointless connection method, the length is 20 mm shorter for each connection. On the other hand, the joint connection method requires a gap of 20 mm for RSJ and RFJ and 63 mm for RR (joint type) for overlap width for

Free coupler · For a short end, use a combination of the standard-size duct and a sliding Sliding coupler joint as long as possible. Joint types are shown in < Table 3.1.6-1>. Reducer

3 Clearance between RDs

If RDs are laid out in parallel, keep 200 mm or more clearance between ducts or between a duct and equipment.

4 Walkway type

The walkway type cannot be used for the installation on the wall surface and by hanging from the ceiling. Also, do not use the short duct end as the walkway.

5 Cover reinforcing plate

The cover reinforcing plate is standardly supplied with 600(H) and 900(H).

The cover reinforcing plate cannot be used for the installation on the wall surface and by hanging from the ceiling. Remove it.

# **Cutting duct**

Whenever possible, use the sliding coupler RSS and avoid cutting the duct. If cutting is necessary, make sure you have two or more sub girders after cutting. However, ducts with sizes of 0.5 m and 0.3 m can be used with just one sub girder, on the condition that one side is connected to RWP. Do not cut the open-type ducts if the number of sub girders reduces.

Reference (3.3.5) RSS sliding coupler

If you cut, perform a repair work using a zinc rich paint (Zn-Al).(\*Do not cut the corner parts)

Design

Design Product configuration specification and weight

Load capacity Ac

modation Basic des

n Installation method

Design

thod method method (on the wall surfa

# 3.2 Pipe shaft and wall penetration

# Table of contents

3.2.1	Installation example of Pipe shart and wall penetration (Installation outdoors on the floor)	22
3.2.2	Installation of RWP wall flange	23
3.2.3	Installation of RSP/RSPR wall sleeve	24
3.2.4	Installation of RSB cut-off wall plate	24
3.2.5	Installation of RSPC water shut-off plate protection cover ·····	25
	Installation of CB chamber box (removal from the front)	
3.2.7	Installation of CB chamber box (removal from the bottom)	27
	Installation of CB chamber box (self-making)	
3.2.9	Wall penetrating installation method (indoors)	28


# 3.2.1 Installation example of Pipe shaft and wall penetration (installation outdoors on the floor)


Water shut-off treatment is required for outdoor use.


There are the following penetration methods in which the water shut-off treatment is considered.


Note The explanation on the installation method below is just an example. Follow the instruction by the supervisor on site for details.


#### <Figure 3.2.1-1> Installation example (Pipe shaft)


















Table	3.2.1-1>	
< I able	0.2.1-1/	

			Required part (just for each example)						
Duct size	Installation example	Explained in	Wall flange RWP	45° vertical ell RCF	90° vertical ell RC/RCI	Wall sleeve RSP	cut-off wall plate RSB	Chamber box CB	
150	Α	P.72	0	0	_	_	_	_	
300′300H	В	P.73	0	0	_	O *1	-	_	
450、450H 600、600H	C	P.75	0	0	_	_	0	_	
900,900H	В	P.73	0	0	_	O *1	_	_	
	D	P.77	_	_	_	_	_	0	
300~900 300H~900H	<b>=</b>	P.80	_	-	_	_	-	0	
	E	P.81	_	_	0	_	_	0	
All sizes	G	_	0	_	_	_	_	(self-making) *2	

# 3.2.2 Installation of RWP wall flange

# Installation example A


# Product configuration



2 Perform the penetrated part treatment by using the wall flange (RWP) and the elevation surface fittings (RC, RCF).

Also shut off water by "puttying + caulking" or "mortar back-filling + caulking treatment" for the penetrated part.

<Figure 3.2.2-2>




Installation of RSP/RSPR wall sleeve


# Installation example **B**

Perform the water shut-off treatment by using the wall sleeve (RSP-A square caulking type), the wall flange (RWP), and the 45° vertical ell (RCF) in combination.


# Product configuration




### 2 Dimensions of opening



# 3 Position of pilot hole for attaching RSP and RWP




#### 4 Caulking treatment




#### Installation of RSB cut-off wall plate 3.2.4

Perform the water shut-off treatment by using the cut-off wall plate (RSB), Installation example C  $\perp$ the wall flange (RWP), and the 45 $^\circ$  vertical ell (RCF) in combination.


1 Product configuration The cut-off wall plate is used by being embedded in the body.




2 Dimensions for embedding the cut-off wall plate in the body



3 Position of M6×45L tapping bolt or anchor for M6 for attaching wall flange




#### 4 Caulking treatment




# Installation of RSPC water shut-off plate protection cover

#### Product configuration



To protect the caulking of the water shut-off plate from ultraviolet rays, install a water shut-off plate protection cover.

Fit the 45-degree bend (inside) of the cover top into the 45-degree bend of the frame top for temporary placement of the cover, and secure it with bolts.



Design


# Installation of CB chamber box (removal from the front)

# Installation example


The cover can be removed without cutting the caulking. The duct can be extracted from the front.

\*\*The chamber box (CB) is a product of special specifications with alteration of materials and dimensions, etc. (a separate meeting required for the price and delivery date).


#### Product configuration




#### 2 Dimensions of opening



#### 3 Position for fixing W3/8 anchor bolt for CB <Figure 3.2.6-3>



#### 4 Dimensions of level for removing RD duct




\*The opening dimensions and positions are examples only. Design it to prevent rainwater from entering through the opening.

# Installation of CB chamber box (removal from the bottom)

# Installation example **I** / Installation example **I**


The duct can be extracted from the bottom. Wall installation and suspended installation are available. <Figure 3,2,7-2~6> \*\*The chamber box (CB) is a product of special specifications with alteration of materials and dimensions, etc. (a separate meeting required for the price and delivery date).


#### Product configuration





\*\*The dimensions of the opening and the mounting position of the W3/8 anchor bolts for CB are the same as those of the installation

## 2 Dimensions of opening










#### Bottom exit (suspended)


Precautions when using RCI elevation corner 90 (riser)

bottom exit

(suspended)



connect to the RCI, use "CBB-900 (H)-RCI," which is RCI elevation corner 90°(riser) Install a mounting Mounting bracket bracket at the end of both RCI and RD duct.



600H

900H 860

560

# Installation of CB chamber box (self-making)

# Installation example Installation of CB chamber box (self-making)

In a case where no ready-made product suits the condition on site, you may yourself.


In self-making, conditions will differ depending on the respective environment, and we will show one example

As for the installation using a self-made chamber box, follow the direction by the supervisor on site.

<Figure 3.2.8-1~2>

1 Wall butt method


Note The chamber box and penetrating member are to



• 3.2.8 Installation of CB chamber box

• 3.2.9 Wall penetrating installation method (indoors)

(self-making)




# Wall penetrating installation method (indoors)

As the wall penetrating installation method indoors, there are "wall butt method" and "wall penetrating installation method".

For both methods, a combination of straight duct (SLIMDUCT RD) and decorative plate (RWP wall flange) is used in installation. However, "wall butt method" is easier in maintenance. \* For RWP, see [3.2.2] Installation of RWP wall flange.

# 2 Wall penetrating installation method



# **Connection method**

The connection method is largely classified into the following concrete methods: coupler-free connection which uses no member for connection, connection by using some members for connection, and connection by using the special parts for 900/900H.

Table of contents

-1 1		
3.3.1	Table for selecting connection method	29
3.3.2	Coupler-free connection · · · · · · · · · · · · · · · · · · ·	30
3.3.3	RSJ fixing coupler ·····	30
3.3.4	RFJ free coupler ·····	30
3.3.5	RSS sliding coupler	32
3.3.6	RR reducer ····	33
3.3.7	Connection for 900/900H corner parts	33
3.3.8	Connection for 900/900H joint (1) RXR	33
3.3.9	Connection for 900/900H joint (2) RXJ	34
3.3.10	RXSS/RXSSW box joint sliding coupler ·····	34
3.3.11	RCSS sliding coupler for RCF-900 (H)-SUS	35

# Table for selecting connection method

There are several connection methods as shown below. Use an appropriate method to suit the purpose.

∠Eiguro 3 3 1.1 >

	Method	Explanation	Overlap width for connection
	er-free connection eference [3.3.2]	Generally used connection method. Connect duct bases of ducts some corners each other without using separate members for connection.  Note  This method cannot be used for the installation on the wall surface, or for connection with 150 size, some fittings for 900 (H) size, different size ducts, or end cut ducts.	Margin for insertion -20mm
	Fixing coupler	This is used when the vertical installation or coupler-free coection cannot be applied.	Overlap width for connection 20mm
	Free coupler	This is used when the coupler-free connection or fixing coupleannot be used e.g. for the cut end of duct.  Note  This can be used only in the installation on a plane surface and installation directly on the wall surface. This cannot be used for connection with the elevation surface fittings in the installation on the wall surface.	Overlap width for connection 20mm
	Sliding coupler	Fixing coupler for adjusting length.  Note  There is no sliding coupler for 150 size. This cannot be used for connection with the elevation surface fittings in the installation on the wall surface.	
Coupler Reference [3.3.3] to [3.3.8]	Reducer (including RXR)	When connecting with the elevation surface fittings, this can be used only for the plane part. The coupler type cannot be used for the installation suspended from the wall surface or installation by hanging from the ceiling.  Coupler type  Plate type  900 (H) RXR	Coupler type Overlap width for connectio 63mm  Plate type Margin for insertion -20mm  900 (H) RXR Margin for insertion -20mm
Connection for 900/900H parts*1 Reference	for 900(H) size corner parts	This is used for connecting one corner part to another fitting of 900/900H size.	RXJ: Overlap width for connectic 10mm (6 mm to connect RCI to RCC

• 3.3.2 Coupler-free connection

[ Design ]

• 3.3.3 RSJ fixing coupler

• 3.3.4 RFJ free coupler

3.3 Connection method

• 3.3.4 RFJ free coupler

Cutting length of S/H type cover and bottom plate

(rough indication)

RD duct bottom plate

RD duct (cover)

RD duct (base)

<Figure 3.3.4-2>

[ Design ]

Design


**Coupler-free connection** 3.3.2

This is the generally used connection method for connection of ducts or fittings. Connection is possible without using separate members for connection.

However for a installational reason, the "Coupler-free connection method" cannot be used for the installation on the wall surface, or for connection with RD-150 series, different size ducts each other, or end cut ducts. For details, see [3.3.1] Table for selecting connection method.

1 Overlap width for connection in the coupler-free connection <Figure 3.3.2-1>


In the coupler-free connection, the effective dimension will become shorter, because the connection is made by overlapping the end of a duct and the end of the other one by 20mm.



# **RSJ** fixing coupler

The fixing coupler can be used for the installation on a plane surface, installation on the wall surface, and installation by hanging from the ceiling. When the fixing coupler is used, 20mm clearance between parts is needed.

It is also possible to set the mounting bracket at the connection part by using the supplied mounting bracket fixing plate. (for installation on the floor only)




#### RFJ free coupler 3.3.4

There are two types of free coupler: A type in which the cover coupler etc. are included, and S/H simplified type. They are used for connecting a cut duct. They can be used for the installation on the floor and installation directly on the wall surface. However note that they cannot be used for connection with the vertical ell in the installation on the wall surface. When the free coupler is used, 20 mm clearance between parts is needed.

For the A type, it is also possible to set the mounting bracket at the connection part by using the supplied mounting bracket fixing plate.

S/H type provides clean finishing when jointless connection is used as it does not use a lid bracket and the free joint is not clearly visible.

For details, see [3.4.7] Position for setting the mounting bracket. Note \*\* RD duct 0.5m/0.3m, and fittings cannot be cut.



# Notes on using the free coupler

## 1. Cutting duct base

Ducts can be used by cutting within the range where at least two struts remain. However for the open type, cutting resulting in reduction of struts is not possible.

### 2. Cutting cover

#### (1) S/H type

<Figure 3.3.4-2>

The cover is not to be cut when the length of cut duct base is 40mm or less.

If the length of cut duct base exceeds 40mm, the cover is to be cut so that its length becomes longer than the duct base by 40mm.

\* If there is no problem in fixing bolts or attaching the reinforcing plate, cutting may be omitted.

#### (2) A type

Cut it so that it becomes of the same length as the duct base.

#### (3) Cover bolt

If holes for cover bolts do not remain, perform drilling at the required positions.

#### 3. Bottom plate

## (1) S/H type

Cut it so that it protrudes from the duct base by 40mm.

#### (2) A type

Cutting is not needed when the mounting bracket is set at the connection part.

When the mounting bracket is not set, cut the bottom plate for duct so that it becomes shorter than the duct by 20 mm, and use the bottom plate for coupler RDBJ.

#### 4. Repair work (Steel sheet type)

For the part where you performed cutting or processing work, perform the repair work by using the zinc rich paint (Zn-AI).

## 5. Notes on attachment

#### (1) S/H type

In the vertical installation, attach it so that the cover of the upper part comes in the upper position. In connection to the vertical ell, connect the uncut side.

For lowering the position (RCF), attach it so that the cut side comes to the lower position, and perform drilling so that the mounting bracket can be set to the vertical ell.

#### (2) A type

In connection to the vertical ell, connect the uncut side.

For lowering the position, attach it so that the cut side comes to the upper position, and set the mounting bracket also at the connection part.

#### (3) Setting mounting bracket

For A type, the mounting bracket can be set at the connection part by using the mounting bracket fixing plate.

Note that for 150 size, the mounting bracket can be set only in the connection of a duct with


For S/H type, the mounting bracket cannot be set at the connection part. Set the mounting bracket near the connection part (at a near strut etc.).

Design


# **RSS** sliding coupler


This is the sliding coupler with the length adjustment function. This can be used when the distance between parts is 20 to 320mm. Setting the mounting bracket at the bottom is also possible.

- The bottom plate of RSS can be attached only for connection with RD duct of 1 m/2 m and the elevation surface corner.
- · Sliding adjustment on the corner part side cannot be used for connections with the corner parts of walkway type.
- This cannot be used for the connecting part with the elevation surface corner for installation on the wall face.



istance between parts (L)	Used parts (Duct length + RSS)	RSS bottom plate attachment	Remarks	
-20	None (general connection)	-		
20 to 120	RSS-1	0	For 20, fixing coupler is also usable.	
120 to 220	RSS-2	0		
220 to 320	RSS-3	0	For 260, single use of 0.3 m duct is also possible.	
300 to 400	0.3m+RSS-1	×		
400 to 500	0.3m+RSS-2	×	For 460, single use of 0.5 m duct is also possible.	
500 to 600	0.3m+RSS-3	×	For 540, use of 0.3 m+0.3 m duct is also possible.	
500 to 600	0.5m+RSS-1	×	For 540, use or 0.3 mmo.3 m duct is also possible.	
600 to 700	0.5m+RSS-2	×		
700 to 800	0.5m+RSS-3	×	For 740, use of 0.3 m+0.5 m duct is also possible.	
780 to 880	0.3m+0.5m+RSS-1	×		
880 to 980	0.3m+0.5m+RSS-2	×	For 940, use of two 0.5 m ducts is also possible. For 960, single use of 1 m duct is also possible.	
980 to 1080	0.3m+0.5m+RSS-3	×		
1000 to 1100	1m+RSS-1	0		
1100 to 1200	1m+RSS-2	0		
1200 to 1300	1m+RSS-3	0	For 1,240, use of 0.3 m+1 m duct is also possible.	
1280 to 1380	0.3m+1m+RSS-1	0		
1380 to 1480	0.3m+1m+RSS-2	0	For 1,440, use of 0.5 m+1 m duct is also possible.	
1480 to 1580	0.3m+1m+RSS-3	0		
1480 to 1580	0.5m+1m+RSS-1	0		
1580 to 1680	0.5m+1m+RSS-2	0		
1680 to 1780	0.5m+1m+RSS-3	0	For 1,720, use of 0.3 m+0.5 m+1 m duct is also possible.	
1760 to 1860 0	0.3m+0.5m+1m+RSS-1	0		
1860 to 1960 0	0.3m+0.5m+1m+RSS-2	0	For 1 060, upo of 0 m dust is also possible	
1960 to 2060 0	0.3m+0.5m+1m+RSS-3	0	For 1,960, use of 2 m duct is also possible.	
2000 to 2100	2m+RSS-1	0		
2100 to 2200	2m+RSS-2	0		
2200 to 2300	2m+RSS-3	0		





# RR reducer

There are two types of reducer RR, and the installation method and

The mounting bracket cannot be set at the connection part of the

Set the mounting bracket at a near strut etc.

Also note that this cannot be used for connection with the vertical ell in the installation on the wall surface.

#### Coupler type

This can be used for the installation on a plane surface and installation directly on the wall surface.

When this is used, 63mm clearance between parts is needed. The bottom plate cannot be used.

## Plate type

This can be used for the installation on a plane surface and installation on the wall surface (downward).

When this is used, the smaller duct enters inside by 20mm.

Note In the installation on the wall surface (upward), rain water tends to intrude from ne gap easily because of the structure of parts.


<Figure 3.3.6-1> Coupler type Plate type

# Connection for 900/900H corner parts

Use bolts to secure the duct, which will be connected to the corner parts, directly on the guide.

Note Support the duct and corner part separately to prevent the load from being given to other parts.


After piping work is completed, install the lid reinforcing plate (RXH-900, etc.).



# 3.3.8 Connection for 900/900H joint (1) RXR

When connecting 900/900H size corner part (except for RCF) to a duct of a different diameter, use

For installation, insert the duct into the part by 20 mm and secure it to RXR with bolts.




Design

Design

# Connection for 900/900H joint (2) RXJ

To connect one corner part to another corner part (except for RCF) using RXJ, provide a gap of 10 mm (6 mm for RCI and RCO) between them and connect them with RXJ. For a small gap that is created at the top, apply caulking treatment.




# RXSS/RXSSW box joint sliding coupler

This installation is used to connect one box to another using the sliding coupler. It is used for connecting a plane corner between RX and RX or an elevation corner between RCI and RCO.

## Parts to be connected


- · RX-900 (H) (cross-shape branch joint)
- RXW-900 (H) (cross-shape branch joint for walkway)
- · RF-900 (H) (plane corner 45°)
- RFW-900 (H) (plane corner 45° for walkway)



<Figure 3.3.10-1> Box joint sliding coupler

RXSS/RXSSW

\*The illustration is an example of use for walkway.





# RCSS sliding coupler for RCF-900 (H)-SUS

Sliding coupler used to connect the elevation corner 45° (for SUS).

#### Parts to be connected

· RCF-900 (H)-SUS (elevation corner 45°)





• 3.4.1 Product configuration

• 3.4.3 Table for selecting a 150-size mounting bracket (for installation on the floor)

3.4 Mounting bracket . 3.4.5 Table for selecting a mounting bracket for installation

• 3.4.4 Table for selecting a mounting bracket other than

on the wall surface (basic installation example)

[ Design ]

Design

Design

**Mounting bracket** 


The mounting bracket for RD 300 to 900 sizes can be adjusted within the range from 130 to 940 in its height by using the gate part (RZM) and leg part (RZB) in combination.


There are two types of 150 size mounting bracket: one leg mounting bracket of 280 through 940, and mounting bracket for wall surface which is appropriate for installation on the wall surface and its height is adjustable by three stages of 100, 125, and 150

# contents

is adjus	stable by three stages of 100, 125, and 150.	
3.4.1	Product configuration ·····	
3.4.2	Load capacity ·····	
3.4.3	Table for selecting a 150-size mounting bracket (for installation on the floor)	
3.4.4	Table for selecting a mounting bracket other than 150-size (for installation on the floor)	
3.4.5	Table for selecting a mounting bracket for installation on the wall surface (basic installation example)	
3.4.6	Example of position for setting	
3.4.7	Position for setting	
3.4.8	Standard pitch between bases ·····	
3.4.9	Example of setting the mounting bracket·····	
3.4.10	RZC bracket attachment plate for vertical ell ······	42
3.4.11	RBK-B auxiliary bracket for strut ······	42
3.4.12	RBK-A auxiliary bracket for duct base	42
3.4.13	RD-HB Screw set for RD-HB wall cover ·····	42
3.4.14	RZY mounting bracket guide for duplex mounting	42
	RDY pipe support base ·····	
	RKT fixing bracket for fixing RD to shaped steel ·····	
3.4.17	RKTW RD walkway fixing bracket for shaped steel ······	43
3.4.18	RCT RD bracket for fixing channel Fixing (to floor)	44
3.4.19	Fixing (to floor)	44

# **Product configuration**





#### **Load capacity** 3.4.2

For the load capacity, see [1.4] Load capacity and strength.

# Table for selecting a 150-size mounting bracket (for installation on the floor)


<Table 3.4.3-1>

Model number	Height	(Unit:mm
RZ-150-M	280 to 480	
RZ-150-L	480 to 710	
RZ-150-LL	710 to 940	

# Table for selecting a mounting bracket other than 150-size (for installation on the floor)

Based on <Table 3.4.4-2>, select a combination of gate and leg to suit the required height.

Note that if there are multiple combinations to suit the required height, the leftmost one is of the lowest price.



<Table 3.4.4-2>

nm)	Combination with RZM-S type	Combination with RZM-MS type	Combination with RZM-MM type	n		ation with M type	Combination with RZM-L type
950							
900							
350							
300						<u>-7</u> 90_	
750				730_			7.50 When using RZB-L
700							
550				When using		When using RZB-L	_630
600	<u>-</u> 590-	When using		RZB-L		_600_	When using RZB-ML
550	When using RZB-L			540		_540-	When using RZB-M 540-
500							When using
150		450	When using		480	When using RZB-ML	L480 L480 L480 L
100	400	When using	420_ RZB-MĹ		When using RZB-M		
350	When using RZB-ML 350	RZB-ML350	When using350-		-380 When using - RZB-S	350	
	000	_330	320 - When using RZB-M		330 330		ration
300	280— When using	When using RZB-M	RZB-S 270 270			H	
250	RZB-M -230	230 230 Vihen using				When us	sing LIO
200	1-80— When using						1 H1 Mounting bracket gate RZM
50							Mounting bracket leg RZB
100							

# Table for selecting a mounting bracket for installation on the wall surface (basic installation example)

For installation on the wall surface, see \ [2.3] Method of installation on the wall surface.

\ Table 3.4.5-1/		
Model number	Height	Remarks
RZW-150	100, 125, 150 (three stages)	Dedicated for 150 size
RZM-S+RZB-S	130mm to 180mm	_

#### Notes in design

Values in the table for selecting a mounting bracket are just the calculated values, and in almost all of the actual installation, an error will occur by several millimeters to several centimeters depending on the parts assembly conditions and installation environment (incline of floor) etc. In selection, leaving a margin is recommended.

	g mounting n in design	when	the	height o	f mountii	ng bracket


RZM-S + RZB-ML Error correction is possible within the range of 350mm to 400mm.


 $\times$  RZM-M + RZB-S


Since the error correction is possible within the range of 330mm to 380mm, error correction to over 380 mm is not possible


# **Example of position for setting**

\* For details about attaching the mounting bracket to parts, see the item of parts.









# Position for setting

3.4 Mounting bracket

Positions for setting mounting brackets described here are just in a general case. The required quantity and setting positions of mounting brackets differ depending on the fitting shape/size and installation method. Be sure to check the pages of each fitting and its installation method to decide the

positions for setting mounting brackets. The mounting bracket can be set at the strut, duct base, connection part, auxiliary strut, and bottom plate, etc.

Note that the setting positions of mounting brackets differ depending on the duct size and installation method.

<Table 3.4.7-1> Quick reference of mounting bracket setting positions  $\bigcirc$ : Usable  $\triangle$ : Usable but there are some restrictions  $\times$ : Unusable -: Cannot be set for a constructional reason

			O · Usable △	· Osable	but there ar	e some restriction	is A . Utiusable	e — . Carinot be set for a constructional reason
Object to be set for	Size	Setting position	Connection method Duct base attachment method			Bottom plate + Standard	wall surface Bottom plate + Standard	Use condition and remarks (restrictions in $\triangle$ case)
			Coupler-free connection	0	0	0	×	
			Fixing coupler	0	Δ	0	×	Limited to auxiliary use for walkway. *2
		Connection	Free coupler A	Δ	Δ	Δ	×	Limited to auxiliary use for 2m pitch*1 and walkway. *2
		part	Free coupler S/H	_	_	_	-	
			Reducer	-	_	_	_	
	Other than 150		Sliding coupler	Δ	△*4	△*5	×	Limited to auxiliary use for 2m pitch*1. *
		Strut	Standard duct	0	0	0	0	
		part	Open type duct	0	0	0	Δ	Limited to auxiliary use in the installation on the wall surface. **
Duct		Duct base	Standard duct	0	Δ	×*3	△*7	Limited to auxiliary use for walkway. *2 Limited to 2m or 1m type in the installation on the wall surface
		part	Open type duct	0	Δ	×*3	○*7	Limited to auxiliary use for walkway. *2 Limited to 2m or 1m type in the installation on the wall surface
	150		Coupler-free connection	_	_	-	-	
		Connection part	Fixing coupler	Δ	-	Δ	×	Cannot be set in a part connecting with fittings.
			Free coupler	Δ	-	Δ	×	Cannot be set in a part connecting with fittings.
			reducer	_	_	-	-	
		Strut part		0	_	0	0	
		Duct base	part part	_	_	_	-	
		Connection	Coupler-free connection	0	0	0	×	
			Fixing coupler	0	Δ	0	×	Limited to auxiliary use for walkway. *2
			Free coupler A	Δ	Δ	Δ	×	Limited to auxiliary use for 2 pitch*1 and walkway. *2
	Other than	part	Free coupler S/H	_	_	_	-	
	150		Reducer	-	_	_	_	
			Sliding coupler	Δ	_	△*6	×	Limited to auxiliary use for 2m pitch*1. *
Fittings		Strut part (including auxiliary strut)		0	0	0	0	
		Duct base	e part	_	-	_	-	
			Coupler-free connection	-	_	-		
		Connection	Fixing coupler	1	_	_	_	
	150	part	Free coupler	-	_	_	_	
	.00		Reducer	-	_	_	-	
		Bottom pl	ate	0	_	0	0	
		Duct base	e part	_	-	_	_	

- \*1... See [3.4.8] Standard pitch between bases.
- \*2··· The auxiliary use refers to the use of mounting bracket which is not counted in the load calculation, and the safety is kept even without using it.
- \*3... When attaching the bottom plate, processing the bottom plate is necessary.
- \*4··· For the walkway, be sure to set the mounting bracket.
- $*5\cdots$  In the connection with 0.5m or 0.3m duct, the bottom plate cannot be attached.
- \*6... In the connection with fittings other than RCF, the bottom plate cannot be attached.

# Standard pitch between bases

Positions for setting mounting brackets described here are just in a general case. The required quantity and setting positions of mounting brackets differ depending on the fittings shape/size and installation method.

Be sure to check the pages of each fitting and its installation method to decide the positions for setting mounting brackets

Pitch to be set between mounting brackets for duct: Basically 1,980mm for the joinless connection.

However adjust it depending on the piping condition or environment weight (e.g., snow accumulation).

Basically set the mounting bracket at two positions or more for one duct/fittings. (The necessary quantity of the mounting brackets differs depending on the installation method. See the item of each part for details.)

Pitch between mounting brackets and load capacity

# Support at the both ends of duct (2m pitch)

In the installation by using the coupler-free connection, set the mounting brackets at the both ends of duct.

In this case, the pitch between mounting brackets is 1,980mm (approximately 2m). <Figure 3.4.8-1.1>

The pitch becomes 1980mm because (the ducts of 2000mm in length are connected with overlapping by 20mm).

\* The pitch between mounting brackets to support duct differs depending on the load.

Reference [1.4] Load capacity and strength


## 2 Support at the both ends of duct and strut at the center (1m pitch)


When increasing the quantity of the mounting brackets to increase the load capacity, set the mounting brackets at the both ends of duct and strut at the

In this case, the pitch between mounting brackets is 990mm (approximately 1m). <Figure 3.4.8-1.2>

## 3 Support at the both ends of duct and all struts (0.5m pitch)


When increasing the quantity of the mounting brackets to further increase the load capacity, set the mounting brackets at the both ends of duct and all struts. In this case, the pitch between mounting brackets is 490 to 500mm





(approximately 0.5m).

<Figure 3.4.8-1.3>



# **Example of setting the mounting bracket**

#### 1 Example of basic mounting bracket setting

For stability, set the mounting brackets to support the duct at least in two positions.

\* For the required quantity of mounting brackets for each part, check the page of explanation on each part.

#### 2 Example of mounting bracket setting in the connection using coupler (walkway)

When the RD duct is used as the walkway, setting the mounting bracket at the connection part using a coupler part is to be limited to

Set the mounting brackets at two positions (struts) near the connection part (one on its one side and the other on its opposite side).

## 3 Example of mounting bracket setting in the connection using a special coupler (2m pitch)


In the 2m-pitch setting (setting the mounting bracket at the connection part), when free coupler RFJ, reducer RR, or Sliding coupler RSS is used, set the mounting brackets at two positions (strut or duct base) near the connection part (one on its one side and the other on its opposite side).


\* Usable only for auxiliary use (not counted in the load calculation). (excluding RR)


#### 4 Example of mounting bracket setting in the connection using sliding coupler


Between the parts for walkway or in use of combination with the vertical ell, set the mounting bracket also at the sliding coupler. (excluding 150


\* For attaching the vertical ell, see the item of each part














for duplex mounting


• 3.4.17 RKTW RD walkway fixing bracket for shaped steel

Design

Design

# RZC bracket attachment plate for vertical ell

This is used for supporting the 90° vertical ell or sloping part.




# **RBK-B** auxiliary bracket for strut

This is used for fixing general type ducts and fittings directly to the wall.

# Reference

[2.3.3] Conditions for installation on the wall surface (directly on the wall surface)




# **RBK-A** auxiliary bracket for duct base

This is used for installing the open type duct on the wall surface.


#### Reference

[2.3.3] [2.3.4] Conditions for installation on the wall surface




# RD-HB screw set for wall cover

This is used for mounting the cover of duct, corner parts, and joint parts for wall installation.




# RZY mounting bracket guide for duplex mounting

This is used to support duplex mounting of the RD duct.Attach RZY (guide for duplex mounting) to RZB.




- This cannot be used in the connection part. Attach this to the strut. This cannot be attached
- to the connection part.
- This can be attached to RZB-M/ML/L.
- Make an enough space between RZY and RZM to ensure the installation space (attaching cover, piping)



#### RDY pipe support base 3.4.15

This is used when attaching the conduit etc. to the RD mounting bracket. This can be attached to RZB-M/ML/L.



# RKT fixing bracket for fixing RD to shaped steel

This is of dedicated use for the standard type RD duct. The RD duct can be attached to the shaped steel by using this. This cannot be used for the walkway type or fittings.

- This cannot be used in the vertical installation on the wall surface etc
- This cannot be used for fixing the RD duct for walkway.
- Do not use this in a position where vibration or shaking occurs. · Secure fixing cannot be attained for other than the scope of
- application of shaped steel. · Securely tighten the bolt with the designated torque.
- · Set it in 4 or more positions for one duct.
- <Table 3.4.16-1>




<Figure 3.4.16-1> RKT


	Applicable shaped steel	Load by which shift will begin	Tightening torque			
H-shaped steel	Flange thickness 7 to 13 mm	ekness 7 to 13 mm 245N (25kgf)				
Channel steel	75×40mm, 100×50mm, 125×65mm, 150×75mm	147N (15kgf)	5.9N·m(60kgf·cm)			

# RKTW RD walkway fixing bracket for shaped steel

Walkway type ducts can be attached to shaped steel.

- Do not reuse the product after it has been used.
- This cannot be used for vertical parts on the wall, etc.
- This cannot be attached to either end (joint) of the RD duct. • Insert the bracket to the shaped steel in the direction of the arrow engraved on the product.






7-1>		Applicable shaped steel	Tightening torque
	H-steel	Flange thickness 7 to 13 mm	42N·m(428kgf·cm)
	Channel steel	75×40mm、100×50mm、125×65mm、150×75mm	42N*III(420KgI*CIII)

3.4.18 RCT bracket for fixing channel

There is a method for installing RD duct directly on channel. Set the bracket for fixing channel and secure it with a bolt.

- This cannot be used in the vertical installation on the wall surface etc
- · This cannot be used for fixing the RD duct for walkway. • Do not use this in a position where vibration or shaking occurs.
- · Please install on both sides of the RD duct.




• 3.4.18 RCT bracket for fixing channel [Design]

• 3.4.19 Fixing (to floor)

# SHBN-S-Z bolt hanging bracket For outdoor use (equivalent to HDZT49)

To support and secure the channel on the steel material, SHBN-S-Z bolt hanging bracket (for outdoor use) can also be used.





# 3.4.19 Fixing (to floor)

Fix the mounting bracket by anchoring or embedment with mortar. For the installation on the floor, fixing it by using the form (name of our product: Plabase) or the multipurpose support base "Recycrock" is also possible.

#### Firmly fix the mounting bracket when using it in a walkway etc.

I Fixing it by using the support base "Recycrock CR"













Allowable load per piece when using CR-W1015/A1015 Allowable surface load: 7,840N Area of RD leg (including bolts) = 22cm<sup>2</sup> Allowable load per piece when using CR = 1,045N (106.6kgf) /piece

#### 2 Fixing by using the form "Plastic base Plabase (PB-100/120)"







# 3 Fixing by using anchor


Use commercially available W3/8 or M10.


# **Fittings**


Table of	3.5.1	Types of fittings ·····	45
contents	3.5.2	RE 90° flat ell ·····	46
	3.5.3	RF 45° flat ell ·····	47
	3.5.4	RFS flexible corner	49
	3.5.5	RT tee ····	50
	3.5.6	RXN/RX cross ····	51
	3.5.7	RCF 45° vertical ell ·····	53
	3.5.8	RC/RCI/RCO 90° vertical ell (150 to 600 H) ······	56
	3.5.9	RC/RCI/RCO 90° vertical ell (900/900H) ······	59
	3.5.10	Installation of a mounting base on the elevation surface corner ······	61

# Types of fittings

There are the following types of fittings: vertical ell and flat ell 45°/90° bending, tee, and cross. Note that available sizes are limited for some fittings.







3	5	1_1	>	

Classification	Product name (Abbreviated name)	Туре	Remarks
	90° flat ell	Standard type	For 900 size, use RX-900/900H.
	(RE)	Walkway type	There is no sliding coupler for 150 size. For 900 size, use RXW -900/900H.
	45° flat ell	Standard type	_
	(RF)	Walkway type	There is no sliding coupler for 150 size.
Elbow	Flexible corner	Standard type	There is no sliding coupler for 150 size.
	(RFS)	Walkway type	There is no sliding coupler for 150 size.
	90° vertical ell° (RC/RCI/RCO)	Standard type	_
	45° vertical ell (RCF)	Standard type	_
Taa	Tee	Standard type	For 900 size, use RX-900/900H.
Tee	(RT)	Walkway type	There is no sliding coupler for 150 size. For 900 size, use RXW -900/900H.
0	Cross	Standard type	There is no sliding coupler for 150 size.
Cross	(RX)	Walkway type	There is no sliding coupler for 150 size.

- and by hanging from the ceiling. Remove it before setting.
- \* The walkway type cannot be used for the installation on the wall surface and by hanging from the ceiling.
- \* 900/900H size fittings is of the structure of the duct being inserted. (RCF is excluded.)


[ Design ]

Design

Bottom Other plate

3.5.2 RE 90° flat ell

This is the plane surface 90°-bending elbow part.




			(Unit:mm)
Size	W	L	Н
150	150	250	111
300/300H	300	500	134/254
450/450H	450	650	134/254
600/600H	600	800	134/254

• 3.5.2 RE 90° flat ell

%900/900H uses RX.

# Position for setting and required quantity of mounting brackets




<Figure 3.5.2-3> RE(W)-300 to 600H
Connection part, strut,

Auxiliary strut


··· Three positions for three pieces

#### Vote

- Be sure to make a fixing on the auxiliary strut.
   As to the mounting bracket when RE is set on the floor, RZ-150 or a small-size mounting.
- the floor, HZ-15U or a small-size mounting bracket can also be used. In that case, set it on the hole at the outer side of the auxiliary strut. For REW, use the mounting bracket according
- For the duplex mounting, set the mounting bracket to straddle the fittings.



# 2 Example of setting mounting bracket



# 3 Finished dimensions





Table of RE	90° flat	ell finishe	ed dimens	sions	3	<ta< th=""><th>ble 3</th><th>3.5.2-1&gt;</th><th>&gt;</th></ta<>	ble 3	3.5.2-1>	>


Contribution of the Contri										
Size	w	Coupler-free Connection of RSJ joints		Connection of RSJ joints	Connection of RSS joints					
5.125			_	b	b	С	x *	Used coupler		
150	150	250	350	_	370	_	_	_		
						720~ 820	20~120	RSS-1		
300/300H	300	500	700	680	720	820~ 920	120~220	RSS-2		
				920~1020	220~320	RSS-3				
						870~ 970	20~120	RSS-1		
450/450H	450	650	850	830	870	970~1070	120~220	RSS-2		
						1070~1170	220~320	RSS-3		
						1020~1120	20~120	RSS-1		
600/600H	600	800	1000	980	1020	1120~1220	120~220	RSS-2		
						1220~1320	220~320	RSS-3		

# 3.5.3 **RF 45° flat ell**


This is the plane surface 45°-bending elbow part.




# Position for setting and required quantity of mounting brackets




# 2 Example of setting mounting bracket



3 Finished dimensions






• 3.5.3 RF 45° flat ell

[ Design ]

Size	W	* L1	* <b>L</b> 2	Couple conne	er-free ction	Conne RSJ joi	ction of ints	Connection of RSS joints		:s	
				а	b	а	b	а	b	<i>x</i> *	Used coupler
150	150	133	71	_	_	362	158	_	-	-	_
								938~1010	397~468	20~120	RSS-1
300/300H	300	333	209	910	369	938	397	1010~1081	468~539	120~220	RSS-2
								1081~1152	539~610	220~320	RSS-3
								1045~1116	441~512	20~120	RSS-1
450/450H	450	395	209	1016	413	1045	441	1116~1187	512~583	120~220	RSS-2
								1187~1257	583~653	220~320	RSS-3
								1151~1222	485~556	20~120	RSS-1
600/600H	600	457	209	1123	457	1151	51 485	1222~1293	556~627	120~220	RSS-2
								1293~1363	627~697	220~320	RSS-3

\* Values of L1 and L2 are for preparing the piping diagram.

\* When the value of "x" exceeds 320, see [Table 3.3.5-1] in [3.3.5] RSS sliding coupler.







Table of RF 45° flat ell finished dimensions (connection using coupler)									<table< th=""><th>3.5.3-2&gt;</th><th>(Unit:mm)</th></table<>	3.5.3-2>	(Unit:mm)				
Size	w	L1	L2	а	b	x	Used coupler	Size	W	Lı	L2	а	b	x	Used coupler
				1217	508	10	RXJ					1214~1284	503~573	0~100	RXSS-900-1
900/900H	980	557	151	1393	685	260	0.3m duct	900/900H	980	557	151	1284~1353	573~644	100~200	RXSS-900-2
				1534	826	460	0.5m duct					1353~1426	644~715	200~300	RXSS-900-3

Insert a duct (straight pipe) between RF elevation surface corners 45° when using RFJ free joints or RSJ fixing joints (calculation of step dimensions)



		٠.
*900/900H is calculated on the assumption that the end of the duct pipe	*	
enters the corner part by 20mm.		


\*a=b+L1+L2 The distance between RF: $\sqrt{2}\times$ b-L1-L2

x	x indicates the duct length							
	Size	Calculation						
	Size	RFJ + jointless connection	RSJ connection					
	150	_	$x = \sqrt{2} \times b - 244$ a = b + 204					
3	300/300H	$x = \sqrt{2} \times b - 542$ a = b + 542	$x = \sqrt{2} \times b - 582$ a = b + 542					
4	450/450H	$x = \sqrt{2} \times b - 604$ $a = b + 604$	$x = \sqrt{2} \times b - 644$ a = b + 604					
6	600/600H	$x = \sqrt{2} \times b - 666$ a = b + 666	$x = \sqrt{2} \times b - 706$ a = b + 666					
Ś	900/900H	$x = \sqrt{2} \times b - 668$ a = b + 708	_					

\*For size 900, the duct is fixed directly to the RF parts with screws without using RFJ. If you cut the duct, make a plug-in connection or drill screw holes and secure with screws.

# **RFS** flexible corner

It is a corner part that can be adjusted as required in the horizontal direction.



			(Unit - mm,
Size	W	Н	L
300	304	138	240
450	454	138	290
600	604	138	340
900	904	138	440
300H	304	258	240
450H	454	258	290
600H	604	258	340
900H	904	258	440

# 1 Range of angles

Horizontal plane: 0° to 20°

For between 20° and 40° in the horizontal plane, use 2 sets of RFS (W) flexible corner and connect an RD duct in between.

#### Note

• RFS (W)-900(H) can be used only for an RD duct with length of 0.5 m or longer. (Connection is not possible for


For between 45° and 65° in the horizontal plane, connect RF (W) plane surface corner 45°.

#### Note


• RFS (W)-900(H) cannot be directly connected to RF. Install an RD duct with length of 0.5 m or longer in between.

# <Figure 3.5.4-2> Example of connection


# RFS(W)-300(H)/450(H)/600(H)



# RFS(W)-900(H)



# 2 Finished dimension



RFS flexible corner Table of finished dimension (B dimension) <Table 3.5.4-1>

For the finished position and angle of the RD duct, see the following


Size	O°	4°	8°	12°	16°	20°
300/300H	90	86	82	78	74	70
450/450H	115	108	102	95	89	82
600/600H	140	131	122	112	103	94
900/900H	190	176	161	147	132	118

B: Distance from the RD duct end to the center of flexible corner

50

RT tee 3.5.5

Tees for plane surface.





Size	W	D	ı	(Unit:mm)
150	150	250	250	111
300/300H	300	500	700	134/254
450/450H	450	650	850	134/254
600/600H	600	800	1000	134/254

• 3.5.5 RT tee


[ Design ]


# 1 Position for setting and required quantity of mounting brackets







#### 2 Example of setting mounting bracket





#### 3 Finished dimensions





(Unit:mm)

# Table of RT tee finished dimensions


<table 3<="" th=""><th>5.5.5-1&gt;</th></table>	5.5.5-1>
---	----------

Size	W	D	L	Coupler-free connection	Connection of RSJ joints	Connection of RSS joints		
				b	b b		x *	Used coupler
150	150	250	350	ı	370	l	_	_
						720~ 820	20~120	RSS-1
300/300H	300	500	700	680	720	820~ 920	120~220	RSS-2
						920~1020	220~320	RSS-3
		450 650	850	830	870	870~ 970	20~120	RSS-1
450/450H	450					970~1070	120~220	RSS-2
						1070~1170	220~320	RSS-3
						1020~1120	20~120	RSS-1
600/600H	600	600 800	1000	980	1020	1120~1220	120~220	RSS-2
						1220~1320	220~320	RSS-3


# **RXN/RX** cross


This is a coupler (fittings) branching in three directions.

The size for 900/900H can also be used as an elbow or tee by stopping the opening by using the supplied plate.




#### Position for setting and required quantity of mounting brackets







#### 2 Example of setting mounting bracket



lpha When the value of "x" exceeds 320, see [Table 3.3.5-1] in [3.3.5] RSS sliding coupler.

3 Finished dimensions





• 3.5.6 RXN/RX cross


Table of cross 300 to 600H finished dimensions


<Table 3.5.6-1>

(Unit:mm)

[ Design ]

Size	W	L	Coupler-free connection	Connection of RSJ joints	Col	nection of RSS joints		
			b	b	b	<i>x</i> *	RSS-1 RSS-2 RSS-3 RSS-1 RSS-2 RSS-3 RSS-1 RSS-2 RSS-3 RSS-1 RSS-2 RSS-3	
					720~ 820	20~120	RSS-1	
300/300H	300	700	680	720	820~ 920	120~220	RSS-2	
					920~1020	220~320	RSS-3	
					870~ 970	20~120	RSS-1	
450/450H	450	850	830	870	970~1070	120~220	RSS-2	
					1070~1170	220~320	RSS-1 RSS-2 RSS-3	
					1020~1120	20~120	RSS-1	
600/600H	600	1000	980	1020	1120~1220	120~220	RSS-2	
					1220~1320	220~320	RSS-3	








Table of cross	900/900H finished dimensions	<table 3.5.6-2=""></table>

1	(Unit:mm)
	Used coupler


Size	а	b	x	Used coupler
		990	10	RXJ
		980~1080	0~100	RXSS-900-1
000/00011	980	1080~1180	100~200	RXSS-900-2
900/900H		1180~1280	200~300	RXSS-900-3
		1240	260	0.3m duct
		1440	460	0.5m duct

# RCF 45° vertical ell

Elevation surface 45° elbow.

3.5 Fittings

One set (RCF) is composed of one piece of rising type (RCFI) and one piece of falling type (RCFO).



#### 1 Position for setting and required quantity of mounting brackets


• 150


None (not supported directly)


• 300 to 900H


Connection part

··· Two positions for two pieces











3 Dimension of level difference

Values of "c" and "d" are the dimensions of the bottom of RCF for preparing the layout diagram.





%When using free coupler : x = dimension of duct short pipe (RFJ + coupler-free connection installation method)

Use a sliding coupler which is easy to adjust length as far as possible. When using the free coupler, use the A type at which the mounting bracket can be set by checking "[3.3.4] Free coupler" in advance.


Table o	Table of RCF 45° vertical ell dimension of level difference <table 3.5.7-1=""> (Unit: mm)</table>											
Size	w	С	d	н	Coupl conne	er-free ction	Connec RSJ joi	ction of nts		Connection of	RSS joints	
	"		-		а	b	а	b	а	b	x	Used coupler
150	150	116	70	111	_	_	332	146	_	_	_	_
									443~513	192~262	20~120	RSS-1
300	300	149	103	134	416	164	444	192	513~584	262~333	120~220	RSS-2
									584~641	333~404	220~320	RSS-3
									443~513	192~262	20~120	RSS-1
450	450	149	103	134	416	164	444	192	513~584	262~333	120~220	RSS-2
									584~641	333~404	220~320	RSS-3
									443~513	192~262	20~120	RSS-1
600	600	149	103	134	416	164	444	192	513~584	262~333	120~220	RSS-2
									584~641	333~404	220~320	RSS-3
									443~513	192~262	20~120	RSS-1
900	900	149	103	134	416	164	444	192	513~584	262~333	120~220	RSS-2
									584~641	333~404	220~320	RSS-3
									530~599	228~298	20~120	RSS-1
300H	300	199	103	254	502	199	530	228	599~669	298~368	120~220	RSS-2
									669~726	368~439	220~320	RSS-3
									530~599	228~298	20~120	RSS-1
450H	450	199	103	254	502	199	530	228	599~669	298~368	120~220	RSS-2
									669~726	368~439	220~320	RSS-3
									530~599	228~298	20~120	RSS-1
600H	600	199	103	254	502	199	530	228	599~669	298~368	120~220	RSS-2
									669~726	368~439	220~320	RSS-3
									530~599	228~298	20~120	RSS-1
900H	900	199	103	254	502	199	530	228	599~669	298~368	120~220	RSS-2
									669~726	368~439	220~320	RSS-3

- \* When the value of "x" exceeds 320, see [Table 3.3.5-1] in [3.3.5] RSS sliding coupler.
- \* Values of "a" and "b" in this table were obtained from the working drawing.
- $\times$  When the value of "x" exceeds 1m, use the 90° vertical ell.

Table of RCF 45 °vertical ell (900 (H) size / SUS type) dimension of level difference < Table 3.5.7-2> (Unit : mm)

C:		Connection of RCSS joints							
Size	Н	а	b	Х	Used coupler				
		487~558	207~278	13~113	RCSS-900-1-SUS				
900	134	558~629	278~349	113~213	RCSS-900-2-SUS				
		629~700	349~420	213~313	RCSS-900-3-SUS				
		572~643	242~313	13~113	RCSS-900H-1-SUS				
900H	254	643~714	313~384	113~213	RCSS-900H-2-SUS				
		714~785	384~455	213~313	RCSS-900H-3-SUS				


Insert a duct (straight pipe) between RCF elevation surface corners 45° when using RFJ free joints or RSJ fixing joints (calculation of step dimensions)



x indicates the duct length  $x = \sqrt{2} \times b - 226$ a = b + 186 $x = \sqrt{2} \times b - 252$  $x = \sqrt{2} \times b - 292$ a = b + 252a = b + 252300H 450H  $x = \sqrt{2} \times b - 302$  $x = \sqrt{2} \times b - 342$ a = b + 302a = b + 302\* If the duct length exceeds 1m, use an elevation surface

# 4 Example of calculation of the height of mounting bracket (when using RCF coupler-free type)


<Figure 3.5.7-9> When obtaining the height of mounting bracket based on the position of Pipe shaft anchor




#### Notes in design

Values above are just the calculated values for selecting a mounting bracket, and in almost all of the actual installation, an error will occur by several millimeters to several centimeters depending on the parts assembly conditions and installation environment (incline of floor) etc. In selection, leaving a margin is recommended.

Example) Selecting mounting bracket when the height of mounting bracket is 380 mm in design



Error correction is possible within the range of 350mm to 400mm.



Since the error correction is possible within the range of 330mm to 380mm, error correction to over 380mm is not possible.


3.5.8


Design

• Fix the load-applied side (wall side) with the fixing coupler.

3 Example of installation on the wall surface


- When the horizontal part is connected by the coupler-free connection, set the mounting bracket at the connection part.
- When the horizontal part is connected by the fixing coupler, set the mounting bracket at the strut of the duct.
- Bottom plate must be made of steel or stainless steel (net bottom plate is not acceptable).





Elevation surface 90° elbow. There are the rising type (RCI) and the falling type (RCO). RC-150 can be used for both "rising" and "falling" by exchanging the cover and bottom plate.

RC/RCI/RCO 90° vertical ell (150 to 600H)



#### Position for setting and required quantity of mounting brackets

· 150

None (not supported directly)

• 300 to 600H

RCI

Connection part

··· Two positions or more for one piece (see Note)

RCO


Connection part

··· At least two positions for zero pieces (see Note)


#### Note


When not setting the mounting bracket, use the fixing coupler RSJ or sliding coupler RSS by checking the installation example carefully in advance.

- $\ensuremath{\ensuremath{\%}}$  Between RCI and RCO, direct or indirect support is required.
- \* Indirect support
- State where no mounting bracket is set at the target object directly, but the load is supported by combination with other parts.



#### 2 Example of setting mounting bracket (for level difference)





narts

56

et

Mounting bracket


Fittings

Botton plate

Other par

Other parts

4 Dimension of level difference







Table of R	Table of RC/RCI/RCO 90° vertical ell dimension of level difference <table 3.5.8-1=""> (Unit:mm)</table>										
Size	connection DC Ligitor		Coupler-free Connection connection RSJ joints		Conr	nection of RSS	joints				
						b	b	b	<i>x</i> *	Used coupler	
150	150	210	210	111	309	_	330	_	_	_	
								430~530	20~120	RSS-1	
300	300	260	281	134	410	390	430	530~630	120~220	RSS-2	
								630~730	220~320	RSS-3	
								430~530	20~120	RSS-1	
450	450	260	281	134	410	390	430	530~630	120~220	RSS-2	
								630~730	220~320	RSS-3	
								430~530	20~120	RSS-1	
600	600	260	281	134	410	390	430	530~630	120~220	RSS-2	
								630~730	220~320	RSS-3	
								550~650	20~120	RSS-1	
300H	300	380	401	254	530	510	550	650~750	120~220	RSS-2	
								750~850	220~320	RSS-3	
								550~650	20~120	RSS-1	
450H	450	380	401	254	530	510	550	650~750	120~220	RSS-2	
								750~850	220~320	RSS-3	
								550~650	20~120	RSS-1	
600H	600	380	401	254	530	510	550	650~750	120~220	RSS-2	
								750~850	220~320	RSS-3	


\* When the value of "x" exceeds 320, see [Table 3.3.5-1] in [3.3.5] RSS sliding coupler.


# 3.5.9 RCI/RCO 90° vertical ell (900/900H)




# ■ Position where the mounting bracket can be set

- RCI bottom plate ··· Two positions or more
- RCO bottom plate, Mounting bracket fixing plate for RCO ··· One or two positions





## 2 Example of setting mounting bracket for RCI





3 Installation example of RCO-900(H) mounting base

Example of installation and usage < Table 3.5.9-1 >


	Vertical duct Length State		Example of	Remarks and Notes			
			installation/usage				
1	Im or less	Standard-size duct	Example of installation 1/ usage 1	Support the load of piping at the upper and lower horizontal area to prevent the load from being given to the duct or corner parts.			
N	More than 1m	Installation directly on the wall face	Example of installation 2/ usage 2	Ensure that the piping load is not given to the corner parts.			


■ Example 1 of setting mounting bracket/Example 1 of use






■ Example 2 of setting mounting bracket/Example 2 of use





#### 4 Dimension of level difference



# Table of RCI/RCO-900/900H vertical ell dimension of level difference

<fig< th=""><th colspan="11"><pre><figure 3.5.9-2=""> (Unit : mm)</figure></pre></th></fig<>	<pre><figure 3.5.9-2=""> (Unit : mm)</figure></pre>																			
Size	w	, L ,	L.	Н	а	RXJ use	RXSS use	Duct use	x	Used										
JIZC	\ \	(RCI)	(RČO)	' '	a	b	b	b		coupler										
						606	_	_	6	RXJ										
						_	600~700	_	0~100	RXSS-900-1										
900	980	385	385	169	600	_	700~800	_	100~200	RXSS-900-2										
900	900	303	303		1600	_	800~900	_	200~300	RXSS-900-3										
						_	_	806	260	0.3m duct										
						_	_	1060	460	0.5m duct										
						725	_	_	6	RXJ										
																_	719~819	_	0~100	RXSS-900H-1
900H	000	504	504	288	740	_	819~919	_	100~200	RXSS-900H-2										
900⊓	900	304	504	200	119	_	919~1019	–	200~300	RXSS-900H-3										
						_	_	979	260	0.3m duct										
						_	_	1179	460	0.5m duct										


# 3.5.10 Installation of a mounting base on the elevation surface corner


## ■ Mounting base fixing plate for elevation surface and mounting base height

To install a mounting base fixing plate for elevation surface, it.is necessary to select an RD mounting base. To select an RD mounting base, calculate the H2 dimension (= mounting base height) shown in the figure below using the following calculation method.


• Note that the calculation method to obtain the H2 dimension for elevation surface corner 90° is different from that for elevation surface corner 45°.


- If it is difficult to accurately determine the step height, a height-adjustable sliding joint can be used, in which case the dimension B becomes variable (Table 2).
- Note that it is different from using a fixing joint (Table 1).
- For the finished dimensions of corners, see the instructions for corner.






■Table 2 (Unit: m									
Size	Dimension A		Dimension B (for fixing jo						
JIEC	Difficision A	RSS-1	RSS-2	RSS-3					
300	134	430 to 530	530 to 630	630 to 730					
300H	254	550 to 650	650 to 750	750 to 850					
450	134	430 to 530	530 to 630	630 to 730					
450H	254	550 to 650	650 to 750	750 to 850					
600	134	430 to 530	530 to 630	630 to 730					
600H	254	550 to 650	650 to 750	750 to 850					





900H



900H | 254 | 228~298 | 298~368 | 368~438

60

4 Attaching net (retrofit)

Duct and RE only

Design

## 3.6 Bottom plate


Since RD is designed to be used with the copper pipe covered with insulation material in which the polyethylene foam heat insulating tube of extremely low water absorption is used, the bottom plate is basically not used. However, use the bottom plate for a position being heavily affected by wind and rain such as the wall surface, for a position such as a penetrating part where the water shut-off performance is to be considered, or in a condition where the bird damage can be assumed.

#### Table of contents


3.6.1	Type of bottom plate setting	62
3.6.2	Bottom plate usable position	63
3.6.3	Fittings necessary for bottom plate installation	64

## Type of bottom plate setting


#### 1 Attaching bottom plate (in advance)



## 2 Attaching bottom plate (retrofit) \* Duct only




## 3 Attaching net (in advance) \* Duct and RE only




# <Figure 3.6.1-4> Bottom net

#### 5 Bottom plate for coupler



## 6 Retrofit bottom plate for coupler



\* When setting the mounting bracket at the connection part, the bottom plate for coupler is not necessary.

## **Bottom plate usable position**

The bottom plate usable position is shown in <Table 3.6.2-1>.

For details of parts required in attachment, check [3.6.3] List of parts used for the bottom plate attachment work.

Warning Retrofit attachment of the bottom plate in a position where there is a risk of dropping is dangerous.

<Table 3.6.2-1> Bottom plate usable position

O: Usable	$\triangle$ :	but alternative method available	$\times$ :	Unusable

Object to be attached to			Bottom plate	Bottom net (floor)		
		Attachment in advance (floor)	Attachment in advance (wall)	Retrofit attachment (floor)	In advance	Retrofit attachment
	Duct	0	0	0	0	0
Flat ell		○ *5	○ *5	×	×	×
Ve	ertical ell	0	0	×	×	×
	Coupler-free connection	△ *1	×	×	×	×
	Fixing coupler	0	0	○ *2	×	×
Connection	Free coupler A	○ *6	×	○ *2 · 6	×	×
part	Free coupler S/H	△ *6	×	×	×	×
	Reducer	△ *3	△ *3	△ *3	×	×
	Sliding coupler	○ *4	○ *4	×	×	×

\*1··· For coupler-free connection, the bottom plate for coupler cannot be used. Normally the mounting bracket is set at the connection part, and the bottom plate is not needed.

If the mounting bracket cannot be set at the connection part, use the coupler.

\*2··· When connecting a duct of 1m or longer and a short-size duct of 0.5m or shorter/flat ell/tee by the retrofit attachment method, "retrofit bottom plate for coupler RJB" is needed instead of "bottom plate for coupler RDBJ"

For details of parts required in attachment, check [3.6.3] List of parts used for the bottom plate attachment work.

\*3··· There is no bottom plate for the reducer.

Reference [3.3.6] RR reducer Since the reducer (plate type) is built into parts, no bottom plate is needed. \*4··· The bottom plate of RSS can be attached only in connection with RD duct 2m/1m, and the 45° vertical ell.

\*5... There is no bottom plate for RXN.

\*6... Processing the bottom plate for duct is necessary. Reference [3.3.4] RFJ free coupler

List of parts used in the bottom plate attachment work. For the bottom plate usable position, check [3.6.2] Bottom plate usable position.

Design

## Fittings necessary for bottom plate installation

• 3.6.3 Fittings necessary for bottom plate installation [Design]

<Table 3.6.3-1>

Product to be attached	Attachment method	Model number	Duct size	Attachment part	Mounting bracket setting at the connection part	Required member	Installation reference page
				D at (Ora. 1 ms)	Set	Bottom plate (A), Bottom plate (B)	P148
				Duct(2m, 1m)	Not set	Bottom plate A, Bottom plate B, Bottom plate for coupler, Seffing plate	P148,153
			300/450/600/900	D. 101(0 Fra 0 200)	Set	Bottom plate (A), Bottom plate (B)	P148
		RD、RD-1		Duct(0.5m, 0.3m) Fittings	Not set	Bottom plate (A), Bottom plate (B), Bottom plate for coupler, Stiffening plate	P148,153
			150	_	Set	Bottom plate (A), Bottom plate (B)	P148
			130		Not set	Bottom plate (A), Bottom plate (B), Bottom plate for coupler	P148
				Duct(2m, 1m)	Set	Bottom plate	P148
				Buot(ZIII( IIII)	Not set	Bottom plate, Bottom plate for coupler, Stiffening plate	P148,153
		RD-05	300/450/600/900	Duct(0.5m)	Set	Bottom plate	P148
				Fittings	Not set	Bottom plate, Bottom plate for coupler Stiffening plate	P148,153
					Set	Bottom plate (R), Bottom plate (L)	P150
	In advance	RE	300/450/600	Duct(2m, 1m)	Not set	Bottom plate (R), Bottom plate (L), Bottom plate for coupler, Stiffening plate	P150,153
		1112	000/400/000	Duct(0.5m)	Set	Bottom plate (R), Bottom plate (L)	P150
				Fittings	Not set	Bottom plate (R), Bottom plate (L), Bottom plate for coupler, Stiffening plate	P150,15
					Set	Bottom plate (R), Bottom plate (L)	P151
		RF	300/450/600	Duct(2m, 1m)	Not set	Bottom plate (R), Bottom plate (L), Bottom plate for coupler, Stiffening plate	P151,15
				Duct(0.5m)	Set	Bottom plate (R), Bottom plate (L)	P151
_				Fittings	Not set	Bottom plate (R), Bottom plate (L), Bottom plate for coupler, Stiffening plate	P151,15
Bottom plate		RT	300/450/600	Duct(2m, 1m)  Duct(0.5m)  Fittings	Set	Bottom plate	P152
plate					Not set	Bottom plate, Bottom plate for coupler, Stiffening plate	P152,15
					Set	Bottom plate	P152
					Not set	Bottom plate, Bottom plate for coupler, Stiffening plate	P152,15
		RD\RD-1	300/450/600	Duct(2m,1m)	Set	Bottom plate (A), Bottom plate (B), Resin bush for bottom plate (RDB-B)	P149
					Not set	Bottom plate (A), Bottom plate (B), Bottom plate for coupler, Resin bush for bottom plate(RDB-B)	P149,15
				Duct(0.5m, 0.3m) Fittings	Set	Bottom plate (A), Bottom plate (B), Resin bush for bottom plate(RDB-B)	P149
					Not set	Bottom plate (A), Bottom plate (B), Bottom plate for coupler for retrofit attachmen(RJB), Resin bush for bottom plate(RDB-B), Stiffening plate	P149,15
	Retrofit attachment		150	_	Set	Bottom plate (A), Bottom plate (B), Resin bush for bottom plate (RDB-B)	P149
			. 33		Not set	Bottom plate (A), Bottom plate (B), Bottom plate for coupler, Resin bush for bottom plate(RDB-B)	P149
				D(0 1 )	Set	Bottom plate, Resin bush for bottom plate(RDB-B)	P149
				Duct(2m, 1m)	Not set	Bottom plate, Retrofit bottom plate for coupler, Resin bush for bottom plate (RDB-B)	P149,15
		RD-05	300/450/600/900	Duct(0.5m)	Set	Bottom plate, Resin bush for bottom plate(RDB-B)	P149
				Fittings	Not set	Bottom plate, Bottom plate for coupler for retrofit attachmen(RJB), Resin bush for bottom plate(RDB-B), Stiffening plate	P149,15
Bottom	In advance	RD、RD-1	300/450/600/900	-	-	Bottom net (RNB), Resin bush for bottom plate(RDB-B)	P155
net	Retrofit attachment	RD-05	300/450/600/900	-	_	Bottom net (RNB), Resin bush for bottom plate(RDB-B)	P155

## Other parts

#### Table of contents


3.7.1	RXH cover reinforcing plate	65
3.7.2	RSK RD duct partitioning bracket for H type	65
3.7.3	RDK RD strut set ·····	66
3.7.4	REC end cap	66
3.7.5	RPH PD supporting bracket ·····	67
3.7.6	RDS caution sticker	67


## **RXH** cover reinforcing plate

This is used for reinforcing the 900/900H size duct end. Use this when connecting with chamber box CB etc.

Note • This is standardly supplied with RX/RF 900/900H type.


With RCF/RCI/RCO 900/900H type, a different-shape cover guide or cover reinforcing plate is standardly supplied.






## **RSK RD duct partitioning bracket for H type**


This is the insulation compression preventing bracket for the polyphyletic ducting system. This is of dedicated use for the H type duct of 2m and 1m.






#### **RDK RD strut set** 3.7.3


This is used as the support of piping in hanging from the ceiling (with the cover of duct facing downward). This can be attached to the RD duct 300 to 600H of 2m or 1m.





## **REC** end cap


This is the plate to cover the hole at the end of duct.




## **RPH PD supporting bracket**

This is the bracket to support the duct branched from the RD duct (SLIMDUCT PD).

- X This does not support or fix piping.
- For supporting piping, use commercially available supporting brackets etc. as necessary.
- \* In the duct base of RD duct, several holes (24 holes for 2m) are prepared for attaching bolts, into which the W3/8 or M10 bolts





## **RDS** caution sticker

It is used as a reminder not to use the duct (except walkway type) as a passageway or step.

- Note Remove dusts and dirt from the surface before putting
  - Once a sticker is removed, its adherence deteriorates and it becomes difficult to put it on again.
  - · Store it in a dry place away from direct sunlight.



Design

# Installation

## 4 Installation procedure

How to proceed installationP70Pipe shaft and wall penetrationP71 to P81Mounting bracketP82 to P96RD duct (straight pipe)P97 to P100ConnectionP101 to P118FittingsP119 to P145Bottom plateP146 to P155OthersP156 to P160

Installatio

w to proceed

How to p install

Pipe shaft and wall penetration

lounting brack

uct (straight |

onnection

ittings


ottom plate

iers

4.1 How to proceed installation

## 4.1.1 How to proceed installation

Proceed the installation by following the procedures as shown below.



• 4.1.1 How to proceed installation

4.1.2 Tools for installation

## Tools for installation

In the SLIMDUCT RD installation, the following tools are required for each process.

General installation	Fixing separately sold strut (in hanging from the ceiling etc.)	Cutting duct
Phillips-head screw driver No.3     Wrench No.17 (for M10, W3/8)     Wrench No.10 (for M6)	Wrench No.10 (for M6)	<ul> <li>For highly corrosion-resistant hot-dip galvanized steel sheet</li> <li>High-speed cutter</li> <li>Sander etc.</li> <li>For stainless steel sheet</li> <li>Plasma cutter etc.</li> </ul>
Fixing mounting bracket	Wall penetration	Branching
Anchor (W3/8) + Drill etc.     Form + Mortar etc.	Drill     Anchor     Mortar     Calking compound     Sandpaper etc.	Hacksaw     High-speed cutter

Note For tightening the mounting bolts, be sure to use the Phillips-head screw driver No.3. (The tightening torque is to be 5N-m.)

## 4.2 Pipe shaft and wall penetration

Table of contents	4.2.1	List of installation methods	71
		RWP wall flange ·····	
	4.2.3	RSP/RSPR wall sleeve ·····	73
	4.2.4	RSB cut-off wall plate	75
	4.2.5	RSPC water shut-off plate protection cover	76
	4.2.6	CB chamber box ·····	77


## 4.2.1 List of installation methods


Water shut-off treatment is required for outdoor use.


There are the following penetration methods in which the water shut-off treatment is considered.


Note The explanation on the installation method below is just an example. Follow the instruction by the supervisor on site for details.


<Figure 4.2.1-1> Installation example (Pipe shaft)











<Table 4.2.1-1>

			Required part (just for each example)					
Duct size	Installation example	Explained in	Wall flange RWP	45° vertical ell RCF	90° vertical ell RC/RCI	Wall sleeve RSP	cut-off wall plate RSB	Chamber box CB
150	Α	P.72	0	0	_	_	_	_
300′300H	В	P.73	0	0	_	O *1	-	_
450、450H 600、600H	C	P.75	0	0	_	_	0	_
900,900H	В	P.73	0	0	_	O *1	_	_
	D	P.77	_	_	_	_	_	0
300~900 300H~900H	8	P.80	_	_	_	_	_	0
	E	P.81	_	_	0	_	_	0
All sizes	G	_	0	-	-	_	-	(self-making) *2

wall pene

Mounting bra

raight pipe)

nection Duct

ittings

## 4.2.2 RWP wall flange

Duct and fittings (some 900 size products excluded) can be connected.

This can be used in combination with the cut-off wall plate RSR or wall slee


This can be used in combination with the cut-off wall plate RSB or wall sleeve RSP.

\* Also check the Design section before performing installation.

D Barcode or downloading ne specification rawing



#### 4.2.2-1 Product configuration



<Table 4.2.2-1.1> Set contents


	Size	Upper part	Lower part	Set bolt
	150	1	1	6
	300/300H	1	1	6
	450/450H	1	1	6
	600/600H	1	1	6
	900/900H	1	1	16


<Table 4.2.2-1.2> Bolt specification

Bolt specification	Material
⊕ countersunk	
tapping bolt	SUS
M6×45L	


#### 4.2.2-2 Installation of RWP

1 Check to see if the mounting holes are ready or anchors have been installed.






## 2 After piping, set the cover of RD duct, and attach the RWP upper part.



## Finally, perform the water shut-off treatment as necessary.



## 4.2.3 RSP/RSPR wall sleeve

This is the wall sleeve for the pipe takeout part.

4.2 Pipe shaft and wall penetration

This is used in combination with the wall flange RWP.


Duct and fittings (some 900 size products excluded) can be connected.

\* Also check the Design section before performing installation.

2D Barcode for downloading the specification drawing



## 2.3-1 Product configuration



<Table 4.2.3-1.1> **Set contents** 

Size	Main unit	Set bolt
300/300H	1	2
450/450H	1	2
600/600H	1	2
900/900H	1	4


<Table 4.2.3-1.2> Bolt specification

Bolt specification	Material
⊕ pan head tapping bolt M5×25L	SUS

#### 4.2.3-2 Installation of RSP


1 Check that opening the mounting hole or driving the anchor is complete.

Reference [3.2.3] Installation of RSP wall sleeve




2 Bolt at two positions, one in the upper center of the wall sleeve, and the other in the lower center of the wall sleeve.


% For 900/900H size, bolt at two positions in each of the upper and lower center of the wall sleeve (four positions in total)



3 Attach the lower part of wall flange, attach the lower part of vertical ell and the lower part of duct, perform piping, and then attach each upper part of them.



4 Apply caulking at the top, right, and left sides of wall sleeve and wall flange respectively as shown in the figure.




## **RSB** cut-off wall plate

Perform the water shut-off treatment by using the cut-off wall plate (RSB), the wall flange (RWP), and the 45° vertical ell (RCF) in combination. The cut-off wall plate is used by being embedded in the body.


\* Also check the Design section before performing installation.

#### 4.2.4-1 Product configuration




#### 4.2.4-2 Installation of RSB


**1** Embed the cut-off wall plate in the body of pipe takeout part.




2 Perform drilling for the M6×45L tapping bolt, or drive the M6 anchor for attaching the wall flange as shown in the figure.



3 Attach the lower part of wall flange, attach the lower part of vertical ell and the lower part of duct, perform piping, and then attach each upper part of them.



4 Finally, perform the caulking treatment of each part.




## Water shut-off plate protection cover

To protect the caulking of the water shut-off plate from ultraviolet rays, install a water shut-off plate protection cover.



## Product configuration



Size	Frame	Cover	SEMS⊕ hex M6 × 15L	Cross recessed head tapping screws $\phi$ 5 × 25L
300	1	1	4	5
450	1	1	4	7
600	1	1	4	7
900	1	1	4	7

• 4.2.5 Water shut-off plate protection cover [Installation]


<Table4.2.5-1.2> Bolt specifications

<Table 4.2.5-1.1> Set contents


item	Specifications	Material
Screws for mounting frame	Cross recessed head tapping screws $\phi 5 \times 25L$	SUS
Bolt for fixing Cover	SEMS⊕ hex M6 × 15L	SUS

#### 4.2.5-2 Example of RSPC installation


Using the supplied tapping screws, mount the frame on the wall face (recommended hole diameter =  $\phi 4.3$  mm), leaving a gap of 15 mm in the height and width from the mounting position of the water shut-off plate.



2 Fit the 45-degree bend (inside) of the cover top into the 45-degree bend of the frame top for temporary placement of the cover.



3 After the cover is temporarily placed, secure the cover to the frame using SEMS ⊕ hex M6 x 15L screws (4 pieces), which are included in the package.




## **CB** chamber box

The cover can be removed without cutting the caulking.

- \*The chamber box (CB) is a product of special specifications with alteration of materials and dimensions, etc. (a separate meeting required for the price
- \*Check instructions on the [Design] page before installation.




## 4.2.6-1 Product configuration




#### <Table 4.2.6-1.1 > Bolt specifications

Size	Specifications	Material	Quantity
CB-300(H)			
CB-450(H)	Sems ⊕		24
CB-600(H)	hex bolt	SUS	24
CB-900(H)-A	M6×15L	303	
CB-900(H)-B			25
CB-900(H)-C			25
Common	Flange nut M6	SUS	4




#### 4.2.6-2 Example of CB Assembly <front exit>


■ Prepare an opening as shown in the figure below.




2 Install W3/8 anchor bolts with the dimensions indicated in the figure below.



Attach the frame at the opening using W3/8 hex bolts.




4 Attach the side plates to the frame using the supplied sems  $\oplus$  hex bolts.




Insert the bottom plate A from the front and attach it to the side plates using the supplied sems 


hex bolts.



 $\fill \fill \fil$ 




Attach the duct to the front plate B using the supplied sems  $\oplus$  hex bolts and flange nuts, and then install the piping.




Attach the front plate A to the side plate using the supplied sems  $\oplus$  hex bolts.




• Loosen the screws, make sure that the front plate A is placed on top of the front plate B as shown in the enlarged figure, and tighten the screws back together.




9 Attach the duct cover.



Attach the top plate to the side plates using the supplied sems  $\oplus$  hex bolts.



Apply caulking or putty in the gap between the wall surface and the frame and side plate for waterproofing.




Installation

How to proceed installation


4.2.6-3 Example of CB Assembly <bottom exit (wall)>

For the installation procedure of  $1\sim4$  perform assembly in the same manner as described in 4.2.6-2 <front exit>.


Insert the bottom plate C from the front and attach it to the side plates using the supplied sems ⊕ hex bolts.




Insert the bottom plate B from the front and attach it to the side plates using the supplied sems  $\oplus$  hex bolts.




Attach the front plate C to the side plates and the bottom plate B using the supplied sems ⊕ hex bolts.




Attach the duct to the bottom plate C using the supplied sems ⊕ hex bolts and flange nuts, and then install the piping.



8 Attach the duct cover.



 $\blacksquare$  Attach the top plate to the side plates using the supplied sems  $\oplus$  hex bolts.



## 4.2.6-4 Example of CB Assembly <bottom exit (suspended)>

For the installation procedure of  $\boxed{1}\sim \boxed{4}$  perform assembly in the same manner as described in 4.2.6-2 <front exit>.

Insert the bottom plate E from the front and attach it to the side plates using the supplied sems ⊕ hex bolts.


To directly connect to RCI-900 (H), use "CBB-900 (H)-RCI," which is sold separately.


When connecting the RCI directly, adjust the RCI mounting bracket to have the top surface of the RCI and the bottom surface of the CB side plate at the same height, and temporarily place it to make sure that RCI stays inside the CB side plate. After this, install the bottom plate, which is sold separately, to the side plate, using the supplied sems ⊕ hex bolts.

Pipe shaft and wall penetration


6 Attach the duct to the bottom plate E using the supplied sems ⊕ hex bolts and flange nuts, and then install the piping.

Note Make sure that the weight of the RD duct is not applied to the chamber box when connecting the RD duct.







Insert the bottom plate D from the front and attach it to the side plates using the supplied sems  $\oplus$  hex bolts.



8 Attach the duct cover.





For the installation procedure of  $\bigcirc$  ~  $\bigcirc$  perform assembly in the same manner as described in 4.2.6-3 <br/>bottom exit (wall)>.


Installation


## Mounting bracket


Table of

4.3.1	List of parts for the mounting bracket
4.3.2	RZ (RZM+RZB) RD mounting bracket (for 300 to 900)83
4.3.3	RZ-150, RZW RD mounting bracket (for 150)
4.3.4	RZC bracket attachment plate for vertical ell
4.3.5	RZY mounting bracket guide for duplex mounting
4.3.6	RDY pipe support base ************************************
4.3.7	RZH RD mounting base reinforcing plate89
4.3.8	FL-B-Z cross-lock B type (for outdoor use) 90
4.3.9	RBK-B auxiliary bracket for strut 90
4.3.10	RBK-A auxiliary bracket for duct base
4.3.11	RKT bracket for fixing to shaped steel 92
4.3.12	RKTW RD walkway fixing bracket for shaped steel92
	RCT RD bracket for fixing channel
4.3.14	CR recycrock (multipurpose support base)95
4.3.15	PB plastic base96

## List of parts for the mounting bracket



































## RZ (RZM+RZB) RD mounting bracket (for 300 to 900)

This is the mounting bracket for RD (300 to 900).

By combining the gate (RZM) and leg (RZB), this can be used as the mounting bracket of various height.

\* Also check the Design section before performing installation.






## **Product configuration**

#### 300 to 900 type is of the combination of gate and leg.

**Reference** [3.4.4] Table for selecting a mounting bracket other than 150 type (for installation on the floor)



#### <Table 4.3.2-1.1> Set contents

Туре	Gate-shaped bracket	Base	Bolt set for assembling mounting bracket	Bolt set for attaching duct
RZB	0	2	4	0
RZM	1	0	0	2

<Table 4.3.2-1.2> Bolt set specifications

	ltem	Specifications	Material	Quantity
		Cup head square neck bolt M8×19L	SUS	1
	Bolt set for	Hex nut M8	SUS	1
	assembling mounting bracket	Flat washer M8	SUS	2
		Spring washer M8	SUS	1
	Dalt and for	Hex bolt W3/8×L25	SUS	1
,	Bolt set for attaching duct	Hex nut W3/8	SUS	1
	attaching duct	Flat washer W3/8	SUS	1


## Example of assembling and attaching RZ <300 to 900>

■ Attach RZB (RD mounting bracket leg) to RZM (RD mounting bracket gate).

※ Bolt tightening torque: 19.6N⋅m

\* If Recycrock CR etc. is to be used, set it after this procedure

Reference [3.4.19] Fixing (to floor), Recycrock CR





<Figure 4.3.2-2.2> RD duct coupler-free connection

RZ

Installation


2 Attach the duct etc. to the mounting bracket.





### When attaching RZ to the wall surface (for the combination of RZM-S + RZB-S only)

- 1. Attach RZ to the wall surface by using anchors etc.
  - \* For the type and specifications of the anchor bolt etc., follow the instruction by the supervisor on site.
- 2. Attach the duct etc. to RZ.
- When there are multiple mounting holes, use the outermost two holes.
- When attaching the duct and parts, fix the duct by using the supplied bolt set and the commercially available spring washer (W3/8 SUS) in addition.



## RZ-150, RZW RD mounting bracket (for 150)

This is the mounting bracket for RD (for 150).


There are the following two types: RZ-150 for to be fixed on the floor, and RZW-150 for to be fixed on the wall surface.

\* Also check the Design section before performing installation





## Product configuration



#### <Table 4.3.3-1.1> Set contents

Туре	Gate-shaped bracket	Base	Bolt set for assembling mounting bracket	Bolt set for attaching duct
RZ-150	1	1	2	1
RZW-150	1	2	2	2


<Table 4.3.3-1.2> **Bolt set specifications** 

Item	Specifications	Material	Quantity
	Hex bolt W3/8×L25	SUS	1
Bolt set for	Hex nut W3/8	SUS	1
assembling mounting bracket	Flat washer W3/8	SUS	2
mounting bracket	Spring washer W3/8	SUS	1
Bolt set for attaching duct	Hex bolt W3/8×L25	SUS	1
	Hex nut W3/8	SUS	1
	Flat washer W3/8	SUS	1


## 4.3.3-2 Example of assembling and attaching RZ-150

1 Attach the leg (base) to the upper part.

※ Bolt tightening torque: 19.6N⋅m




2 Attach the duct etc. to the mounting bracket.





## 4.3.3-3 Example of assembling and attaching RZW

- 1 Attach the leg (base) to the gate (upper part).
  - ※ Bolt tightening torque: 19.6N⋅m



- 2 Attach RZW to the wall surface by using anchor bolts etc.
  - \* For the type and specifications of the anchor bolt etc., follow the instruction by the supervisor on site.
- 3 Attach the duct etc. to RZW.






## RZC bracket attachment plate for vertical ell

This is the fixing plate to attach the mounting bracket to the duct or fittings on an elevation surface or sloping slope (inclined at 45°).



\* Also check the Design section before performing installation.

## Product configuration



<Table 4.3.4-1.1> Set contents

Туре	Quantity
RZC main unit	1
Bolt set for attaching duct	2


<Table 4.3.4-1.2> Bolt set specifications

Item	Specifications	Material	Quantity
	Hex bolt W3/8×L25	SUS	1
Bolt set for attaching duct	Hex nut W3/8	SUS	1
	Flat washer W3/8	SUS	1

#### 4.3.4-2 Installation of RZC


#### 1 Attach RZC to the mounting bracket.


Mounting bolts are supplied with the mounting



2 Attach the target object to RZC.

\* Use the mounting holes which fit the target object.






## RZY mounting bracket guide for duplex mounting

This is used for duplex mounting of the RD duct.



\* Also check the Design section before performing installation.

### Product configuration



<	able	4.3.5-1.1>	Set	contents	


Туре	Quantity
RZY main unit (gate)	1
Bolt set for assembling the mounting bracket	2
Bolt set for attaching duct	2

#### <Table 4.3.5-1.2> Bolt set specifications

Item	Specifications	Material	Quantity
	Cup head square neck bolt M8×19L	SUS	1
Bolt set for	Hex nut M8	SUS	1
assembling mounting bracket	Flat washer M8	SUS	2
mounting bracket	Spring washer M8	SUS	1
Bolt set for	Hex bolt W3/8×L25	SUS	1
attaching duct	Hex nut W3/8	SUS	1
attaoning adot	Flat washer W3/8	SUS	1


#### 4.3.5-2 Installation of RZY

1 Attach RZY to the RZB RD duct mounting bracket leg.




#### 2 Attach the RD duct base.

\* Cannot be used for the connection part.



3 Perform piping of the lower stage, set the cover, and attach the RZM RD mounting bracket gate. Then, perform the procedures in the same way as RZ.

Reference [4.3.2] RZ (RZM+RZB) RD mounting bracket




## **RDY** pipe support base

This is a part for attaching the conduit etc. to the RD mounting bracket. The rail of 20mm in width and holes of  $\phi$ 14 are equipped to attach the conduit supporting bracket.

\* Also check the Design section before performing installation.



## Product configuration



<Table 4.3.6-1.1> Set contents

Туре	Quantity
Gate (pipe support base)	2
Strut	1
Bolt set for attaching strut	2


<Table 4.3.6-1.2> Bolt set specifications

	Item	Specifications	Material	Quantity
	Balt ant for	Hex bolt M8×12L	SUS	1
Bolt set for attaching stru		Hex nut M8	SUS	1
	attaching strut	Flat washer M8	SUS	1

#### 4.3.6-2 Example of assembling and attaching RDY


Attach the gate to the RD mounting bracket leg (RZB)

\* The mounting bolts are not supplied. Attach it at the same time when attaching RZM.



#### 2 Attach the strut to the gate.


%For attaching a commercially available supporting brackets, check the instruction manual of its manufacturer.



## **RZH RD** mounting base reinforcing plate

Attach RD mounting base reinforcing plate (RZH) to the RD mounting bracket leg.

#### 4.3.7-1 Installation of RDH



#### <Table 4.3.7-1.1> Set contents

Item	Quantity	
Mounting bracket reinforcing plate	1	
Bolt set for mounting the reinforcing plate	2	

<table4.3.7-1.2> <b>Bo</b>l</table4.3.7-1.2>	t set specifications

Items	Specifications	Material	Quantity	
Bolt set for mounting the einforcing plate	Cup head square neck bolt M8 x L19	SUS	1	
	Hex nut M8	SUS	1	
	Flat washer M8	SUS	1	
	Spring washer M8	SUS	1	



<Figure 4.3.8-1.1>


(for outdoor use)

Warning

FL-B-Z cross-lock B type


M6 hex × 20L SUS · M6 spring washer SUS · M6 flat washer SUS \* The cover bolt supplied with the product cannot be used. • For installation on the wall surface (suspended from the wall

- surface), the following treatment is required. Be sure to attach the bottom plate. Otherwise, wind pressure is applied
- from inside the duct, causing a damage to the duct. • For fixing the duct to the mounting bracket, use a commercially available "Stainless W3/8 spring washer". (RZW-150 is excluded)
- \* Use it in addition to the bolt set supplied with the product for fixing.



Although SLIMDUCT RD can be installed on the wall surface, there are some restrictions.

For installation on the wall surface, a treatment to prevent loosening of bolts is required.



## **RBK-B** auxiliary bracket for strut

This is the auxiliary bracket to be used in the installation directly on the wall surface. For the open type duct (RD-450H, 600H, 900H of 2m and 1m). use the auxiliary bracket for duct base RBK-A.

FL-B-Z cross-lock B type (for outdoor use)

Attach the cross lock B type (outdoor specification) to the RD mounting frame.

Product configuration · Installation of FL-B-Z


for do the specifica



FL-B-Z

\* Also check the Design section before performing installation.

### Product configuration





ltem	Material	Quantity
RBK-B (inner diameter $\phi$ 11×L22)		
Flat Washer M10	SUS	1
Spring washer M10		

## 4.3.9-2 Installation of RBK-B auxiliary bracket for strut

As shown in the figure, insert the commercially available anchor bolt (W3/8 or M10) into the bracket, and attach them to the same position as attaching the mounting bracket. For the position for attachment, see pages of each part.

\* The anchor bolt specifications are to differ depending on the wall structure and load. Follow the instruction by the supervisor on site to select the appropriate one.





## **RBK-A** auxiliary bracket for duct base


This is the auxiliary bracket to be used in the installation of the open type duct (RD-450H, 600H, 900H of 2m and 1m) on the wall surface.

\* This can also be used for the general type 2m and 1m duct (excluding 150 type).

# RKB-A

### Product configuration

\* Also check the Design section before performing installation.



Item	Material	Quantity
RBK-A	ZAM	1
Spring washer M10	SUS	'

<Table 4.3.10-1.1> RBK-A Set contents

<Table 4.3.10-1.2> RBK-A-SUS Set contents Spring washer M10


#### 4.3.10-2 Installation of RBK-A auxiliary bracket for duct base


#### Installation directly on the wall surface

As shown in the figure, insert the commercially available anchor bolt (W3/8 or M10) into the bracket, and attach them to the \$\phi12\$ hole of the duct

See the figure for the position for attachment.

\* The anchor bolt specifications are to differ depending on the wall structure and load. Follow the instruction by the supervisor on site to select the







# **←**① ② **→** . . . . .


#### In the installation suspended from the wall surface

As shown in the figure, insert the hex bolt (supplied with the mounting bracket) into the bracket, and set the mounting bracket at the  $\phi$ 12 hole of the duct base. See the figure for the position for attachment.

\* Drilling is required on the bottom plate for the attachment of RBK-A. 







Installation

How to procee installation

## **RKT** bracket for fixing to shaped steel


When fixing the RD duct to the shaped steel, fix the RD duct base to the shaped steel by using the bracket for fixing RD to shaped steel RKT.

\* Also check the Design section before performing installation.

for dow



#### Product configuration




#### <Table 4.3.11-1.1> Set contents

ltem	Material (surface treatment)	Quantity
Upper bracket		
Lower bracket	0.00	
Cup head square neck bolt M6×35L	SPHC Dacrotizing	1
Spring washer M6		
Hex nut M6		

#### 4.3.11-2 Installation of RKT

1 Set the lower bracket so that its longer fitting surface contacts the RD duct base, and its shorter fitting surface contacts the shaped steel.



3 Tighten the nut from under the lower


X Tightening torque 5.9N·m (60 kg·cm)


#### Note

bracket.

- This cannot be used in the vertical installation on the wall surface etc.
- This cannot be used for fixing the RD duct for walkway.
- · Do not use this in a position where vibration or shaking occurs. · Secure fixing cannot be attained for other than the scope of
- application of shaped steel.
- · Securely tighten the bolt with the designated torque.

2 Set the upper bracket so that its protrusion does not ride on the RD duct base or shaped steel.





#### RKTW RD walkway fixing bracket for shaped steel 4.3.12


When fixing the duct walkway to shaped steel, fix the RD duct base to shaped steel using RKTW, the RD walkway fixing bracket for shaped steel.

\* Check instructions on the [Design] page before installation.

Applicable shaped steel H steel section: Flange thickness 7 to 13 mm Channel steel: 75 x 40, 100 x 50, 125 x 65, 150 x 75



## 4.3.12-1 Product configuration



<Table 4.3.12-1.1> **Set contents** 

Item	Material	Quantity
Type A	Highly corrosion-resistant steel sheet	2
Type B	steel sheet	2

#### 4.3.12-2 Example of RKTW assembly


Items to be checked before installation

For attachment to shaped steel, mount the item in the direction of the arrow engraved on the bracket.

1 Place the bracket (type A) with its engraved marking surface along the bottom of the RD duct base and set it in the direction of the arrow making sure that the washer is applied to the duct


%For type B, it is the side that does not have the engraved marking

· Make sure that the bracket is in contact with the RD duct base without any gap.



2 Lift the duct base 3 mm or more from the installation surface of the shaped steel and slide the bracket.


• Insert the bracket until its bolt thread hits the flange of the shaped steel.





I Tighten the bolts and it is complete.


※Tightening torque: 42 N⋅m (428 kgf⋅cm)


- - Do not reuse the product after it has been used.
  - This cannot be used for vertical parts.
  - This cannot be attached to either end (joint) of the
  - Insert the bracket to the shaped steel in the direction of the arrow engraved on the product.












Installation

## RCT RD bracket for fixing channel

To secure an RD duct to channel, use an RD bracket for fixing channel RCT to secure the RD duct base to the channel.

#### 4.3.13-1 RCT products configurations and installation examples

#### Tighten the nut from under the lower






- It can be used only when the RD duct and the channel are intersecting each other
- It cannot be used for vertical installation such as on the wall face.
- · It cannot be used for securing RD ducts for walkways.

## SHBN-S-Z bolt hanging bracket For outdoor use (equivalent to HDZT49)

To support and secure the channel on the steel material, SHBN-S-Z bolt hanging bracket (for outdoor use) can also be used.




#### **CR Recycrock** (multipurpose support base)

This is the multipurpose support base which is friendly to the global environment using recycled material.

There are the following types: CR-W 3/8 rail type which can also be used as the mounting bracket for RD, CR-A anchor base type, CR-D which can be used to support conduit, and CR-H hanger rail


\* Also check the Design section before performing installation.

#### Product configuration




#### 4.3.13-2 Example of assembling and attaching CR

1 CR-W··· Set the nut or bolt in the rail, and attach the mounting bracket etc.



## **2** CR-A··· Attach the mounting bracket <a href="Figure 4.3.14-2.2"><a href="Figure 4. and fix it with the bolt.

\* Use a bolt of 25mm in length (SUS).



## PB plastic base

This is the light-weight plastic base with excellent weatherability.


It is not necessary to prepare the frame or remove it after hardened, enabling large reduction of the working hours.


\* Also check the Design section before performing installation.





## Product configuration







#### 4.3.15-2 Example of assembling and attaching PB

■ Set Plabase by aligning it with the mounting bracket.

Since Plabase has the positioning mark, align the mark and positioning line for beautiful finish.




2 Assemble Plabase. There are two methods of assembling Plabase: coupling by sliding parts in the vertical direction, and coupling by fitting parts in the horizontal direction.



3 Finally fill mortar.

After pouring and filling mortar, sufficiently perform the mortar butt work. If too much water is contained, a large shrinkage may occur and the finished surface may not become flat. For the blending ratio, refer to <Figure 4.3.15-2.3>.



## RD duct (straight pipe)

4.4 RD duct (straight pipe)

There are two types of RD duct: Standard type and Walkway type which can be used as the walkway in the maintenance work etc.

Also, there are two connection methods: Connection using coupler parts and coupler-free connection without using coupler parts. Be sure to check "3.5 RD duct [Design]" before installation.

Table of contents

4.4.1	RD duct ·····	97
4.4.2	RDW walkway type duct	98
4.4.3	Example of RD/RDW ·····	99
4.4.4	RD/RDW coupler-free connection <simple assembly="" method=""></simple>	100

## **RD** duct

Standard-type straight pipe (straight duct).

Note that the installation details are different between for the standard type and for the walkway type.

\* Also check the Design section before performing installation.



### Product configuration




Table 1 1 1-1 1> Set details


<table 4.4<="" th=""><th>1.1-1</th><th>1.1&gt;</th><th>set de</th><th>tails</th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th>&lt;</th><th>&lt; I</th><th></th></table>	1.1-1	1.1>	set de	tails								<	< I	
			Bolt		Length of duct									
Size	Cover	Base	set for	2	2m 1m 0.5m		0.5m		0.	0.3m				
			connection	Cover bolt	Cover reinforcing									
				DOLL	plate		plate		plate		plate	1		
150	1	1	0	4	0	2	0	2	0	2	0	Ι'		-
300/300H	1	1	4	4	0	2	0	2	0	2	0			
450/450H	1	1	4	4	0	2	0	2	0	2	0			
600/600H	1	1	4	4	2	2	2	2	2	2	1			
900/900H	1	1	4	4	3	2	2	2	2	2	2			

<Table 4.4.1-1.2> Bolt specification

Item	Specifications	Material	
Bolt set	Sems ⊕ hex M6×15L	SUS	
for connection	Flange nut M6	SUS	
Cover bolt	Sems ⊕ hex M6×15L	SUS	

#### 4.4.1-2 Position to attach the cover reinforcing plate

#### <Table 4.4.1-2.1> Position to attach the cover reinforcing plate



## **RDW** walkway type


Walkway-type straight pipe (straight duct).

Note that the installation details are different between for the standard type and for the walkway type.



\* Also check the Design section before performing installation.

## 4.4.2-1 Product configuration



<Table 4.4.2-1.1> Set details

			Bolt		Zm         1m         0.5m           Cover bolt         Cover reinforcing plate         Cover reinforcing plate         Cover reinforcing plate         Cover reinforcing plate						
Size	Cover		set for								0.3m
			connection	Cover bolt	Cover reinforcing plate	Cover bolt	Cover reinforcing plate	Cover bolt	Cover reinforcing plate	Cover bolt	Cover reinforcing plate
300/300H	1	1	4	4	3	2	2	2	2	2	2
450/450H	1	1	4	4	4	2	3	2	2	2	2
600/600H	1	1	4	4	5	2	4	2	3	2	2
900/900H	1	1	4	4	5	2	4	2	3	2	2

<Table 4.4.2-1.2> Bolt specification

Item	Specifications	Material
Bolt set	Sems ⊕ hex M6×15L	SUS
for connection	Flange nut M6	SUS
Cover bolt	Sems ⊕ hex M6×15L	SUS


## Position to attach the cover reinforcing plate

#### <Table 4.4.2-2.1> Position to attach the cover reinforcing plate


	2m-duct	1m-duct	0.5m-duct	0.3m-duct
300(H)size	875 125	122	125	105
450(H)size	575 [15]	325 125	125	105
600(H)size	575 125	325 125	125	105
900(H)size	575 125	325 [25]	125	105


## **Example of RD/RDW assembly**

1 Fit ducts each other so that their duct base ends overlaps by 20mm, and fix the overlapped part of the bottom of duct base to the mounting bracket by using W3/8 hex bolts.




2 Fix the side surface of overlapped part of the duct base ends with bolts.







3 Perform piping, and then attach each reinforcing plate. For the attachment position, see "Position to attach the cover reinforcing plate".


The cover reinforcing plate for the connection part is to be attached for 600 to 900H with coupler-free connection or connection using the free coupler S/H type.






4 Set the cover with overlap by 20mm. (At the part connected with the flat ell, overlap the covers so that the cover of the straight duct comes over the other for beautiful finish.)






## RD/RDW coupler-free connection (simple assembly method)

Place duct A on the mounting bracket, and fix its beginning end of duct A to the mounting bracket. For the end of duct A to be connected to another duct, do not fix to the mounting bracket but just place it temporarily.




2 For the end of duct A to be connected to another duct, align "notch", "round hole", and "hole of the mounting bracket".

<simple assembly method>




3 Insert the bolt into the round hole of the duct base that is placed temporarily on the mounting bracket, and temporarily tighten the bolt with the nut.




4 Temporarily place the beginning end of duct B on the mounting bracket of the side of end of duct A to be connected to another duct.

Insert the (notch) of the beginning end of duct B into between the duct A duct base and the mounting bracket (bolt-attaching position).




<Figure 4.4.4-5> Raise duct A
Slide duct B, and fit the (notch) of

5 Finely align "duct A", "duct B", and "hole of the mounting bracket" by sliding duct B.




6 After aligning "duct A", "duct B", and "hole of the mounting bracket", attach the bolt and finally fasten the nuts at both sides.



7 Assembly completed








## Connection


e of	4.5.1	Connection methods and part list	101
ents	4.5.2	Coupler-free connection ·····	102
	4.5.3	RSJ fixing coupler ·····	103
	4.5.4	RFJ free coupler ·····	105
	4.5.5	RSS sliding coupler ·····	108
	4.5.6	RR reducer (coupler type)	110
	4.5.7	RR reducer(plate type)	111
	4.5.8	RXR reducer for 900-type fittings	112
	4.5.9	RXJ coupler for 900(H)-type fittings	113
	4.5.10	RXSS/RXSSW box joint sliding coupler	114
	4.5.11	RCSS Sliding coupler for RCSS RCF-900 (H)-SUS	117


## **Connection methods and part list**


























at the connection part.

**Coupler-free connection** 


#### Example of assembly by coupler-free connection

This is the installation method to connect the RD ducts (excepting 150) and main fittings without using coupler parts.

This can be used for the installation on the floor and installation by hanging from the ceiling. \* Also check the Design section before performing installation.

1 Fit ducts each other so that their duct base ends overlaps by 20mm, and fix the overlapped part of the bottom of duct base to the mounting bracket by using Hex bolts W3/8.


Note If the mounting bracket cannot be set, change the installation method to that using coupler parts. ▶When fitting ducts each other, the straightness of ducts can be kept by switching the overlapping side (direction) alternately



• 4.5.2 Coupler-free connection

[ Installation ]


2 Fix the side surface of overlapped part of the duct base ends with bolts.




- 3 Perform piping, and then attach the cover reinforcing plate.
  - \* For attaching the cover reinforcing plate, see pages of each part.

The cover reinforcing plate for the connection part is to be attached in the 600 to 900H coupler-free connection or when the free coupler S/H type is used.

4 Set the cover with overlap by 20mm. (At the part connected with the flat ell, overlap the covers so that the cover of RD duct comes over the other for beautiful finish.)






## **RSJ** fixing coupler

This is the coupler used for connecting ducts or fittings (except for some 900 For the installation on the floor, it is also possible to set the mounting bracket

\* Also check the Design section before performing installation.

\* For the installation on the wall surface, also check [2.3.3] and [2.3.4] Conditions for installation on the wall surface.

#### Product configuration



#### <Table 4.5.3-1.1> Set contents


Size	Cover (outer)	Cover (inner)	Base	Bolt for cover	Bolt set for base	Mounting bracket fixing plate
150	1	1	2	2	4	1
300/300H						
450/450H	1		2	2		2
600/600H	'	'	(one each for the right and left)	3	0	2
900/900H			(Unic cauli fur file figlit difu left)			


#### <Table 4.5.3-1.2> Bolt specification

	-	
Item	Specifications	Material
Bolt for cover	Sems ⊕ hex bolt M6 × 20L	SUS
Bolt set	Sems ⊕ hex bolt M6 × 15L	SUS
for base	Flange nut M6	SUS

#### Installation of RSJ


■ Make a 20mm clearance at the duct connection part, and attach the fixing coupler (base part).





When attaching the mounting bracket (RZ) to the connection part, fix the duct to the mounting bracket by using the mounting bracket fixing plate (mounting bracket fixing bracket for 150 size).


The mounting bracket fixing plate is not needed when the mounting bracket is not attached to the connection part.



• 4.5.3 RSJ fixing coupler

[ Installation ]


Perform piping, and then insert the inner cover between the inner base and the upper part of duct base. For 300 to 900H, fit the nut part of the inner cover in the guide groove of coupler.



4 Finally set the cover of duct, and attach the outer cover.

#### Note

For installation on the wall, it is necessary to take measures to prevent bolts from loosening. For details, see [2.3] Installation method (on the wall surface).



## 4.5.4 RFJ free coupler

This is the coupler to connect a cut duct and other parts.


This can be used in the installation on the floor and installation directly on the wall surface.

\* Also check the Design section before performing installation.

※ For the installation on the wall surface, also check [2.3.3] and [2.3.4] Conditions for installation on the wall surface. 2D Barcode for downloading the specification drawing



### Product configuration



#### <Table 4.5.4-1.1> Set contents

Size	Outer Cover	Inner Cover	Outer base	Inner base	Bolt for cover	Bolt for base	Mounting bracket fixing plate
150	1	1	2	2	2	4	1
300/300H							
450/450H	0	0	2	,	0	4	0
600/600H	U	0	2	2		4	U
900/900H							

#### <Table 4.5.4-1.2> Bolt specification

ltem	Specifications	Material
Bolt for cover	Sems ⊕ hex M6 × 20L	SUS
Bolt for base	Sems ⊕ hex M6 × 15L	SUS


#### 4.5.4-2 Installation of RFJ (type A)


1 When cutting the duct base, cut so that at least two struts remain. Otherwise the cut one cannot be used.

However for the open type, cutting resulting in reduction of struts is not possible.

Cut the cover to be the same size as the duct. Cut the bottom plate to be shorter than the duct by 20mm.


2 Make a 20mm clearance at the duct connection part, and clamp and tighten the RD duct with the free coupler (base part).






3 When setting the mounting bracket (RZ) at the connection part, fix the duct to the mounting bracket by using the mounting bracket fixing bracket.

The mounting bracket fixing bracket is not needed when the mounting bracket is not set at the connection part.




Insert the inner cover between the inner base and the upper part of duct base.

For 300 to 900H, fit the nut part of the inner cover in the guide groove of coupler.




• 4.5.4 RFJ free coupler



5 Finally set the cover of duct, and attach the outer cover.

In the installation on the wall surface, treatment to prevent loosening of bolt is necessary. For details, check [2.3] Installation method (on the wall surface).



#### Notes on attachment

In connection to the vertical ell, connect the uncut side.

If attachment to the vertical ell is inevitable such as the case of lowering the position, attach it so that the cut side comes in the upper position.

For 150 type, the mounting bracket can be set only when it is connected to the duct. When connecting to the fittings, set the mounting bracket at the strut near the fittings.

#### 4.5.4-3 Installation of RFJ (type S/H)

When cutting the duct, cut so that at least two struts remain. Otherwise the cut one cannot be used.


However for the open type, cutting resulting in reduction of struts is not possible.


Cut the cover so that its length becomes longer than the duct base by 40mm. If holes for cover bolts do not remain, perform drilling at the required positions.

Also, when using the bottom plate, cut it so that its length becomes longer than the duct base by 40mm.

% For Steel sheet type, for the part where you performed cutting or processing work, perform the repair work by using the zinc rich paint (Zn-AL).


2 Make a 20mm clearance at the duct connection part, and clamp and tighten the RD duct with the free coupler (base part).





3 Perform piping, and then finally set the cover of duct.

※ For 600 to 900H, attach the cover reinforcing plate to the connection part.



#### Notes on attachment

The mounting base cannot be installed for the S/H type. Install mounting bases to the sub girders, etc. located before and after the S/H type.

For vertical installation, attach this so that the lid of the upper part comes on top.

For connection to an elevation surface corner, connect the end that is not cut.

For connection to an elevation surface corner such as when lowering the position, attach this so that the cut side comes to the bottom, and provide a hole for installing the mounting base on the elevation surface corner.

Installation

<Figure 4.5.5-2.3>

Hex bolt W3/8

Coupler-free connection

W3/8 flat washer W3/8 hex nut

Bottom plate of sliding couple

108

#### **RSS** sliding coupler 4.5.5

This is the connection length adjustable coupler.

This can be used when the clearance between ducts or fittings is 20mm to


 $\ensuremath{\,\%\,}$  900(H) size fittings is excluded.

\* Also check the Design section before performing installation.





### Product configuration



#### <Table 4.5.5-1.1> Set contents

Size	Cover (outer)	Cover (inner)	Base	Bottom plate	Stiffening plate	Bolt for cover	Bolt set for base	Bolt set for bottom plate	Bolt set for stiffening plate
300/300H									
450/450H	] ,		2		,	_	0	4	4
600/600H	· ·	'	(one each for the right and left)	'	4	3	0	4	4
900/900H	1								

#### <Table 4.5.5-1.2> Bolt specification

Item	Specifications	Material
Bolt for cover	Sems ⊕ hex M6 × 20L	SUS
Bolt set	Sems ⊕ hex M6 × 15L	SUS
for base	Flange nut M6	SUS
5	Sems ⊕ hex M6 × 15L	SUS
Bolt set for bottom plate	Hex nut M6	SUS
lor bottom plate	Flat washer M6	SUS
Bolt for stiffening plate	Sems ⊕ hex M6 × 20L	SUS


#### Installation of RSS

Attach or temporarily place the ducts or fittings, and check the dimension of level difference of the Pipe shaft takeout part (H) (level difference between the inner bottom surface of flange of the wall flange RWP and the bottom surface of duct), or check the distance between the ducts or fittings (L). Based on this value, select the appropriate sliding coupler.


	Unit-(mm)
Sliding coupler model number/item	Distance between ducts L
RSS-300-1/450-1/600-1/900-1	20 to 120
RSS-300-2/450-2/600-2/900-2	120 to 220
RSS-300-3/450-3/600-3/900-3	220 to 320
RSS-300H-1/450H-1/600H-1/900H-1	20 to 120
RSS-300H-2/450H-2/600H-2/900H-2	120 to 220
RSS-300H-3/450H-3/600H-3/900H-3	220 to 320

\* For the dimension of level difference, see [3.5] Fittings.

\* If the distance L exceeds 320mm, see [3.3.5] RSS sliding coupler.



2 Attach and fix the sliding coupler base to the base part of duct or fitings. Be sure to attach it so that the guide groove of sliding coupler base comes at the center of the clearance.



3 Attach the bottom plate of sliding coupler and the mounting bracket.


#### Notes on using the bottom plate of sliding coupler

The bottom plate of sliding coupler cannot be attached to a duct other than the straight duct of 2m and 1m, or a fitting other than the 45° vertical ell. If the bottom plate of sliding coupler needs to be attached inevitably, processing the bottom plate of sliding coupler is required. Also in this case, supporting the bottom plate by the mounting bracket

\*When using as the walkway, cutting is not allowed.



4 Perform piping, and then insert the sliding coupler cover inner bracket between the guide groove of coupler and the upper part of duct base.




Washer W3/8

Hex nut W3/8 Mounting bracket

fixing plate for elevation surface

5 Set the cover of duct, and then finally attach the sliding coupler cover outer bracket and the stiffening plate.

For installation on the wall, it is necessary to take measures to prevent bolts from loosening. For details, see [2.3] Installation method (on the wall surface).



This is the coupler for connecting different size parts.


This can be used in the installation on the floor and installation directly on the wall surface.

wall surface.

\*\* Also check the Design section before performing installation.

Also check the Design section before performing installation.
 For the installation on the wall surface, also check [2.3.3] and [2.3.4] Conditions for installation on the wall surface.

## 4.5.6-1 **Product configuration**



<table 4.5.6<="" th=""><th>-1.2&gt;</th><th>Set o</th><th>content</th><th>S</th></table>	-1.2>	Set o	content	S
Size	Cover	Cover	Base	

• 4.5.6 RR reducer (coupler type)

Size of larger side	Cover (outer)		Base (outer)	Bolt for cover	Bolt set for base		
300	1	1	2 *	2	4		
300H		1	1			3	
450/450H	1			2*	4	4	
600/600H	'   '		2	4	4		
900/900H				3			


\* one each for the right and left

#### <Table 4.5.6-1.2> Bolt specification

ltem	Specifications	Material
Bolt for cover	Sems ⊕ hex M6 × 20L	SUS
Bolt set	Sems ⊕ hex M6 × 15L	SUS
for base	Flange nut M6	SUS


## 4.5.6-2 Installation of RR (coupler type)

1 Set the mounting bracket at the hole (φ 12) in the duct base of larger size duct. Then, attach the reducer base to the duct base.



2 Attach and fix the smaller size duct to the reducer base.


Perform piping, and then fit the reducer inner cover in the guide groove of coupler.



**3** Finally set the cover of duct, and attach the different diameter outer cover.

#### Note

For installation on the wall, it is necessary to take measures to prevent bolts from loosening. For details, see [2.3] Installation method (on the wall surface).



## 4.5.7 RR reducer (plate type)

This is the coupler for connecting different size parts.


Since this is the coupler of duct-inserting type, the effective length of duct will become shorter by 20mm.

2D Barcode for downloading the specification drawing

 $\ensuremath{\mathbb{X}}$  Also check the Design section before performing installation.

\* For the installation on the wall surface, also check [2.3.3] and [2.3.4] Conditions for installation on the wall surface.

#### 4.5.7-1 Product configuration



<Table 4.5.7-1.1> Set contents

Cover	Guide	Bolt
1	2 (one each for the right and left)	8

<Table 4.5.7-1.2> Bolt specification

Item	Specifications	Material
Bolt	Sems ⊕ hex M6 × 15L	SUS

### 4.5.7-2 Installation of RR (plate type)

1 Fix the mounting bracket to the strut of duct.

Then, attach the reducer guide to the duct base (large) by using the supplied bolts.

#### Note

When fixing the mounting bracket to the duct base, fix it at between the strut of each duct and the connection part.

2 Fit the duct (small) into the reducer guide.


Attach the duct base (small) to the reducer guide by using the bolts and nuts supplied with the duct (small).


#### Note


For the height, the bottom line is to be aligned.

After the piping work is completed, set the cover of duct (small).

Finally, set the reducer cover to the duct base (large) and the reducer guide by using the supplied bolts.







Installati

How to proceed installation

Pipe shaft and wall penetration

straight pipe)

ection Du

Fittings

3ottom plate

Others

112

## RXR reducer for 900 (H) size fittings


This is the reducer dedicated for use with the 900(H) size fittings. Since this is the coupler of duct-inserting type, the effective length of duct will become shorter by 20mm.



\* Also check the Design section before performing installation.

\* For the installation on the wall surface, also check [2.3.3] and [2.3.4] Conditions for installation on the wall surface.

#### 4.5.8-1 Product configuration



<Table 4.5.8-1.1> Set contents

	Туре	Main unit
	TYPE I	2
	TYPE II	(one each for the right and left)
		1
	TYPE Ⅲ	'


We use the bolts supplied with

We use the bolts supplied the fittings for attachment.

#### Installation of RXR


■ Remove bolt from the fittings.

※ Positions (four positions)enclosed by ○




2 Fix RXR with bolts.

• 4.5.8 RXR reducer for




3 Fit in the duct, and fix it with bolts.

Bolts are supplied with the duct.



4 Perform piping, and then finally set the cover. For installation of the fittings, see pages of each fitting.



## RXJ coupler for 900 (H) size fittings


This is the coupler RXJ for connecting 900(H) size fittings each other except for RCF.

Note For the installational reason, some gap is formed.

\* Also check the Design section before performing installation.








<Table 4.5.9-1.1> Set contents

Size	Main unit
900/900H	2


#### 4.5.9-2 Installation of RXJ

Make the coupler parts of RX(W)s butt each other.



2 Connect the fittings (RX(W)s in this example) by fixing RXJs to the fittings from the both sides.

Note For the top surface of the connected box-type fittings, apply caulking or puttying for waterproofing.



RXSS/RXSSW box joint sliding coupler 4.5.10


> This installation is used to connect one box to another using the sliding coupler. It is used for connecting a plane corner between RX and RX or an elevation corner between RCI and RCO.

• 4.5.10 RXSS/RXSSW box joint sliding coupler [Installation]



\*Check instructions on the [Design] page before installation.

## Product configuration



#### Set contents

Model number	Cover	Reinforcing plate	Bottom plate	Blind plate	Side plate	Screw set for the cover	Screw set for the blind plate
RXSS(W)-900(H)-1	1	1	1	2	2	4	4
RXSS(W)-900(H)-2	1	1	1	2	2	4	4
BXSS(W)-900(H)-3	1	1	1	2	2	4	4

Side	Screw set for	Screw set for		items
plate	ide   Screw set for   Screw set for   the blind plate			Screw set for
2	4	4		the cover
2	4	4		Screw set for
2	4	4		the blind plate

<Figure 4.5.10-2.1>

cross-shape

branch joint

<Figure 4.5.10-2.3>

<applicable adjustment="" sliding="" width=""></applicable>			
Model number	Adjustment width L		
RXSS(W)-900(H)-1	0~100		
RXSS(W)-900(H)-2	100~200		
BX66(M)-000(H)-3	200200		

ems ⊕ hex bolt M6 × 15

ems ⊕ hex bolt M6 × 15L

SUS

SUS

Flange nut M6

Flange nut M6L

#### 4.5.10-2 Example of RXSS assembly (1) <plane corner (example) RX-RX connection>

 $\blacksquare$  Attach the bottom plate using the sems  $\oplus$  hex bolts and flange nuts supplied (4 locations in total).


Make adjustment to have the top at the same height.




2 Remove the sems  $\oplus$  hex bolts, which are supplied with RX, and attach and tighten the RX side plates and sliding coupler side plates together (8 locations in total).

> When the sliding adjustment width is 0 to 15 mm Fill the holes (2 places) at the center of the sliding coupler side plates using the supplied sems  $\oplus$  hex bolts and flange nuts in advance.

The sliding coupler side plate can be mounted on either the front or rear side. However, mount it so that the sliding part does not protrude into the piping route. If the side plate protrudes, the duct cannot be installed.






Do not use

the blind plate

after installation


 $\ensuremath{\mathbf{3}}$  Attach the blind plate using the sems  $\oplus$ hex bolts and flange nuts supplied (4 locations in total).

Do not use the blind plate when the sliding adjustment width is 0 to 15 mm.




4 Attach the RX (W) reinforcing plate, the cover and the sliding coupler cover to RX (W) in that order and tighten them together with the supplied screws (4 locations in total).


For walkways, install the reinforcing plate at the center between the parts.



#### Note

Do not exceed the applicable sliding adjustment width for use. Exceeding the applicable sliding adjustment width for use may generate a gap in the long hole of the sliding coupler cover.







#### 4.5.10-3 Example of RXSS assembly (2) <elevation corner (example) RCI-RCO connection>

 $\blacksquare$  Attach the bottom plate using the sems  $\oplus$ hex bolts and flange nuts supplied (4 locations in total).

Make adjustment to have the cover mounting surface at the same height.






114

Installation

Installation

When the sliding adjustment width is 0 to 15 mm

Fill the holes (2 places) at the center of the sliding coupler side plates using the supplied sems  $\oplus$  hex bolts and flange nuts in advance.




• 4.5.10 RXSS/RXSSW box joint sliding coupler [Installation]

2 Remove the sems ⊕ hex bolts, which are supplied with RCI and RCO, and tighten the RCI and RCO side plates and sliding coupler side plates together (8 locations in total).

#### Note


The sliding coupler side plate can be mounted on either the front or rear side.



Attach the blind plate using the sems  $\oplus$  hex bolts and flange nuts supplied (4 locations in total).

#### Note


Do not use the blind plate when the sliding adjustment width is 0 to 15 mm.



Attach the RCI and RCO cover and the sliding coupler cover in that order and tighten them together with the screws supplied with RCI and RCO (4 locations in total).

#### Note

Attach the RCO cover end plate to the side where the sliding coupler is not installed.



## 4.5.11 RCSS sliding coupler for RCSS RCF-900 (H)-SUS

It is a coupler that can adjust the connection length for the 900 size elevation corner 45° (for SUS). This coupler accommodates a gap ranging from 13 mm to 313 mm between the corner parts.


\*Check instructions on the [Design] page before installation.

## for downloading the specification drawing

#### Parts to be connected

· RCF-900 (H)-SUS (elevation corner 45°)

#### 4.5.11-1 Product configuration




#### **Set contents**

Model number	Cover	Bottom plate	Blind plate	Side plate	Screw set for the bottom plate	Screw set for the blind plate	Washer for the cover	
RCSS-900(H)-1	1	1	2	2	4	4	4	
RCSS-900(H)-2	1	1	2	2	4	4	4	
RCSS-900(H)-3	1	1	2	2	4	4	4	

#### Bolt specifications


Items	Specifications	Material
Screw set for	Sems ⊕ hex bolt M6 x 15L	SUS
the cover	Flange nut M6	SUS
Screw set for	Sems ⊕ hex bolt M6 x 15L	SUS
the blind plate	Flange nut M6	SUS
Washer for the cover	Flat washer W3/8	SUS


## 4.5.11-2 Example of RCSS assembly



Attach the bottom plate using the sems  $\oplus$  hex bolts and flange nuts supplied (4 locations in total).

Note Make adjustment to have the cover mounting surface of RCFI and RCFO at the same height.





allation


Pipe shaft and vall penetration

ting bracket

Duct (straight pi


118

Attach RZC to the bottom plate using the bolt set supplied with RZC (2 locations in total).



#### When the sliding adjustment width is 0 to 15 mm


Fill the holes (2 places) at the center of the sliding coupler side plates using the supplied sems  $\oplus$  hex bolts and flange nuts in advance.



3 Remove the sems ⊕ hex bolts, which are supplied with RCFI and RCFO, and attach and tighten the RCFI and RCFO side plates and the RCSS side plates together in this order (8 locations in total).

#### Note


The RCSS side plate can be mounted on either the front or rear side.



4 Attach the blind plate using the sems  $\oplus$  hex bolts and flange nuts, which are supplied (4 locations in total).

#### Note


Do not use the blind plate when the sliding adjustment width is 0 to 15 mm.




Adding the supplied flat washer to the sems  $\oplus$  hex bolt supplied with RCFI and RCFO, attach the RCFI and RCFO covers and the RCSS cover together in this order in a way in which the cutout side of the cover is positioned on the side of RCFI (4 locations in total).


## Note

- Installation may fail, if the cutout side is positioned on the side of RCFO.
- Installation may not be secured sufficiently, if a flat washer is not added. Do not exceed the applicable sliding adjustment width for use.
- A gap may be generated in the long hole of the RCSS cover, if exceeding the applicable sliding adjustment width for use.








## 4.6 Fittings




## Fittings list


















RE 90° flat ell

Plane surface type 90° elbow. Note that the attachment method differs depending on the size.



\* Also check the Design section before performing installation.

## 4.6.2-1 Product configuration




#### <Table 4.6.2-1.1> Set contents

Size	Base	Cover	Bottom plate	Cover bolt (pieces)	Bolt set for connection	Cover reinforcing plate (for RE/for RD)
150	1	1	1	4	0	0/0
300/300H	1	1	0	3	4	0/0
450/450H	1	1	0	3	4	0/0
600/600H	1	1	0	3	4	1/1

<Table 4.6.2-1.2> Bolt specification


ltem	Specification	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set for connection	Sems ⊕ hex M6×15L	SUS
	Flange nut M6	SUS

#### 4.6.2-3 Base top view



#### Example of assembling and attaching RE (1) (300 to 600H)

1 Place RE temporarily on the mounting bracket and connect it to the duct.




2 Secure the connection part to the mounting bracket.

\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.

Perform piping, and then finally attach the cover reinforcing plate\*and the cover.


- \* 600/600H size only
- \* For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate also to the connection part. (600/600H size only)



#### Example of assembling and attaching RE (2) 150

■ Attach the mounting bracket to the bottom plate of RE.


> \*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.



2 Connect RE and the duct by using the fixing coupler.

Reference [4.5.3] RSJ fixing coupler

Perform piping, and then finally set the cover.



Installation

How to proceed installation

450/450H 600/600H

## REW 90° flat ell (walkway type)


Plane surface type 90° elbow (walkway type)

Note that the reinforcing plate attachment position differs depending on the



\* Also check the Design section before performing installation.

## Product configuration




٦	<table 4.6<="" th=""><th>ntents</th></table>	ntents			
	Size	Cover	Base	9	Bottom plate
	300/300H	1	1		0
	450/450H	1	1		0
	600/600H	1	1		0
	Size	Cover	bolt	fc	Bolt set or connection
	300/300H	3			4

	-	·
Size	Wide reinforcing plat for walkway NT	e Cover reinforcing plate
300/300H	0	2
450/450H	1	1
600/600H	1	1

<Table 4.6.3-1.2> Bolt specification

Items	Material	
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set	Sems ⊕ hex M6×15L	SUS
for connection	Flange nut M6	SUS

#### 4.6.3-2 Position to attach the reinforcing plate




#### 4.6.3-3 Installation of REW

1 Fit in the duct bases each other with an overlap of 20mm, fix them to the mounting bracket, and then fix the overlapped parts by bolting from the sides.

\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.


Warning Be sure to set at least three mounting brackets.



2 Perform piping, and then attach each reinforcing plate to the positions as shown in the table "Position to attach the reinforcing Plate" above.

Set the cover of walkway type.

- \* For beautiful finish, set the cover of 90° flat ell walkway type first, and then set the cover of straight duct.
- \* For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate to the connection part. (600/600H type only)




## RF 45° flat ell

Plane surface type 45° elbow.

Note that the attachment method differs depending on the size.

\* Also check the Design section before performing installation.

#### 4.6.4-1 **Product configuration**




## <Table 4.6.4-2.1> **Set contents**

	Size	Base	Cover	plate	reinforcing plate (for RF/for RD)	bolt	for connection
	150	1	1	1	0/0	4	0
	300/300H	1	1	0	0/0	3	4
	450/450H	1	1	0	0/0	3	4
	600/600H	1	1	0	1/1	3	4
	900/900H	1	1	2	0/2	6	8
- 1							

<Table 4.6.4-2.2> Bolt specification


	Items	Specification	Material
	Cover bolt	Sems ⊕ hex M6×15L	SUS
	Bolt set	Sems ⊕ hex M6×15L	SUS
)	for connection	Flange nut M6	SUS

### 4.6.4-2 Position to attach the cover reinforcing plate (base top view)



## Example of assembling and attaching RF (1) <300 to 600H>

■ Place RF temporarily on the mounting bracket and connect it to the duct.




2 Fix the connection part to the mounting bracket.

\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.

Perform piping, and then finally attach the cover reinforcing plate\*and the cover.

- \* 600/600H size only
- \* For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate also to the connection part. (600/600H size only)




(Installation)

#### 4.6.4-4 Example of assembling and attaching RF (2) <900 to 900H>


1 Set the mounting bracket at the bottom plate of RF.

\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.



2 Insert the RD duct and fix it. Perform piping, and then finally attach the cover reinforcing plate\* and the cover.


\*···Standardly supplied with 900/900H.



#### 4.6.4-5 Example of assembling and attaching RF (3) <150>

1 Set the mounting bracket at the bottom plate of RF.


\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket



Attach the duct to the RF by using the fixing coupler.

Reference [4.5.3] RSJ fixing coupler

Perform piping, and then finally set the cover.





## RFW 45° flat ell (walkway type)

Plane surface type 45° elbow (walkway type).

Note that the reinforcing plate attachment position differs depending on the

\* Also check the Design section before performing installation.






<table 4.6<="" th=""><th>.5-1.1&gt;</th><th>&gt; Set</th><th>conten</th><th>ts</th></table>	.5-1.1>	> Set	conten	ts

Size	Cover	Da:	96	plate	bolt	for connection	
300~450H	1	1		0	3	4	
600/600H	1	1		0	3	4	
900/900H	1	1		1	6	8	
Size	Wide reinforcii for walkwa	Wide reinforcing plate for walkway NI		reinforcing plate or walkway	inforcing plate or RFW	Cover reinforcing plate	
300~450H	0		0~450H 0 0		0	2	
600/600H	1			0	0	1	
						_	

<Table 4.6.5-1.2> Bolt specification

Item	Specification	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set	Sems ⊕ hex M6×15L	SUS
for connection	Flange nut M6	SUS

### 4.6.5-2 Position to attach the reinforcing plate




#### Installation of RFW (1) 300 to 600H size

1 Fit in the duct bases with an overlap of 20 mm, secure them to the mounting bracket, and secure the overlapped sides of the base duct bases using bolts.


\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.

Warning Be sure to set at least two mounting brackets.



2 Perform piping, and then attach each reinforcing plate to the positions as shown in the table "Position yo attach the reinforcing Plate" above. Set the cover of walkway type.

\* For beautiful finish, set the cover of 45° flat ell walkway type first, and then set the cover of straight




How to proceed installation


4.6.5-4 Installation of RFW (2) 900/900H type

1 Set the mounting bracket at the bottom plate of RFW (walkway type).

\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.



2 Attach the RXC parts connection bracket for 900(H) to RFW, and then fit in the duct and fix




## **RFS** flexible corner

This corner part is angle adjustable in the horizontal plane.



## **Product configuration**




Size	Cover (inner R side)	Cover (outer R side)	Duct base (inner R side)	Duct base (outer R side)	Cover reinforcing plate
300/300H	1	1	1	1	1
450/450H	1	1	1	1	1
600/600H	1	1	1	1	1
900/900H	1	1	1	1	1


Size	Resin bush	Flat washer M8	SEMS⊕ hex M6 x 15L
300/300H	4	4	4
450/450H	4	4	4
600/600H	4	4	4
900/900H	4	4	5

#### Installation of RFW

1 Temporarily fix the duct base of the duct to the mounting bracket, using hex bolts and nuts (supplied with the mounting bracket). Insert the resin bush into the hole of the duct base (outer R side) from the outside, and fit the flat washer M8 to the tab on the bush from the inside and secure it.



2 Remove the hex bolt that is temporarily fixed, insert the duct base (inner R side and outer R side) between the duct base and mounting bracket, and temporarily fix it again.



Installation


How to proceed installation

Duct (straight pipe)

3 With reference to the graduation mark provided on the flexible corner duct base (inner R side), adjust the angle of the RD duct. When the angle has been adjusted, tighten and secure the hex bolts (inner R side and outer R side) that are temporarily fixed.

\* The angle can be adjusted in the range between 0° and 20°.


To align the RD duct angle on both sides, use the same graduation mark on both sides.




<Figure 4.6.6-2.3>

• 4.6.6 RFS flexible corner (Installation)


4 Install the piping and attach the duct cover reinforcement plate (the number and position may vary from those indicated in the figure, depending on the size of the duct).



5 Install the duct cover.



6 Attach the RFS cover reinforcing plate to the inner R side (round hole) and the outer R side (long hole) in this order and secure it with the hex bolts that are supplied.




## RFSW flexible corner (walkway type)

This corner part is angle adjustable in the horizontal plane.



## Product configuration




Size	Cover (inner R side)	Cover (outer R side)	Duct base (inner R side)		Cover reinforcing plate	Cover reinforcing plate (for connection)
300/300H	1	1	1	1	1	-
450/450H	1	1	1	1	1	_
600/600H	1	1	1	1	1	1
900/900H	1	1	1	1	1	1

<Table 4.6.7-1.1> Set contents


Size	Resin bush	Flat washer M8	Low-head ⊕ M6 x 15L	Flat washer M6	SEMS⊕ hex M6 x 15L
300/300H	4	4	_	_	4
450/450H	4	4	_	_	4
600/600H	4	4	4	4	4
900/900H	4	4	4	4	5

### **Product configuration**

Temporarily fix the duct base of the duct to the mounting bracket, using hex bolts and nuts (supplied with the mounting bracket). Insert the resin bush into the hole of the duct base (outer R side) from the outside, and fit the flat washer M8 to the tab on the bush from the inside and secure it.



2 Remove the hex bolt that is temporarily fixed, insert the duct base (inner R side and outer R side) between the duct base and mounting bracket, and temporarily fix it again.



Installation


How to procee installation

Pipe shaft and wall penetration

With reference to the graduation mark provided on the flexible corner duct base (inner R side), adjust the angle of the duct.
When the angle has been adjusted, tighten and secure the hex bolts (inner R side and outer R side) that are temporarily fixed.

% The angle can be adjusted in the range between 0° and 20°.

To align the RD duct angle on both sides, use the same graduation mark on both sides.




<Figure 4.6.7-2.3>

• 4.6.7 RFSW flexible corner [Installation]

(walkway type)


Install the piping and attach the duct cover reinforcement plate (the number and position may vary from those indicated in the figure, depending on the size of the duct).





- 5 Install the duct cover.
  - For RFSW-300(H)/450(H)

    Secure it to the duct base, using the hex bolts supplied with the duct.
  - For RFSW-600(H)/900(H)
  - Place two cover reinforcing plates (for connection), secure to the duct base using the hex bolts supplied with the duct, and secure to the cover reinforcing plates using the supplied bolts and puts
  - nuts.

    \*\* For the cover reinforcing plate (for connection), use the item (1 piece) supplied with the flexible corner and the item (1 piece) supplied with the duct.







## 4.6.8 **RT tee**


Plane surface type branching fittings. Note that the attachment method differs depending on the size.

\* Also check the Design section before performing installation.

2D Barcode for downloading the specification drawing



## Product configuration




#### <Table 4.6.8-1.1> Set contents

Size	Base	Cover	Bottom plate	Cover reinforcing plate	Bolt for Cover	Bolt set for connection		
150	1	1	1	0	6	0		
300/300H	1	1	0	0	4	4		1
450/450H	1	1	0	0	4	4	1	
600/600H	1	1	0	2	3	4		

<Table 4.6.8-1.2> Bolt specification


Item	Specifications	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set	Sems ⊕ hex M6×15L	SUS
for connection	Flange nut M6	SUS

## 4.6.8-2 Base top view



4.6.8-3 Example of assembling and attaching RT (1) <300 to 600H>

Temporarily place RT on a Mounting bracket, and connect the duct.



• 4.6.8 RT tee


[ Installation ]

2 Fix the connection part to the mounting bracket.

\*\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.

Perform piping, and then finally attach the cover reinforcing plate\* and set the cover.


- \* 600/600H size only
- For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate also to the connection part. (600/600H size only)



### 4.6.8-4 Example of assembling and attaching RT (2) <150>

1 Set the mounting bracket.


\*\*Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.



2 Connect the RD duct to RT by using the fixing coupler.

Reference [4.5.3] RSJ fixing coupler

Perform piping, and then finally set the cover.



## 4.6.9 RTW tee (walkway type)


Plane surface type branching fittings (walkway type).

Note that the reinforcing plate attachment position differs depending on the size.

\* Also check the Design section before performing installation.

2D Barcode for downloading the specification drawing

#### 4.6.9-1 RTW tee (walkway type)



#### <Table 4.6.9-1.1> Set contents


	Size	Cover	Base	Cover bolt
	300/300H	1	1	4
	450/450H	1	1	4
	600/600H	1	1	3
i		1		

Bolt set for connection	Wide reinforcing plate for walkway	Cover reinforcing plate
8	1	2
8	1	0
8	1	2

#### <Table 4.6.9-1.2> Bolt specification

	Item	Specifications	Material
	Cover bolt	Sems ⊕ hex M6×15L	SUS
	Bolt set for connection	Sems ⊕ hex M6×15L	SUS
		Flange nut M6	SUS


#### 4.6.9-2 Position to attach the reinforcing plate




#### 4.6.9-3 Installation of RTW

- Fit in the duct bases each other with an overlap of 20mm, fix them to the mounting bracket, and then fix the overlapped parts by bolting from the sides.
  - Bolts, nuts and washers for attaching the duct are supplied
     with the mounting bracket.

Warning Be sure to set at least three mounting brackets.



- Perform piping, and then attach each reinforcing plate to the positions as shown in the table "Position to attach the reinforcing Plate" above.
  - Set the cover of tee (walkway type) .
  - For beautiful finish, set the cover of tee (walkway type) first, and then set the cover of straight duct.
  - For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate to the connection part. (600/600H size only)



132

How to proceed installation


**RXN/RX** cross

Plane surface type branching fittings. Note that the attachment method differs depending on the size.

\* Also check the Design section before performing installation.

• 4.6.10 RXN/RX cross [Installation]

#### 4.6.10-1 Product configuration




#### <Table 4.6.10-1.1> Set contents

<Table 4.6.10-1.2> Bolt specification

Size	Cover	Base	Bottom plate		Cover reinforcing plate for RD/RXN	Cover bolt	Pillar bolt	Side plate bolt	Bolt set for connection
300/300H	1	1	0	0	0/0	4	0	0	12
450/450H	1	1	0	0	0/1	4	0	0	12
600/600H	1	1	0	0	3/1	4	0	0	12
900/900H	1	1	1	2	4/1	4	8	16	16


ı	Item	Specifications	Material
	Cover bolt	Sems ⊕ hex M6×15L	SUS
	Pillar bolt	Sems ⊕ hex M6×15L	SUS
	Side plate bolt	Sems ⊕ hex M6×15L	SUS
	Bolt set for	Sems ⊕ hex M6×15L	SUS
	connection	Flange nut M6	SUS

#### 4.6.10-2 Base top view



### 4.6.10-3 Installation of RXN <300 to 600H>

Temporarily place the mounting bracket, and connect RXN and the duct.




#### 2 Fix RXN to the mounting bracket.

- Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.
- \* When using the reducer, set the mounting bracket at the strut.

Perform piping, and then finally attach the cover reinforcing plate\* and set the cover.


- \* 600/600H size only
- For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate also to the connection part. (600/600H size only)




#### 4.6.10-4 Example of assembling and attaching RZ <900/900H>

Set the mounting bracket at RX.


 Bolts, nuts and washers for attaching the duct are supplied with the mounting bracket.



2 Attach the RD duct to the base.



3 Perform piping, and then if the branch duct is 900 or 900H, attach the supplied cover reinforcing plate RXH to the duct end, and finally set the cover.



How to procee installation

## RXNW/RXW cross (walkway type)

Plane surface type branching fittings.

Note that the reinforcing plate attachment position differs depending

\* Also check the Design section before performing installation.




• 4.6.11 RXNW/RXW cross [Installation]

(walkway type)



#### 4.6.11-1 Product configuration




#### <Table 4.6.11-1.1> Set contents

Size	Cover	Base	Bottom plate		Cover reinforcing plate		Pillar bolt	Bolt set for connection	Side plate bolt	Wide reinforcing plate for walkway	Wide reinforcing plate for walkway	Wide reinforcing plate for walkway	Cover reinforcing plate for walkway
300/300H	1	1	0	0	2	4	0	12	0	0	0	1	0
450/450H	1	1	0	0	2	4	0	12	0	0	1	0	0
600/600H	1	1	0	0	3	4	0	12	0	1	0	0	0
900/900H	1	1	1	2	4	4	8	16	16	0	0	0	1

#### <Table 4.6.11-1.2> **Bolt specification**


Item	Specifications	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Pillar bolt	Sems ⊕ hex M6×15L	SUS
Side plate bolt	Sems ⊕ hex M6×15L	SUS
Bolt set for	Sems ⊕ hex M6×15L	SUS
connection	Flange nut M6	SUS

## 4.6.11-2 Position to attach the cover reinforcing plate (base top view)



### 4.6.11-3 Installation of RXNW <300 to 600H>

1 Temporarily place the mounting bracket, and connect RXNW and the duct.




#### 2 Fix RXNW to the mounting bracket.

- \* Bolts, nuts, and washers for fixing the mounting bracket are supplied with the mounting bracket.
- \* When using the reducer, set the mounting bracket at the strut


Perform piping, and then finally attach each reinforcing plate and set the cover.

\* For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate also to the connection part. (600/600H size only)




## 4.6.11-4 Installation of RXW <900/900H>

- 1 Set the mounting bracket at RXW.
  - \* Bolts, nuts, and washers for fixing the mounting bracket are supplied with the mounting bracket.




2 Attach the RD duct to the base.



3 Perform piping, and then attach each reinforcing plate. If the branch duct is 900 or 900H.

attach the supplied cover reinforcing plate RXH to the duct end, and finally set the cover.



139

90° inside vertical ell


Elevation surface elbow 90° (rising) for 300 to 900H. Note that there are different installation methods for 300 to 600H and for

• 4.6.12 RCI 90° inside vertical ell [Installation]



\* Also check the Design section before performing installation.

## 4.6.12-1 Product configuration



#### <Table 4.6.12-1-2> **Set contents**

Size	Cover	Base	Bottom plate	Cover reinforcing plate /Cover guide	Cover* bolt	Bolt set for connection
300/300H	1	1	1	0	4	4
450/450H	1	1	1	0	4	4
600/600H	1	1	1	1	4	4
900/900H	1	1	1	2	8	8*


\* Built in the main unit before shipment

#### <Table 4.6.12-1-3> Bolt specification


Items	Specifications	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set	Sems ⊕ hex M6×15L	SUS
for connection	Flange nut M6	SUS

## 4.6.12-2 Example of assembling and attaching (1) <300 to 600H>


- 1 Attach the base to the duct.
  - \* During the work, temporarily place the base and duct on the mounting bracket etc. to prevent dangling.



2 Fix them to the mounting bracket.




- 3 Perform piping, and then finally set the cover.
  - \* For the coupler-free connection or when free coupler S/H type is used, attach the cover reinforcing plate to the horizontal connected part. (600/600H size only)




#### 4.6.12-3 Example of assembling and attaching (2) <900/900H>


1 Mount the base to the mounting bracket.




2 Insert the duct into the base of RCI and secure it.



3 After piping work is completed, install the lid guide on RCI.



4 Install the duct cover, install the RCI cover, and the work is completed.



4.6.13 RCO 90° outside vertical ell

Elevation surface elbow 90° (falling) for 300 to 900H. Note that there are different installation methods for 300 to 600H and for 900/900H.


\* Also check the Design section before performing installation.

2D Barcode for downloading the specification drawing

• 4.6.13 RCO 90° outside vertical ell [Installation]



## 4.6.13-1 Product configuration



#### <Table 4.6.13-1.1> Set contents

Size	Cover	Base	Bottom plate	Cover reinforcing plate /Cover guide	Cover* bolt	Bolt set for connection
300/300H	1	1	1	0	4	4
450/450H	1	1	1	0	4	4
600/600H	1	1	1	1	4	4
900/900H	1	1	1	2	10	8*

#### <Table 4.6.13-1.2> Bolt specification


Items	Specifications	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt for	Sems ⊕ hex M6×15L	SUS
connection	Flange nut M6	SUS

\* Built in the main unit before shipment

#### 4.6.13-2 Installation of RCO (1) <300 to 600H>


#### 1 Connect the base of RCO to the duct.

\* For the installation on the wall surface, attach the bottom plate to the part connected to RCO.




#### ${\bf 2}$ Perform piping, and then finally attach the cover reinforcing plate ${\bf *}$ and set the cover.

- \* When the horizontal part is connected by the coupler-free connection + mounting bracket, attach the cover reinforcing plate. (600/600H size only)
- Note For installation on the wall, it is necessary to take measures to prevent bolts from loosening. For details, see [2.3] Installation method (on the wall surface).




#### 4.6.13-3 Installation of RCO (2) <900/900H>

1 Attach the RCO base part to the mounting bracket etc.




How to proceed installation

2 Mount the duct to RCO.



3 After piping work is completed, install the lid guide on RCO.




4 After the duct lid is mounted, install The RCO lid, and the work is completed.

#### Note

For installation on the wall, it is necessary to take measures to prevent bolts from loosening.

For details, see [2.3] Installation method (on the wall surface).



## RC 90° vertical ell (150)


Elevation surface elbow 90° for 150 size.

By exchanging the supplied parts (cover and bottom plate), this can be used for both "rising" and "falling".

\* Also check the Design section before performing installation.



## Product configuration



#### <Table 4.6.14-1.1> Set contents


Size	Cover	Bottom plate	Duct base	Bolt for cover/bottom plate
150	2	2	2	8


#### <Table 4.6.14-1.2> Bolt specification

Specifications	Material
Sams A hay M6x15I	2112

### 4.6.14-2 Example of assembling and attaching RC

1 Assemble the base and attach it to the duct 2 Perform piping, and then finally set the cover. by using the fixing coupler.





RCF 45° vertical ell

Elevation surface 45° elbow.

This is the set of the rising type (RCFI) and the falling type (RCFO).


\* Also check the Design section before performing installation.



• 4.6.15 RCF 45° vertical ell [Installation]



## 4.6.15-1 Product configuration



#### <Table 4.6.15-1.1> **Set contents**

Size	Cover	Base	Bottom plate	Cover bolt*	Bolt set for connection	Cover reinforcing plate
150	2	2	2	8	8	0
300/300H	2	2	2	8	8	0
450/450H	2	2	2	8	8	0
600/600H	2	2	2	8	8	2
900/900H	2	2	2	8	8	2


\* Built in the main unit before shipment

#### <Table 4.6.15-1.2> Bolt specification


Items	Specifications	Material
Cover bolt	Sems ⊕ hex M6×15L	SUS
Bolt set for connection	Sems ⊕ hex M6×15L	SUS
Boit set for connection	Flange nut M6	SUS

## 4.6.15-2 Installation of RCF (coupler-free connection)

1 Fit the end of the duct base and that of the duct base of vertical ell with an overlap of 20mm, and fix the bottom of overlapped part of duct bases to the mounting bracket or the mounting bracket fixing plate for elevation surface by using the W3/8 hex bolt.




2 Fix the side surface of overlapped part of the duct base ends with bolts.



3 After the piping work is completed, attach the supplied cover reinforcing plate\* to the part connected to the duct, and then set the cover in the order from the lower part.Set the cover with an overlap of 20mm.

\* 600(H)/900(H) only and for coupler-free connection or connection using the free coupler S/H type only.




How to proceed installation


**Bottom plate** 

Table of

4.7.1	Bottom plate list ·····	146
4.7.2	RDB bottom plate set for RD duct ·····	147
4.7.3	REB bottom plate set for 90° flat ell	150
4.7.4	RFB bottom plate set for 45° flat ell	151
	RTS bottom plate set for tee	
4.7.6	RDBJ bottom plate for coupler ·····	153
	RJB retrofit bottom plate for coupler ·····	
4.7.8	RNB bottom net ····	155


## **Bottom plate list**








• 4.7.1 Bottom plate list


[ Installation ]














## RDB bottom plate set for RD duct

Bottom plate for RD duct (straight pipe).


For 150 size, the bottom plate for connection part (bottom plate for coupler)

Retrofit attachment is also possible by using the separately sold resin bush for

\* Also check the Design section before performing installation.



#### Product configuration



#### <Table 4.7.2-1.1> Set contents (300~900)

Size	Bottom plate A	Bottom plate B	Bolt set for connection
2m	2	2	16
1 m	1	2	12
0.5m	1	0	4
0.3m	1	0	4

\* Even for a part with the same name, its dimensions differ depending on the size.

#### <Table 4.7.2-1.2> Set contents (150)

\ 1 abio 1.7 .1	Crabio III.E 1.E. Got Goritonia (1997)					
Size Bottom plate A Bottom plate B Bottom plate for coupler				Bolt set for connection		
2m	2	2	2	20		
1m 1		2	2	16		

- $\ensuremath{\,\%\,}$  For RD-150-05, the bottom plate is standardly included (built-in).
- \* Even for a part with the same name, its dimensions differ depending on the size.

#### <Table 4.7.2-1.3> Bolt specification

Items	Specifications	Material
Dolt oot	Sems ⊕ hex bolt M6 × 15L	SUS
Bolt set	Hex nut M6	SUS
for connection	Flat washer M6	SUS

#### Installation of RDB

#### 1 Attaching bottom plate in advance (bottom plate for duct 2m/1m/0.5m/0.3m)

After the duct connecting is completed, attach bottom plate (A), bottom plate (B), and (bottom plate for coupler\*) in order by using the supplied bolts from inside the duct base as shown in the figure.

- \* The bottom plate for coupler is standardly supplied with 150 size, but separately sold for other than 150 size.
- \* As for the bottom plate for coupler, use the fixing coupler type or free coupler A type, and it is to be used only when the mounting bracket is not set at the connection part.


Also note that the attachment method differs when the part connected next to it is the duct 0.3m/0.5m, flat ell, or tee. Reference [4.7.6] RDBJ


- There is a directionality in bottom plate
- The bottom plate for coupler is not needed when the mounting bracket is set at the connection part.


#### Installation for attaching the mounting bracket to the connection part


<Figure 4.7.2-3.1.4>

The bottom plate for coupler is not needed because the mounting bracket is used as the bottom plate









#### 2 Retrofit attachment of the bottom plate (bottom plate for duct 2m/1m/0.5m/0.3m)


Make a 20mm clearance at the duct connection part, and connect ducts by using the coupler base such as RSJ or RFJ, and then attach bottom plate A, bottom plate B, and (bottom plate for coupler\*) in order by using the resin bush for bottom plate from the bottom side of duct base.


- \* The bottom plate for coupler is standardly supplied with 150 size, but separately sold for other than 150 size.
- \* As for the bottom plate for coupler, use the fixing coupler type or free coupler A type, and it is to be used only when the mounting bracket is not set at the connection part.


Also note that the attachment method differs when the part connected next to it is the duct 0.3m/0.5m, flat ell, or tee. (see [4.7.6] RDBJ)

- Note There is a directionality in bottom plate(B).
  - The bottom plate for coupler is not needed when the mounting bracket is set at the connection part.
  - Retrofit installation is not possible for 900 type or coupler-free connection.

Reference [3.6.2] Bottom plate usable position







151

## 4.7.3 REB bottom plate set for 90° flat ell

This is the 300 to 600H size bottom plate set for 90° flat ell.

\* Also check the Design section before performing installation.

2D barcode for download the specifical through the specif




• 4.7.3 REB bottom plate set for (Installation)

90° flat ell



#### 4.7.3-1 Product configuration



## <Table 4.7.3-1.1> Set contents

Bottom plate L	Bottom plate R	Bolt set for connection
1	1	6

#### <Table 4.7.3-1.2> Bolt specification


Items	Specifications	Material	
Bolt set	Sems ⊕ hex bolt M6 × 15L	SUS	
for connection	Hex nut M6	SUS	
101 0011110011011	Flat washer M6	SUS	

#### 4.7.3-2 Installation of REB

#### Attaching bottom plate for 90° flat ell in advance


Note Retrofit attachment of the bottom plate is not possible.


Attach the bottom plate (R) and (L) by using the supplied bolts from the base opening side.



#### Supplement For the connection method using coupler and not setting the mounting bracket at the connection part

Drop the bottom plate for coupler from the base opening side, and attach it to the bottom of base along with the stiffening plate by using the supplied bolt.





## 4.7.4 RFB bottom plate set for 45° flat ell

This is the 300 to 600H size bottom plate set for  $45^{\circ}$  flat ell.


\* Also check the Design section before performing installation.

\* The bottom plate is standardly supplied with 150 size.

2D barcode for downloading the specification drawing



## 7.4-1 Product configuration



#### <Table 4.7.4-1.1> Set contents

Bottom plate L	Bottom plate R	Bolt set for connection
1	1	6

## <Table 4.7.4-1.2> Bolt specification


Items	Specifications	Material
Bolt set	Sems ⊕ hex bolt M6 × 15L	SUS
for connection	Hex nut M6	SUS
101 001110011011	Flat washer M6	SUS

#### 4.7.4-2 Installation of RFB

#### Attaching bottom plate for 45° flat ell in advance


Note Retrofit attachment of the bottom plate is not possible.


Attach the bottom plate (R) and (L) by using the supplied bolts from the base opening side



## Supplement For the connection method using coupler and not setting the mounting bracket at the connection part

Drop the bottom plate for coupler from the base opening side, and attach it to the bottom of base along with the stiffening plate by using the supplied bolt.





How to procee installation

## RTS bottom plate set for tee


This is the 300 to 600H size bottom plate set for tee.



\* The bottom plate is standardly supplied with 150 size.

\* Also check the Design section before performing installation.

## 4.7.5-1 Product configuration



#### <Table 4.7.5-1.1> Set contents

Bottom plate	Bolt set for connection
1	8

#### <Table 4.7.5-1.2> Bolt specification


Items	Specifications	Material
Bolt set	Sems ⊕ hex bolt M6 × 15L	SUS
for connection	Hex nut M6	SUS
101 0011110011011	Flat washer M6	SUS

#### 4.7.5-2 Installation of RTS

#### Attaching bottom plate for tee in advance


Note Retrofit attachment of the bottom plate is not possible.


Attach the bottom plate by using the supplied bolts from the base opening side.



#### Supplement For the connection method using coupler and not setting the mounting bracket at the connection part

Drop the bottom plate for coupler from the base opening side, and attach it to the bottom of base along with the stiffening plate by using the supplied bolt.





## RDBJ bottom plate for coupler


This is used for the installation using the bottom plate and in which the fixing coupler or free coupler is used and the mounting bracket is not set at the

\* For 150 size, two bottom plates for duct are standardly included.

\* Also check the Design section before performing installation.



#### Product configuration



#### <Table 4.7.6-1.1> Set contents

Bottom plate	Stiffening plate	Bolt set for connection
1	2	4


#### <Table 4.7.6-1.2> Bolt specification


Items	Specifications	Material
Dalt oat	Sems ⊕ hex bolt M6 × 15L	SUS
Bolt set for connection	Hex nut M6	SUS
	Flat washer M6	SUS

#### 4.7.6-2 Installation of RDBJ

Make a 20mm clearance at the duct connection part, and connect ducts by using the RSJ coupler base, and then attach bottom plate A first, and bottom plate B next, from inside the duct by referring to the figure of [4.7.2-3.1.1].

Temporarily place the bottom plate for coupler from the duct opening side, and attach it from the bottom along with the stiffening plate by using the supplied bolts.





152

## **RJB** retrofit bottom plate for coupler


This is the bottom plate for coupler part (RSJ) used in a special case. This is used when the bottom plate is attached to the part connecting a straight duct and fittings or 0.3m/0.5m duct.

• 4.7.7 RJB retrofit bottom plate for coupler (Installation)



\* Also check the Design section before performing installation.

## 4.7.7-1 Product configuration



#### <Table 4.7.7-1.1> Set contents


В	ottom plate	Stiffening plate	Bolt set for connection
	1	2	2

#### <Table 4.7.7-1.2> Bolt specification


Items	Items Specifications	
D. II.	Sems ⊕ hex bolt M6 × 15L	SUS
Bolt set for connection	Hex nut M6	SUS
Tor cormicotion	FLINK L MO	0110

#### 4.7.7-2 Installation of RJB

I Insert RJB from the bottom of the duct base by sandwiching the duct base with the stiffening plate.



Push the stiffening plate on the sliding side, slide the stiffening plate, and tighten the supplied screws.




## **RNB** bottom net

This is the simple bottom plate (net) for the straight duct. This is attached by using the resin bush for bottom plate.

\* Also check the Design section before performing installation.



### 4.7.8-1 Product configuration




<Table 4.7.8-1.1> Set contents

## 4.7.8-2 Installation of RNB (1): Attachment in advance

Note The bottom net cannot be attached to fittings.

Roll out the bottom net on the duct base, and attach it by inserting the resin bush for bottom plate into the  $\phi$ 7 hole of the duct




#### 4.7.8-3 Installation of RNB (2): Retrofit attachment



- Retrofit attachment of bottom net is not possible for 900 size.
- The bottom net cannot be attached to fittings. (Excluding RE)

After piping, attach the bottom net by inserting the resin bush for bottom plate into the  $\phi$ 7 hole of the duct base as shown from the bottom.

At this time, use the resin bush for bottom plate at an interval of approximately 250mm to prevent dangling of the bottom net.





4.8 Others


# Table of contents


4.8.1	List of other members	156
4.8.2	REC end cap ·····	157
4.8.3	RPH PD supporting bracket	158
4.8.4	RDK RD strut set	159
4.8.5	RSK RD duct partitioning bracket for H type	159
4.8.6	RDS caution sticker ·····	160

## 4.8.1 List of other members











## 4.8.2 **REC end cap**


This is the part to cover the opening of straight duct or fittings (except some parts), etc.

※ Also check the Design section before performing installation.





## 4.8.2-1 Product configuration




#### <Table 4.8.2-1.1> Set contents


Items	Quantity
End cap	1
Bolt (Sems ⊕ hex M6×15L - SUS)	4

#### 4.8.2-3 Installation of REC

Attach the end cap to the RD duct <Figure 4.8.2-3.1>



After piping, attach the cover of RD duct by sliding it in the claw of cap.



156

**RPH PD supporting bracket** 


This is the bracket to support PD duct.

\* This bracket does not support or fix piping. For supporting piping, use commercially available supporting brackets and PD fixing coupler PDB-N etc. as necessary. % In the duct base of RD duct, several holes (24 holes for 2m) are prepared for attaching bolts, into



which the W3/8 or M10 bolts can be inserted. \* Also check the Design section before performing installation.

#### Product configuration



#### <Table 4.8.3-1.1> **Set contents**


Items	Quantity
Main unit	1
Guide	1
Hex bolt	1
Bolt set for connection	1

<Table 4.8.3-1.2> Bolt specification

Items	Specifications	Material	
Hex bolt	⊕ Hex bolt M6×14L	SUS	
Specifications	Sems ⊕ hex bolt M6×20L	SUS	

#### Installation of RPH


1 Attach the guide by matching the position of guide to the branching position.




2 Perform piping, protect the piping with the PD duct, adjust the height, and then fix with the piping support bracket RPH.

\* Bolts, nuts, and washers for fixing the mounting bracket are supplied with the mounting bracket.

Note Be careful not to misplace the top and bottom sides of piping support bracket RPH. Reference <Figure 4.8.3-2.2>



Perform the treatment for the piping end. Use the PD end cover PDC for the piping end.



## **RDK RD strut set**

This is used as the support of piping in hanging the RD duct from the ceiling (with the cover of duct facing downward).


Note For ceiling mounted installation (with the lid facing downwards), please remove the cover reinforcement plate that comes standard with the 600 (H) size duct and some corner parts for safety reasons.

for downloading



\* Also check the Design section before performing installation.

#### **Product configuration**



#### <Table 4.8.4-1.1> Set contents


Items	Quantity
Main unit	1
Bolt set for connection	4


<Table 4.8.4-1.2> Bolt specification

Items Specifications		Material
Bolt ⊕ Countersunk bolt M6×12L		SUS
Washer	Flat Washer φ6.5 × φ18	SUS
Nut	Hex nut M6	SUS

#### 4.8.4-2 Installation of RDK

1 Attach RDK to RD by using the supplied bolts.






## RSK RD duct partitioning bracket for H type

This is the insulation compression preventing bracket for the polyphyletic ducting system. This can be attached to the H type duct

\* Also check the Design section before performing installation.



#### Product configuration




#### <Table 4.8.5-1.1> Set contents


	Items / Specifications	Quantity
Strut		1
Guide		2
Countersunk bolt	(⊕ Countersunk M6×L12 SUS)	4
Hex bolt	(sems ⊕ hex bolt M6×L15 SUS)	4


#### 4.8.5-2 Installation of RSK

1 Attach the strut to the guide.

Install piping under the partitioning bracket, and attach RSK to the duct (duct base).







#### **RDS** caution sticker 4.8.6

It is used as a reminder not to use the duct (except walkway type) as a passageway or step.

#### Product configuration

<Figure 4.8.6-1.1>




#### 4.8.6-2 Example RDS usage

#### Affix it on the duct cover.



- Remove dusts and dirt from the surface before putting the sticker
- Once a sticker is removed, its becomes difficult to put it on again.
- Store it in a dry place away from direct sunlight.



# **Materials**

# **Materials**

Specifications by Ministry of Land, Infrastructure,

**Transport and Tourism** .....P162 to P163

About the corrosion resistance **of RD-ZA type** ..... P163

**View of snow accumulation** .... P164 to P165

SI units

# 5 Materials

		Specifications by Ministry of Land, Infrastructure, Transport and Tourism	
nts	5.2	About the corrosion resistance of RD-ZA type	163
	5.3	View of snow accumulation	164
	5.4	Copper pipe ·····	166
	5.5	SI units ····	167

## Specifications by Ministry of Land, Infrastructure, Transport and Tourism

Standard specifications for Public building construction by Ministry of Land, Infrastructure, Transport and Tourism

The heat insulating decorative case must be made of resin, aluminum alloy, hot-dip aluminum-zinc alloy-coated steel sheet, hot-dip zinc-coated steel sheet or material, hot-dip zinc-coated steel sheet with powder coating, stainless steel sheet, etc. The resin case must be weather-resistant and able to withstand temperatures ranging from - 20°C to 60°C.

(Page 84, Standard Specifications 2022 Edition)

### Supervision guidelines of machinery and equipment installation by Ministry of Land, Infrastructure, Transport and Tourism

#### (8) Heat insulating decorative case

The Standard Specifications prescribes that the heat insulating decorative case must be made of weather resistant resin, aluminum alloy, hot-dip aluminum-zinc alloy-coated steel sheet, hot-dip zinc-coated steel sheet or material, hot-dip zinc-coated steel sheet with powder coating, stainless steel sheet, etc. It must be of molded pipe, elbow, etc., and it must be excellent in water resistance, weatherability, and workability. The resin case must be able to withstand temperatures ranging from - 20°C to 60°C.

<Table 5.1.2-1>

(Page 304, Supervision Guidelines, 2022 Edition)

Classification / Refrigerant pipe			Insulation thickness (mm)			
Classification of heat insulation	Material and Installation procedure			Cooling only	Heat pump	
Exposure indoors     (general living room, corridor, machine room, book room, warehouse, etc.)     Exposure outdoors     (including balcony and open corridor)	Simple piping  1. Copper pipe covered with insulation material  2. Heat insulating decorative case (Required part to be fixed with bolt)  3. Sealing (part outdoors)	Compressor Outdoors Compressor Indoors	Gas pipe Liquid pipe Gas pipe Liquid pipe	20 or more 10 or more 10 or more	20 or more 10 or more 20 or more 10 or more	
Copper pipe covered with insulation material  Refrigerant pipe	Heat insulating decorative case  Control cable etc.	- (	Coated cop (Insulation NEOCOIL NEOPIPE Coated cop (Insulation PAIR COIL Coated cop (Insulation NEOCOIL I	oper pipe thickness 10 KHE oper pipe thickness 20 KHE	mm) ×20mm) mm)	

#### <Table 5.1.2-2>

Classification / Refrigerant pipe		Insulation thickness (mm)			
Classification of heat insulation	Material and Installation procedure			Cooling only	Heat pump
3. Exposure indoors (general living room, corridor, machine room, book room, warehouse, etc.) Exposure outdoors (including balcony and open corridor)	Collective piping 1. Copper pipe covered with insulation material 2. Heat insulating decorative case (Required part to be fixed with bolt) 3. Sealing (part outdoors)	Compressor Outdoors Compressor Indoors	Gas pipe Liquid pipe Gas pipe Liquid pipe	20 or more 10 or more 10 or more 10 or more	20 or more 10 or more 20 or more 10 or more
Copper pipe covered with insulation material  Refrigerant pipe  Coo	Heat insulating decorative case (powder paint finish hot-dip galvanized steel sheet, etc.)  Sealing	• C (   N	pated copposulation the EOCOIL / I pated copposulation the AIRCOIL KI pated copposulation the EOCOIL KI	nickness 10 r NEOPIPE er pipe nickness 10 × HE er pipe nickness 20 r HE / NEOPIP ng decorative	nm) : 20mm) nm) :E KHE

Note 1. Indicated values of the insulation thickness are those when the class-A polyethylene foam heat insulating tube JIS A 9511 is used.

2. For liquid pipes of 9.52 or less in nominal diameter, the insulation thickness may be 8mm.

(Page 325, Supervision guidelines of installation 2018 Edition)


## About the corrosion resistance of RD-ZA type

The RD-ZA series with "Highly corrosion-resistant hot-dip zinc-coated steel sheet (JIS G3323 K27 compliant)\*" provides the corrosion resistance equal to or greater than hot-dip zinc-coated steel sheets (HDZT77) or Galvalume steel sheets (AZ150), and it can be used not only in general outdoor environments but also in salt-damage and severe salt-damage areas where stainless steel (SUS304) cannot be used.

In the end face, red rust will occur in the early stage because the steel base is exposed. However, in several months after the installation, aluminum and magnesium will melt out from the plating layer of the plane surface. The dense zinc-based protective film which contains the melted out aluminum and magnesium covers the end face, and produces an excellent corrosion resistance. At the same time, the color will gradually change to gray or grayish black.

\* Highly corrosion-resistant hot-dip zinc-coated steel sheet: Coating layer of zinc, 6% aluminum, and 3% magnesium

#### <Figure 5.2-1> Mechanism of corrosion resistance production in the end face



Materials

corrosion res RD-ZA type

View of snow accumulation

View of snow accumulation

## The Building Standards Act

The Building Standards Act prescribes conditions related to the snow load.

Article 86, Enforcement Ordinance of the Installation Standards Act (excerpts)

The snow load must be calculated by multiplying the unit load of snow accumulation by the horizontal projected area of the roof and the vertical snow accumulation in the relevant region.

• 5.3.1 The Building Standards Act

for RD (example)

- 2 The unit load of snow accumulation prescribed in the preceding paragraph must be 20 newtons or more per square meter for 1cm snow accumulation. However, the specific administrative agency can specify a heavy snow area in the regulation based on the criteria stipulated by the Minister of Land, Infrastructure and Transport, and can separately determine a different standard for the area.
- 3 The vertical amount of snowfall prescribed in paragraph 1 must be the value specified in the regulation determined by the specific administrative agency based on the criteria stipulated by the Minister of Land, Infrastructure and

From the above, in a heavy snow area, it is necessary to check in advance if there is a specified "unit load of snow accumulation", "vertical snow accumulation", etc. for the area determined by the specific administrative agency.

#### Example of a case where the unit load of snow accumulation is separately determined

- ■30N per square meter for 1cm snow accumulation
- •If the snow accumulation exceeds 1m, increase the unit load by 10% for every 10cm which exceeds 1m only until the percentage reaches to 250% the upper limit.

Example of a case where the area segmentation manner for the vertical amount of snowfall differs depending on the locale

- Segmentation by city, town, and village (administrative district)
- Segmentation by height above sea level

Another example of presence of a separate regulation related to installation of facility (regulation of ensuring snow-piling space)

●For a facility with a roof (rooftop part) of 3m in horizontal length and 2m of deepest snow beam, ensure the space of at least 2m from the wall surface for piling snow.

## Calculation of snow load for RD (example)

When the assumed snow load is 3,000N per cubic meter, and the assumed vertical amount of snowfall is 2m, the snow load is 6,000N per square meter.

#### 1 Example of selecting cover

Select an appropriate RD duct type by checking the strength of cover.

Reference [1.4.2] Load capacity and strength/Strength of cover (allowable load)

#### Example

Standard type =  $4,903 \text{ N/m}^2 < 6,000 \text{ N/m}^2$ 

Walkway type =  $49,030 \text{ N/m}^2 > 6,000 \text{ N/m}^2$ 



Select the walkway type

#### 2 Example of calculating snow load

Find the area based on the size of used RD duct.

Area (S) when RDW-900 is used

 $S = L 2m \times W 0.9m$ 

 $S = 1.8m^2$ 

Area of duct is 1.8m2

Find the load for one piece of RD duct by multiplying the snow load by the area of RD duct.

Snow load applied on RDW-900 (P)

 $P = 6.000N \times 1.8m^2$ 

= 10.800N



Snow load applied on RDW-900 = 10.800N

#### 3 Example of calculating total load

Find the total load (W) by further adding the pipe weight and the product weight

Reference [1.3] Product weight

Example Total load applied on RDW-900

- Product weight of RDW-900 = 30.9kg
- Pipe weight (15.88×25.4×18 pipelines)  $= (0.45+0.72)\times18=21.06$ kg
- 1 kgf = 9.80665 N

 $W = 10,800N + (30.9 + 21.06) \times 9.8$ **≒** 11.310N

Total load applied on RDW-900 = 11.310N

## 4 Example of calculating the quantity of mounting brackets

Find the required quantity of mounting brackets (x) by dividing the total load by the load capacity of mounting bracket.

Reference [1.4.3] Load capacity and strength/Load capacity (allowable load) of mounting bracket [3.4.8] Standard pitch between bases (mounting brackets)

Required quantity of mounting brackets (x)

Load capacity of mounting bracket = 6,374N

 $x = 11,310N \div 6,374N$ 

**≒** 1.77

Two pieces of mounting bracket are required for one piece of RDW-900 (installation by 1m pitch)

#### 5 Example of calculating surface load

Find the load for 1cm<sup>2</sup> by dividing the total load by the quantity of legs of mounting bracket and the area of leg.

\* on the premise that the load is applied evenly

Load for 1cm<sup>2</sup> (v)

- Quantity of legs set for RDW-900 = 4
- · Area of leg of the RD mounting bracket
- = 22cm<sup>2</sup> (bolt part included)

 $y = 11,304N \div 4 \div 22$ ≒ 128.45

Load for  $1 \text{cm}^2 = 128.45 \text{N}$ Reference:

47.5N for CR-A/CR-W1015 1cm<sup>2</sup>

## Other notes

#### 1 Amount of snowfall and load

As to the snow accumulation and load, observing these specified values does not mean completely safe. For example, even in a case of 3,000N per cubic meter in general (specified value), if the appropriate treatment (snow removal etc.) is not performed and such condition is left as is, the density of snow will increase and the unit load of snow accumulation may exceed 5,000N depending on the case. The appropriate treatment is necessary before such situation occurs.

#### 2 Snow dropping

If a snow dropping from the upper part of installation can be assumed, a snow roof, treatment to prevent snow dropping, or snow-piling space may be required to prevent dropped snow hitting the RD duct.

#### 3 Remaining snow

Depending on the sunshine conditions, the snow will remain unmelted and new snow will fall on it, resulting in increase of amount of snowfall and unit load exceeding assumption.

#### 4 Snowdrift

Depending on the wind direction or environmental condition, the amount of snowfall may increase compared to that in the

Materials

About the corrosion resista RD-ZA type

Copper pipe

Table of copper pipe specifications

<Table 5.4.1-1> Table of copper pipe specifications

Туре	Copper	Copper pipe for air-conditioning			allation (hot-water sup	oply, water supply)
Outer diameter			Nominal	Pipe thickness (mm)		
of copper pipe (mm)	diameter	General use	Supervision guidelines	diameter	L	M
6.35	1/4 inch (6.35mm)	0.8	0.80			
9.52	3/8 inch (9.53mm)	0.8	0.80	1/4 inch (6.35mm)	0.76	
12.70	1/2 inch (12.70mm)	0.8	0.80	3/8 inch (9.53mm)	0.89	0.64
15.88	5/8 inch (15.88mm)	1.0	1.00	1/2 inch (12.70mm)	1.02	0.71
19.05	3/4 inch (19.08mm)	1.0	1.05	5/8 inch (15.88mm)	1.07	
22.22	7/8 inch (22.23mm)	1.0	1.20	3/4 inch (19.08mm)	1.14	0.81
25.40	1 inch (25.4mm)	1.0	1.35			
28.58	1-1/8 inch (28.58mm)	1.0	1.55	1 inch	1.27	0.89
31.75	1-1/4 inch (31.78mm)	1.1	1.70			
34.92	1-3/8 inch (34.93mm)	1.1	1.85	1-1/4 inch (31.78mm)	1.40	1.07
38.10	1-1/2 inch (38.10mm)	1.15	2.00			
41.28	1-5/8 inch (41.28mm)	1.2	2.15	1-1/2 inch (38.10mm)	1.52	1.24

## Pipe weight (reference value)

Copper pipe	e specification		Product weight (kg/m)	
Outer diameter of copper pipe	Copper pipe thickness	Thickness of insulation 10mm	Thickness of insulation 20mm	Thickness of insulation
6.35	0.8	0.14	0.18	_
9.52	0.8	0.21	0.26	0.24
12.70	0.8	0.29	0.34	0.32
15.88	1.0	0.45	0.49	0.47
	1.0	0.54	_	
19.05	1.05	0.56	0.61	
	1.2	0.63	_	
22.22	1.0	0.63	0.68	
22.22	1.2	0.74	0.80	
25.40	1.0	0.72	0.78	- - -
23.40	1.35	_	1.01	
28.58	1.0	0.81	0.88	
20.00	1.55	_	1.28	
31.75	1.1	0.99	1.05	
31.73	1.7	_	1.54	_
34.92	1.1	1.09	1.16	
34.92	1.85	_	1.83	
38.10	1.35	1.46	_	
36.10	2.0	_	2.15	
41.28	1.45	1.68	1.75	
41.20	2.15	-	2.49	
44.45	1.55	1.92	2.00	
44.40	2.3	_	2.86	
50.80	1.4	2.04*1	2.07	
50.60	2.65	_	3.73	
53.98	1.5	2.32*1	_	
55.90	2.8	_	4.18	]

(Note 1) Values in the table are the theoretically calculated values, and not the measured values. ※1...Thickness of the insulation is 15mm.

# SI units

## Table of SI units

Length	Meter	m
Mass	Kilogram	kg
Time	Second	S
Current	Ampere	Α
Thermodynamical temperature	Kelvin	K
Amount of substance	Mol	mol
Luminous intensity	Candela	cd

Solid angle Steradian sr			
	SI supplementary unit		
Solid angle Steradian sr	Plane angle	Radian	rad
	Solid angle	Steradian	sr

SI prefix					
Multiple by which the unit is multiplied	Symbol	Name	Multiple by which the unit is multiplied	Symbol	Name
1018	E	exa	10-1	d	deci
1015	Р	peta	10-2	С	centi
1012	Т	tera	10-3	m	milli
10 <sup>9</sup>	G	giga	10-6	μ	micro
10 <sup>6</sup>	М	mega	10-9	n	nano
10³	k	kilo	10-12	р	pico
10 <sup>2</sup>	h	hecto	10 <sup>-15</sup>	f	femto
10¹	da	deca	10 <sup>-18</sup>	а	atto

## SI unit conversion table

(Unit enclosed by the bold line is the SI unit.)

	N	dyn	kgf
Force	1	1 × 10 <sup>5</sup>	$1.019 72 \times 10^{-1}$
	1 × 10 <sup>-5</sup>	1	1.019 72×10 <sup>-6</sup>
	9.806 65	9.806 65×10 <sup>5</sup>	1

	Pa∙s	cР	Р
Vicesity	1	1×10³	1×10
Viscosity	1×10⁻³	1	1×10 <sup>-2</sup>
	1×10 <sup>-1</sup>	1×10²	1

Note IP=1dyn·s/cm²=1g/cm·s, 1Pa·s=1N·s/m², 1cP=1mPa·s

	Pa or N/m	MPa or N/mm	kgf/mm²	kgf/cm²
	1	1×10 <sup>-6</sup>	1.019 72×10 <sup>-7</sup>	1.019 72×10 <sup>-5</sup>
ress	1×10°	1	1.019 72×10 <sup>-1</sup>	1.019 72×10
	9.806 65×10 <sup>6</sup>	9.806 65	1	1×10 <sup>2</sup>
	0.006.65 > 104	0 006 65 ~ 10-2	1 > 10-2	1 1

	m²/s	cSt	St
atic	1	1×10°	1×10 <sup>4</sup>
ity	1×10⁻⁵	1	1×10 <sup>-2</sup>

Note	1St=1cm²/s.	lcSt=1mm²/s

viscosi

	Note 1Pa=1N/m	n²、1MPa=1N/mn	n²					
	Pa	kPa	MPa	bar	kgf/cm²	atm	mmH₂O	mmHg or Torr
	1	1×10 <sup>-3</sup>	1×10⁻⁵	1×10⁻⁵	1.019 72×10 <sup>-5</sup>	9.869 23×10 <sup>-6</sup>	1.019 72×10 <sup>-1</sup>	7.500 62×10 <sup>-3</sup>
	1×10³	1	1×10 <sup>-3</sup>	1×10⁻²	1.019 72×10 <sup>-2</sup>	9.869 23×10 <sup>-3</sup>	$1.01972 \times 10^{2}$	7.500 62
	1×10°	1×10³	1	1×10	1.019 72×10	9.869 23	1.019 72×10 <sup>5</sup>	7.500 62×10 <sup>3</sup>
Pressure	1×10 <sup>5</sup>	1×10 <sup>2</sup>	1×10 <sup>-1</sup>	1	1.019 72	9.869 23×10 <sup>-1</sup>	1.019 72×10 <sup>4</sup>	7.500 62×10 <sup>2</sup>
	9.806 65×10⁴	9.806 65×10	9.806 65×10 <sup>-2</sup>	9.806 65×10 <sup>-1</sup>	1	9.678 41×10 <sup>-1</sup>	1×10 <sup>4</sup>	7.355 59×10 <sup>2</sup>
	1.013 25×10⁵	1.013 25×10 <sup>2</sup>	1.013 25×10 <sup>-1</sup>	1.013 25	1.033 23	1	1.033 23×10⁴	7.600 00×10 <sup>2</sup>
	9.806 65	9.806 65×10 <sup>-3</sup>	9.806 65×10 <sup>-6</sup>	9.806 65×10 <sup>-5</sup>	1×10 <sup>−4</sup>	9.678 41×10 <sup>-5</sup>	1	7.355 59×10 <sup>-2</sup>
	1.333 22×10 <sup>2</sup>	1.333 22×10 <sup>-1</sup>	1.333 22×10 <sup>-4</sup>	1.333 22×10⁻³	1.359 51×10⁻³	1.315 79×10 <sup>-3</sup>	1.359 51×10	1

	11000	-			
	J	kW∙h	kgf⋅m	kcal	
Work,	1	2.777 78×10 <sup>-7</sup>	1.019 72×10 <sup>-1</sup>	2.388 89×10 <sup>-4</sup>	F
Energy,	3.600×10°	1	3.670 98×10 <sup>5</sup>	8.600 0×10 <sup>2</sup>	V
Heat	9.806 65	2.724 07×10⁻°	1	2.342 70×10 <sup>-3</sup>	H
	4.186 05×10 <sup>3</sup>	1.162 79×10 <sup>-3</sup>	4.268 58×10 <sup>2</sup>	1	i

	W	kgf·m/s	PS	kcal/h
ower, Iork rate, Iotive power.	1	1.019 72×10 <sup>-1</sup>	1.359 62×10 <sup>-3</sup>	8.600 0×10 <sup>-1</sup>
	9.806 65	1	1.333 33×10 <sup>-2</sup>	8.433 71
leat flow	$7.355 \times 10^{2}$	7.5×10	1	6.325 29×10 <sup>2</sup>
1001	1.162 79	1.185 72×10 <sup>-1</sup>	1.580 95×10 <sup>-3</sup>	1

Note 1W=1J/s, PS: French horse-power,

		_
	W/(m·K)	kcal/(h·m·℃)
Thermal conductivity	1	8.600 0×10 <sup>-1</sup>
Conductivity	1 162 70	1 1

Note 1J=1W·s, 1J=1N·m,

Thermal	W/(m²⋅K)	kcal/(h·m²·°C)
conductivity	1	8.600 0×10 <sup>-1</sup>
coefficient	1.162 79	1

	Specific heat	J/(kg·K)	kcal/(kg·℃) cal/(g·℃)
		1	2.388 89×10 <sup>-4</sup>
4.100 00 × 10	ricat	4.186 05×10°	1

1PS=0.735kW (by Measurement Law Enforcement Act). 1cal=4.18605J (depends on the calculation method)

Note 1cal=4.18605J Note 1 cal=4.18605J

4.100 00 × 10
Note 1 cal=4.18605J
(depends on the calculation method)

## **SLIMDUCT**™**RD** Design and installation materials

August 2024

INABA DENKI SANGYO CO, LTD. Inaba Denko Products Overseas Sales Department

4-11-14, ITACHIBORI, NISHI-KU, OSAKA, JAPAN 550-0012 Tel: +81 (0) 6-4391-1920 Fax: +81 (0) 6-4391-1935 E-MAIL: inabadenko-overseas@gr-inaba.com